

# Axioline F: system and installation

User manual

# User manual

## Axioline F: system and installation

UM EN AXL F SYS INST, Revision 14

2024-02-05

---

This user manual is valid for:

All modules of the Axioline F product group without bus-specific special features.

# Table of contents

1	For your safety .....	9
1.1	Identification of warning notes .....	9
1.2	Qualification of users .....	9
1.3	Intended use .....	9
1.4	Product changes .....	9
2	Documentation landscape of Axioline F .....	10
2.1	Available documents .....	10
2.2	Documentation on the Internet .....	12
2.3	Purpose of this user manual .....	12
3	The Axioline F product group .....	13
3.1	Axioline F – the block modular I/O system .....	13
3.2	Structure of an Axioline F station .....	13
3.3	Product description .....	14
3.4	Approvals .....	19
4	Axioline F modules at a glance .....	20
4.1	Axioline F order designation .....	20
4.2	Controller .....	23
4.2.1	Controllers overview .....	23
4.2.2	Controllers and left-alignable modules AXC F XT ... ..	23
4.3	Bus coupler .....	26
4.4	Input and output modules .....	27
4.4.1	Overview .....	27
4.4.2	Extreme conditions version (XC) .....	28
4.4.3	Safety modules with safe digital inputs or outputs .....	29
4.4.4	Intrinsically safe modules for the EX area (Ex i) .....	30
4.5	Power module for the communications power $U_{BUS}$ .....	34
4.6	Master .....	34
4.7	Backplane for Axioline Smart Elements .....	34

5	Housing versions, design, and dimensions.....	35
5.1	Housing versions.....	35
5.2	Basic design of Axioline F modules .....	37
5.2.1	Class 3000 AXC controller .....	37
5.2.2	Class 2000 AXC F controller .....	38
5.2.3	Bus couplers and class 1000 AXC controllers .....	39
5.2.4	I/O module (electronics module) .....	40
5.3	Axioline F module dimensions.....	41
5.3.1	AXC controller and bus coupler .....	41
5.3.2	I/O modules for the 24 V area .....	42
5.3.3	I/O modules for the low voltage area .....	44
5.3.4	Power measurement module .....	45
5.3.5	HART/NAMUR .....	45
5.3.6	Intrinsically safe modules .....	45
5.4	Bus base modules.....	46
5.5	Axioline F connectors .....	47
5.5.1	Versions and dimensions .....	47
5.5.2	Basic design .....	48
5.6	Color and marking .....	49
6	Transport, storage, and unpacking .....	52
6.1	Transport.....	52
6.2	Storage.....	52
6.3	Unpacking .....	52
7	Mounting and removing modules.....	53
7.1	Safety notes for mounting and removal .....	53
7.1.1	General safety notes .....	53
7.1.2	Additional safety notes for the low voltage area .....	55
7.2	Basic information about mounting .....	56
7.3	Left alignment.....	60
7.4	Mounting the modules .....	60
7.4.1	Bus base modules, controllers, and bus couplers .....	61
7.4.2	I/O modules .....	62
7.5	Removing modules.....	63
7.5.1	Removing connectors or cables .....	63
7.5.2	Controller, bus coupler, and I/O modules .....	64
7.6	Removing or inserting a connector .....	66
7.6.1	Removing a connector .....	66
7.6.2	Inserting a connector .....	66
7.7	Replacing a module.....	66



---

7.8	Mounting distances .....	67
7.8.1	AXC 305x and AXC F x152 controllers .....	67
7.8.2	AXC F x152 controllers and bus couplers .....	68
7.8.3	I/O modules .....	68
7.8.4	Axioline F backplane .....	69
8	Connecting or removing cables .....	70
8.1	Connections and cables in the Axioline F system .....	70
8.2	Conductor cross sections and stripping and insertion lengths .....	71
8.3	Terminal point, associated spring lever, and associated touch connection .....	73
8.4	Connecting unshielded cables .....	74
8.5	Connecting shielded cables .....	75
8.6	Removing cables from the terminal point .....	76
8.7	Connecting the power supplies .....	77
8.7.1	Axioline F system supply .....	77
8.7.2	Power supply requirements .....	78
8.7.3	Supply at the controller or bus coupler .....	78
8.7.4	Supply at the power module .....	78
8.7.5	Supply at the I/O modules .....	79
8.7.6	Jumpers in power connectors, potential forwarding, and fusing .....	79
8.7.7	Parallel supply .....	80
8.8	Connecting the network .....	80
8.9	Connecting the USB cable to the USB interface .....	81
8.10	Connecting sensors and actuators .....	82
8.10.1	Connection technology for sensors and actuators .....	82
8.10.2	Connections used for extra-low voltage digital I/O modules .....	83
8.10.3	Connecting digital sensors and actuators using different connection technologies .....	84
8.10.4	FLK .....	87
8.10.5	Redundant signals .....	88

9	Grounding and shielding.....	90
9.1	Grounding concept.....	90
9.1.1	Protective ground (PE) .....	90
9.1.2	Functional ground (FE) .....	91
9.2	Shielding concept.....	92
9.2.1	Shielding with Axioline F .....	92
9.2.2	Shielding when connecting analog sensors and actuators .....	92
9.2.3	Connecting the shield using the Axioline F shield connection set .....	93
9.2.4	Connecting the shielding to a busbar .....	97
9.2.5	Integrating analog shielding in a concept with central equipotential bonding at the control cabinet entry .....	98
10	Diagnostic and status indicators .....	99
10.1	Indicators on controllers .....	99
10.2	Indicators on bus couplers.....	100
10.3	Indicators on I/O modules.....	102
10.3.1	LEDs on the power connectors .....	102
10.3.2	LEDs on the I/O connectors .....	104
10.4	Reporting diagnostics via PDI.....	104
11	Axioline F backplane.....	105
11.1	Housing versions.....	105
11.2	Basic design .....	106
11.3	Dimensions.....	107
11.3.1	Dimensions of the backplanes .....	107
11.3.2	Dimensions of the backplanes with inserted Smart Elements .....	108
11.4	Color and marking .....	109
11.5	Mounting and removing the backplane.....	111
11.5.1	Safety notes for mounting and removal .....	111
11.5.2	Basic information about mounting .....	111
11.5.3	Mounting the backplane and Smart Elements .....	112
11.5.4	Removing the backplane .....	115
11.5.5	Replacing the backplane .....	117
11.5.6	Mounting distances .....	117
11.6	Connecting and removing cables .....	118
11.6.1	Connections and cables at an Axioline F backplane .....	118
11.6.2	Conductor cross sections and stripping and insertion lengths .....	118
11.6.3	Connecting cables .....	120
11.6.4	Removing cables from the terminal point .....	121

11.7	Power supplies .....	122
11.7.1	Supplying the Axioline F system with Axioline F backplanes .....	122
11.7.2	Supply at the Axioline F backplane .....	123
11.7.3	Jumpers, potential forwarding, and fusing .....	123
11.8	Grounding and shielding.....	124
11.9	Diagnostic and status indicators .....	125
12	Process, parameter, and diagnostic data.....	127
12.1	Process data .....	127
12.2	Parameter and diagnostic data (PDI channel) .....	127
12.3	Saving of parameters .....	128
13	Software support .....	129
14	Device replacement, device defect and repair .....	130
14.1	Device replacement.....	130
14.2	Device defect and repair.....	130
15	Maintenance, decommissioning, and disposal .....	131
15.1	Maintenance.....	131
15.2	Decommissioning and disposal .....	131
16	Technical data and ordering data .....	132
16.1	Technical data .....	132
16.2	Ordering data .....	138
A	Technical appendix: communication objects (PDI objects).....	143
A 1	General standard objects .....	144
A 1.1	Objects for identification .....	144
A 1.2	Objects for diagnostics .....	147
A 1.3	Objects for process data management .....	151
A 1.4	Objects for device management .....	152
A 1.5	Objects for object descriptions .....	155
A 1.6	Objects for energy management .....	155
A 1.7	Objects for modular devices .....	155
A 2	Manufacturer-specific application objects .....	156
A 3	Value ranges .....	156
A 4	Function blocks for access to the objects .....	156

B	Technical appendix: Altitude, times, synchronization, substitute value behavior, and power-on behavior.....	157
B 1	Use of Axioline F modules at an elevation of more than 3000 meters.....	157
B 2	Transmission speed .....	158
B 3	Typical cycle time on the local bus .....	158
B 4	Response times in an Axioline F system .....	159
B 5	Synchronization.....	164
B 5.1	Synchronization in general .....	164
B 5.2	Synchronization options .....	166
B 5.3	Conditions for local bus synchronization .....	166
B 6	Substitute value behavior and power-on behavior .....	167
C	Technical appendix: Controllers, bus couplers, AXL SE SC ... and AXL SE PD ... ..	168
C 1	AXL SE SC, AXL SE PD ... ..	168
C 2	AXL SE SC-A .....	169
D	Index.....	170
E	Revision history .....	173

# 1 For your safety

Read this user manual carefully and keep it for future reference.

## 1.1 Identification of warning notes



This symbol indicates hazards that could lead to personal injury.

There are three signal words indicating the severity of a potential injury.

### **DANGER**

Indicates a hazard with a high risk level. If this hazardous situation is not avoided, it will result in death or serious injury.

### **WARNING**

Indicates a hazard with a medium risk level. If this hazardous situation is not avoided, it could result in death or serious injury.

### **CAUTION**

Indicates a hazard with a low risk level. If this hazardous situation is not avoided, it could result in minor or moderate injury.



This symbol together with the **NOTE** signal word warns the reader of actions that might cause property damage or a malfunction.



Here you will find additional information or detailed sources of information.

## 1.2 Qualification of users

The use of products described in this user manual is oriented exclusively to electrically skilled persons or persons instructed by them. The users must be familiar with the relevant safety concepts of automation technology as well as applicable standards and other regulations.

## 1.3 Intended use

Axioline F controllers, bus couplers, and I/O modules should only be used according to the instructions in the module-specific documentation and this user manual. Phoenix Contact accepts no liability if the device is used for anything other than its designated use.

## 1.4 Product changes

Modifications to hardware and firmware of the device are not permitted.

Incorrect operation or modifications to the device can endanger your safety or damage the device. Do not repair the device yourself. If the device is defective, please contact Phoenix Contact.

## 2 Documentation landscape of Axioline F

### 2.1 Available documents

The documentation for the Axioline F product group is modular, providing you with the optimum information to meet your requirements.



In the following table, the term “module” is used for the controller, bus coupler, and I/O module.

Table 2-1 Axioline F documentation

Document	Contents
<b>System: information on the Axioline F system</b>	
User manual “Axioline F: system and installation” UM EN AXL F SYS INST (this manual)	This manual is the generic system manual for Axioline F.  It describes the Axioline F product group and everything about mounting, removing and wiring the Axioline F modules, regardless of a higher-level network.
User manual “Axioline F: diagnostic registers and error messages” UM EN AXL F SYS DIAG	The user manual lists all error messages for the system and provides remedial measures.
<b>Module: basic information on a specific module</b>	
Packing slips, Installation notes for electrically skilled persons	The packing slip contains key information for the electrical installation of a module or group of modules. This includes, for example: <ul style="list-style-type: none"> <li>– Short description</li> <li>– Safety notes</li> <li>– Mounting and removal</li> <li>– Terminal point assignment</li> </ul> The packing slip is provided with the module upon delivery and/or is available on the Internet in the download area of the module.  If no packing slip is available, refer to the data sheet or user manual for the product or system used.
User manuals for safety modules and controllers	The user manual for each safety module or controller contains the complete information needed for use.  This includes at the very least: <ul style="list-style-type: none"> <li>– Description</li> <li>– Mounting, removal and power supply</li> <li>– Startup under PC Worx or PLCnext Engineer</li> <li>– Technical data and ordering data</li> </ul>

Table 2-1 Axioline F documentation [...]

Document	Contents
Module-specific data sheets	<p>The data sheet for each module contains the complete information needed for use.</p> <p>This includes at the very least:</p> <ul style="list-style-type: none"> <li>– Function description</li> <li>– Accessories</li> <li>– Technical data</li> <li>– Connection assignment or terminal point assignment</li> <li>– Local diagnostic and status indicators</li> <li>– Connection examples</li> </ul>
<b>Additional: information on a specific module</b>	
Additional user manuals	<p>The additional user manuals either describe:</p> <ul style="list-style-type: none"> <li>– A bus coupler connected to a network or</li> <li>– A specific module</li> </ul> <p>Each user manual only describes the relevant module and/or bus-specific special features. Being a generic manual, the UM EN AXL F SYS INST user manual also applies.</p>
Quick start guides	Quick start guides are available for various topics. A quick start guide describes the startup of a system or module step by step using an example.
Application notes	Application notes provide additional information about special topics.
<b>Up-to-date PDF</b>	
Generate product PDF	<p>On the corresponding product detail page of an item at <a href="https://phoenixcontact.com/products">phoenixcontact.com/products</a>, you can click the “Show Product Details (PDF)” button and download up-to-date information on the product (see <a href="#">Section “Documentation on the Internet” on page 12</a>).</p> <p>This includes e.g.:</p> <ul style="list-style-type: none"> <li>– Commercial data</li> <li>– Technical data</li> <li>– Drawings</li> <li>– Approvals</li> <li>– Classifications</li> <li>– Environmental product compliance</li> <li>– Accessories</li> </ul>

## 2.2 Documentation on the Internet

The documentation can be downloaded at [phoenixcontact.com/products](https://phoenixcontact.com/products). Here you will find information on each product. During your search, take into account the difference between “Show Product Details (PDF)” and “Downloads”.

### Show Product Details (PDF)

Click the “Show Product Details (PDF)” button to receive selected up-to-date information. It provides a **short overview** of the module.

The generated PDF file contains the essential product information. If you require further information, you can use the menu item “Downloads”.

### Downloads

Under the menu item “Downloads”, you can access the **complete** documentation and all other downloads related to a module.

Module-specific documentation can be found in the download area for the corresponding module.

Comprehensive documentation can be found in the download area for the bus coupler.

## 2.3 Purpose of this user manual

This user manual informs you about the Axioline F system. It describes the system and everything about Axioline F module mounting and wiring regardless of a higher-level network.



## 3 The Axioline F product group

### 3.1 Axioline F – the block modular I/O system

Axioline F is a block modular I/O system for the control cabinet. Open to all Ethernet-based communication protocols and available in various designs, Axioline F offers maximum flexibility.

### 3.2 Structure of an Axioline F station

An Axioline F station consists of individual modules, which are snapped onto a DIN rail. A controller or a bus coupler forms the head of the station. I/O modules are mounted next to it. Bus base modules are used for connecting the individual Axioline F modules to one another and to the station head. The bus base modules are snapped onto the grounded DIN rail side by side and thus form the Axioline F local bus.

You can integrate Axioline Smart Elements into an Axioline F station by means of an Axioline F backplane.




Figure 3-1 Example of an Axioline F station

- 1 DIN rail
- 2 End bracket (for securing the station; see [“End brackets” on page 58](#))
- 3 Bus head (bus coupler or controller)
- 4 Axioline F backplane with Axioline Smart Elements
- 5 Axioline F input or output modules
- 6 Bus base module



For detailed information regarding the function, properties, wiring, and parameterization, please refer to the module-specific documentation.

For detailed information regarding the Axioline F backplane, refer to [Section “Axioline F backplane” on page 105](#).

If you install intrinsically safe modules, refer to [Section “Intrinsically safe modules for the EX area \(Ex i\)” on page 30](#).

### 3.3 Product description

Axioline F modules with various functions are available within the Axioline F product group. Additionally, Axioline F backplanes are available, which you can use to integrate Axioline Smart Elements with different functions into an Axioline F station.

#### Axioline F backplane

The Axioline backplanes are described in detail in [Section “Axioline F backplane” on page 105](#).

#### Axioline F modules

The Axioline F modules consist of an electronics module, one or several connectors, and a bus base module.

The electronics module can be changed without having to remove a wire from the connector.

The bus base modules are snapped onto the DIN rail side by side and thus form the Axioline F local bus that connects the modules to one another.



The Axioline F local bus is subsequently referred to as the local bus.




Figure 3-2 Components of an Axioline F I/O module

Key:

- 1 Bus base module
- 2 Electronics module
- 3 Connector for connecting the supply voltage
- 4 I/O connector

#### Versions

Modules are available for the following automation tasks:

- Controllers
- Bus couplers to integrate the Axioline F station into various networks (PROFINET, Sercos, PROFIBUS, etc.).
- Input and output modules for digital and analog signals
- Modules for temperature measurement
- Modules for open and closed-loop control, and position detection
- Modules for communication
- ...

This product range is growing continuously.

## Voltage ranges

Axioline F modules are available for the protective extra-low voltage range and the low voltage range. You can use low-voltage modules and extra-low voltage modules directly next to each other within an Axioline F station.

Tabelle 3-1 Spannungsbereiche nach Normen

Voltage range	Permissible voltage		Standard
	AC	DC	
Low voltage	≤ 1000 V	≤ 1500 V	DIN EN 61140 (VDE 0140-1) DIN VDE 0100-410
– Extra-low voltage (ELV)	≤ 50 V	≤ 120 V	
– Protective extra-low voltage (PELV)	≤ 50 V	≤ 120 V	
– Safety extra-low voltage (SELV)			
– Protective extra-low voltage (PELV)	≤ 30 V	≤ 60 V	DIN EN 61131-2 (PLC standard) DIN EN IEC 61010-2-201
– Safety extra-low voltage (SELV)			

Table 3-2 Voltage ranges for Axioline F

Voltage range	Product groups	Nominal voltage used	Permissible voltage range	Examples
Protective extra-low voltage	Extra-low voltage modules	24 V DC	19.2 V DC ... 30 V DC	AXL F DI16/4 2F
		48 V DC, 60 V DC	-100 V DC ... 100 V DC	AXL F DI8/2 48/60DC 1F
Low voltage	Low-voltage modules	110 V DC/ 220 V DC	-300 V DC ... 300 V DC	AXL F DI8/2 110/220DC 2F
		220 V DC 230 V AC	-300 V DC ... 300 V DC 24 V AC ... 230 V AC (50 Hz ... 60 Hz)	AXL F DOR4/2 AC/220DC 1F
		230 V AC	12 V AC ... 253 V AC (50 Hz ... 60 Hz)	AXL F DO4/3 AC 1F
		400 V AC (conductor-neutral conductor, not phase to phase) 690 V AC (conductor-conductor, phase to phase)	0 V AC ... 440 V AC (conductor-neutral conductor, not phase to phase) 0 V AC ... 760 V AC (conductor-conductor, phase to phase)  CAT III 300 V / CAT II 400 V in accordance with DIN EN 61010-1 and DIN EN 61010-2-030	AXL F PM EF 1F



The instructions given in this user manual and in the module-specific documentation must be followed during installation and startup.

Particularly observe:

[Section "Safety notes for mounting and removal" on page 53.](#)

<b>Mounting location</b>	<p>The Axioline F modules meet IP20 degree of protection and can be used in closed control cabinets or control boxes (junction boxes) with IP54 degree of protection according to EN 60529 or higher.</p> <p>The compact design means that the Axioline F modules can be installed in standard junction boxes. Please observe the mounting distances when selecting the housing, see <a href="#">Section "Mounting distances" on page 67</a>.</p>
<b>Mounting</b>	<p>Each Axioline F module consists of a bus base module and an electronics module. Snap the bus base modules onto the grounded DIN rail without the need for tools and arrange the modules side by side. The local bus is created automatically when the bus base modules are installed next to one another.</p> <p>Then, snap the electronics modules onto the DIN rail over the bus base modules.</p> <p>See <a href="#">Section "Mounting and removing modules" on page 53</a>.</p>
<b>Removal</b>	<p>Only a standard tool is necessary for removing the electronics module (e.g., a bladed screwdriver with a blade width of 2.5 mm).</p> <p>See <a href="#">Section "Mounting and removing modules" on page 53</a>.</p>
<b>Bus connection (network)</b>	<p>The Axioline F station is integrated in the network using a controller or a bus coupler.</p>
<b>Axioline F local bus</b>	<p>There is an interface to the Axioline F local bus on the bottom of the modules. Bus base modules are used to carry the communications power and the bus signals from the controller or bus coupler through the Axioline F station. The bus base module is supplied as standard with each module.</p> <p>The maximum number of Axioline F modules within a station is 63. The actual number of modules within an Axioline F station may be limited by the supplied logic current, the current consumption of the connected modules, and the system limits of the controller or bus coupler.</p> <p>Use the Project+ configuration software to calculate the individual process or parameter data and the corresponding number of devices that can be connected. It can be found at: <a href="http://phoenixcontact.com/product/2688394">phoenixcontact.com/product/2688394</a>.</p> <p>See <a href="#">Section "Maximum number of modules" on page 58</a>.</p>
<b>Connectors</b>	<p>Axioline F modules have connectors for connecting the power supply and the I/O. The connectors have spring-cage terminal blocks. Suitable conductors can be connected with Push-in technology (see <a href="#">Section "Conductor cross sections and stripping and insertion lengths" on page 71</a>).</p>
<b>Connecting the supply voltage</b>	<p>The communications power for the Axioline F station is supplied at the controller or bus coupler. The voltage for the module's I/O is supplied separately to each I/O module (see <a href="#">Section "Connecting the power supplies" on page 77</a>).</p>
<b>I/O connection</b>	<p>Sensors and actuators are connected using connectors (see <a href="#">Section "Connecting sensors and actuators" on page 82</a>).</p> <p>Depending on the module, the sensor/actuator cables are connected in one direction (at the bottom) or in two directions (at the top and at the bottom).</p>

**FE connection**

On the bottom of each module, there is at least one FE spring (metal contact) which establishes the connection to functional ground when the module is snapped onto a grounded DIN rail.

**Programming interface, service interface**

On some controllers and bus couplers, there is a USB interface that can be used as a programming interface or service interface. In addition to providing the network interface, it enables communication with the controller or bus coupler from a PC.

**NOTE: Damage to the USB interface**

In PCs, the USB ports are usually not electrically isolated from the rest of the hardware. This does not cause any problems for USB devices that do not have their own reference ground. However, if you connect grounded devices (e.g., the bus coupler), ground loops with undesired compensating currents may occur. These compensating currents can impair data transmission and, in extreme cases, destroy the interfaces.

**Recommended:**

Connect the USB interface of the bus coupler to your PC in such a way that it is electrically isolated.

To do this, use a USB isolator.

**Startup+**

For information on Startup+, refer to [Section 13, "Software support"](#) and the corresponding documentation.

**Web-based management**

By means of the web-based management integrated into the controllers and some bus couplers, you have the option to display static and dynamic information of the controller using a standard browser. The status and diagnostic functions can be displayed on a graphical user interface by means of read access via a device network connection. In addition, specific controller/bus coupler properties can be configured via web-based management.

**Diagnostics**

The Axioline F system provides comprehensive diagnostics:

- Remote diagnostics
- Process diagnostics (e.g., cycle time monitoring)
- Communication diagnostics
- Module diagnostics (status of Axioline F module)
- I/O diagnostics (status of sensors/actuators)

For the diagnostic options of a specific module, refer to the module-specific data sheets.

**Reset button**

The reset button provided on the controllers and bus couplers can only be operated with a pointed object (e.g., a pen) and is therefore protected against accidental activation.

If the reset button is actuated during operation, the controller or bus coupler is restarted.

Using the reset button, the controller or bus coupler can also be reset to the default settings.



For more detailed information on the reset button, refer to the module-specific documentation.

### Memory (controller)

The controllers have an internal flash memory. Alternatively, you can use a plug-in memory device, such as an SD card or a USB stick.



For more detailed information on the flash memory, refer to the user manual for the controller used.

### 3.4 Approvals

For the latest approvals for a module, please visit [phoenixcontact.com/products](https://phoenixcontact.com/products).



Observe any notes and restrictions on the approvals in the module-specific packing slip or in the module-specific documentation.

#### Searching for approvals of a product

When searching for the approvals of a specific product, please proceed as follows:

- Enter the order designation, a part of it, or the order number in the search window.
- Select the product.
- In the “Product Details” area, open the “Approvals” item.

The current approvals of the product are listed.

Product details

Expand all ▾

Product description ▾

**Approvals**

 Approval ID: TAA00000DF	 Approval ID: LR2001902TA-08	 Approval ID: 14A006
 Approval ID: 36433/B4 BV	 Approval ID: TE1020/88090/21	 Approval ID: 840
 Approval ID: ELE283021XG	 Approval ID: 20-2089164-PDA	 Approval ID: E238706
 Approval ID: TR_TR_D_01831-19	 Approval ID: 23-02-63242	

Figure 3-3 Current approvals (example)

#### Searching for all products that have a specific approval

When searching for products that have a specific approval, e.g., GL or ATEX-approved products, proceed as follows:

- Enter AXL F, for example, in the search window.
- Open the “Approval” filter.
- Activate the check box for the desired approval. Confirm your selection with “Apply”.

This results in a list of all modules that have the selected approval.




Figure 3-4 Selecting ATEX approval

## 4 Axioline F modules at a glance

### 4.1 Axioline F order designation

The order designation helps you to identify the function of a module.

Examples:	Product group	Function and number of inputs or outputs	Wire connection	Function extension	Housing
	AXL F	BK		PB	
	AXL F	DI16	/1	HS	1H
	AXL F	DI16	/4	XC	2F
	AXL F	AI4		I	1H
	AXL F	DO8	/2	2A	1H
	AXL F	PSDO8	/3		1F
	AXL F	DO4	/3	AC	1F
	AXL F	DOR4	/2	AC/220DC	1F
	AXL F	DI8	/2	110/220DC	1F
	AXL F	EX IS AI8		HART XC	1F
	AXL F	BP		SE6	

Table 4-1 Structure of the order designations

<b>Product group</b>	AXL F	Axioline F
	AXC	Axioccontrol for the direct control of Axioline F I/Os
	AXC F	PLCnext Control for direct control of Axioline F I/Os
<b>Function</b>	BK	Bus coupler
	DI	Digital input
	DO	Digital output
	DOR	Relay output
	SDI	Safe digital input
	SDO	Safe digital output
	P(SDI, SDO)	PROFIsafe
	AI	Analog input
	AO	Analog output
	RTD	Analog input for the connection of resistance temperature detectors
	UTH	Analog input for the connection of thermocouple sensors
	CNT	Counter
	INC	Incremental encoder input
	SSI	SSI interface for absolute encoders
	RS UNI	Communication module for serial data transmission via RS-232 or RS-485/422



Table 4-1 Structure of the order designations [...]

<b>Function</b>	PWR	Supply
	PM	Power measurement
	MA	Master
	IOL	IO-Link
	SGI	Strain gauge acquisition
	PWM	Pulse width modulation
	XT ETH	Left-alignable Ethernet interface
	XT IB	Left-alignable INTERBUS master
	XT PB	Left-alignable PROFIBUS master
	XT EXP	Left-alignable PCIe extension interface
	XT SPLC	Left-alignable safety-related controller
	XT ML	Left-alignable module with machine learning function
	IL ADAPT	Inline adapter terminal
	EX IS	Intrinsically safe module
	BP	Backplane for accepting Smart Elements (Axioline SE modules)
<b>Number of inputs or outputs</b>	1 ... 64	1 channel ... 64 channels
<b>Function extension (for bus couplers (BK): bus system/network)</b>	PN	PROFINET
	S3	Sercos
	PB	PROFIBUS DP
	EC	EtherCAT®
	ETH	Ethernet (Modbus/TCP)
	SAS	Ethernet (IEC 61850, MMS, and GOOSE)
	EIP	EtherNet/IP™
<b>Function extension (for controllers and left-alignable extension modules)</b>	1xxx	Performance class 1000
	3xxx	Performance class 3000
	2152	Performance class 2000

Table 4-1 Structure of the order designations [...]

<b>Function extension (for other modules)</b>	HS	High speed
	XC	Extreme conditions (extreme ambient conditions)
	S	Speed
	I	Current
	U	Voltage
	2A	2 A outputs
	FLK	FLK connection
	AC	Low voltage range AC (nominal voltage 230 V AC)
	AC/220DC	Low voltage range AC and DC (nominal voltage 230 V AC, 220 V DC)
	110/220DC	Low voltage range DC (nominal voltage 110 V DC, 220 V DC)
	IB	INTERBUS
	DALI	DALI
	HART	Suitable for the connection of HART devices
	NAM	Suitable for the connection of NAMUR sensors
	SE4	4 Smart Elements
	SE6	6 Smart Elements
<b>Connection technology (for controllers)</b>	1TX	1 Ethernet interface
<b>Connection technology (for digital modules only)</b>	/4	4-wire technology
	/3	3-wire technology
	/2	2-wire technology
	/1	1-wire technology
<b>Housing</b>	1F	1 terminal field, F housing (wide housing), cable outlet at the bottom
	2F	2 terminal fields, F housing (wide housing), cable outlets at the bottom and top
	1H	1 terminal field, H housing (narrow housing), cable outlet at the bottom
	2H	2 terminal fields, H housing (narrow housing), cable outlets at the bottom and top

## 4.2 Controller

### 4.2.1 Controllers overview




Figure 4-1 Example: AXC 1050, AXC 3050, and AXC F 2152

A controller is a modular control system with integrated Ethernet and Axioline F local bus connection. As the head of an Axioline F station, the controller provides the function of a control system.

Choose a class 1000 controller for small to medium-sized automation tasks and benefit from the Axioline F local bus, PROFINET, Modbus/TCP, and an integrated UPS, for example.

A class 3000 controller is the ideal controller for medium-sized to complex applications in which networking options as well as a particularly short processing and response speed are required.

The AXC F 2152 controller is fast, robust and easy to use. It is consistently designed for maximum performance, easy handling and use in harsh industrial environments.

### 4.2.2 Controllers and left-alignable modules AXC F XT ...

In principle, you can extend the controllers by connecting Axioline F modules on the right. Furthermore, you can also add hardware functions to the left of the PLCnext Control AXC F 2152 and AXC F 3252 devices.

The following left-alignable modules (extension modules) are currently available:

#### Available at the time this user manual was created:


- |           |                    |  |
|-----------|--------------------|--|
| – 2403115 | AXC F XT ETH 1TX   | Left-alignable Ethernet interface                                  |
| – 2403018 | AXC F XT IB        | Left-alignable INTERBUS master                                     |
| – 1139999 | AXC F XT EXP       | Left-alignable PCIe extension interface                            |
| – 1091657 | AXC F XT PB        | Left-alignable PROFIBUS master                                     |
| – 1159811 | AXC F XT SPLC 1000 | Left-alignable safety-related controller of performance class 1000 |
| – 1259849 | AXC F XT ML 1000   | Left-alignable module with machine learning function               |

#### In preparation:

- |           |                    |  |
|-----------|--------------------|--|
| – 1160157 | AXC F XT SPLC 3000 | Left-alignable safety-related controller of performance class 3000 |
|-----------|--------------------|--|

**Note the following special characteristics:**

Table 4-2 Special characteristics of the left-alignable extension modules in combination with PLCnext Control devices

Characteristic	AXC F 2152	AXC F 3252
<b>Bus base module</b>		
– Connection of an AXC F XT ... to the PLCnext Control device	Replace the bus base module of the PLCnext Control device with the bus base module AXC BS L 2, Order No. 1064312.	Remove the cap on the left-hand side on the PLCnext Control bus base module.
– Connection of an AXC F XT ... to an AXC F XT ...	To align an additional AXC F XT ... module to the left on an AXC F XT ..., remove the cap on the bus base module of the preceding module.	
<b>Extendibility</b>		
– Direct on the PLCnext Control device (without AXC F XT EXP)	1 AXC F XT ... module	2 AXC F XT ... modules
– When using an AXC F XT EXP	4 AXC F XT ... modules	5 AXC F XT ... modules
	Sequence: Module 1: AXC F XT EXP Modules 2 ... 4: Any*	Sequence: Module 1: Any* Module 2: AXC F XT EXP Modules 3 ... 5: Any*
<b>*Restrictions</b>		
– General	All left-alignable modules may only be connected once.  You can only use the maximum number of four or five modules if further modules are available.	
– AXC F XT IB	If you use the module AXC F XT IB to the left, do not use an AXL F IL ADAPT in the Axioline F local bus, and vice versa.	
– AXC F XT ML 1000	Using the left-alignable AXC F XT ML 1000 machine learning module, you can only extend an AXC F 3152 controller.	

The LED EXT on the PLCnext Control device signals that left-alignable extension modules are being used. The displays have the following meaning:

Designation	Color	Meaning	State	Description
EXT	Red	Left alignment	On	Error at extension module Possible error causes: – Extension module is not supported. – Extension module is not mounted correctly or is defective. – Extension module was disconnected from power during operation or has been removed.
	Green		On	Extension module operating without errors.

**Please note for mounting and supplying with power:**



Always observe:

- The information in [Section “Mounting and removing modules” on page 53](#).
  - The information in [Section “Connecting the power supplies” on page 77](#).
  - The information in the documentation for the modules used, particularly if you are using left-alignable safety-related controllers.
- 
- Mount all the modules required before supplying power to the Axioline F station. Modules to which power is only supplied following the PLCnext Control boot process are not detected or may result in a malfunction.
  - Feed the supply voltage for the left-alignable modules and the PLCnext Control device used via a common power supply unit. This ensures that the devices have the same reference potential.
  - Fuse the power supply unit appropriately for the current consumption of the installation system.
  - Do not reverse the supply voltage connection. The GND potential of the PLCnext Control device and the left-aligned extension modules are connected together via the bus base. Reversing the polarity will lead to an immediate short circuit.
  - To ensure that the left-alignable extension modules are detected correctly, proceed as follows:
    - Switch on the power to the left-alignable extension modules before switching on the power to the PLCnext Control device  
or
    - Switch on the power to the left-alignable modules and to the PLCnext Control device simultaneously.

### 4.3 Bus coupler




Figure 4-2 Example: AXL F BK PB

With a network and an Axioline F local bus connection, the bus coupler is the head of an Axioline F station and represents the link between your network and the Axioline F station.

Table 4-3 Supported bus systems/networks

Bus system/network	Bus coupler (examples)
PROFINET	AXL F BK PN TPS
PROFIBUS DP	AXL F BK PB
EtherNet/IP™	AXL F BK EIP
Ethernet (Modbus/TCP)	AXL F BK ETH
Ethernet IEC 61850	AXL F BK SAS
Sercos	AXL F BK S3
EtherCAT®	AXL F BK EC

## 4.4 Input and output modules

### 4.4.1 Overview




Figure 4-3 Example: AXL F DI16/4 2F and AXL F AO8 XC 1F

Modules are available with various functions. These include, for example, the modules listed below. The text in brackets indicates the function according to the order designation.

- Digital input and output modules (DI, DO, DOR)
- Analog input and output modules (AI, AO)
- Digital input and output modules for the low voltage range (220 V DC, AC)
- Temperature measurement modules (RTD, UTH)
- Module for open and closed-loop control, and position detection (CNT, INC)
- Module for communication (RS UNI, IOL, ...)
- Function module (SSI1 AO1)
- Modules for use under extreme ambient conditions (XC versions, see [Section "Extreme conditions version \(XC\)" on page 28](#))
- Safety modules with safe digital inputs or outputs (PSDI, PSDO, see [Section "Safety modules with safe digital inputs or outputs" on page 29](#))
- Power module for the communications power  $U_{Bus}$  (see [Section "Power module for the communications power  \$U\_{Bus}\$ " on page 34](#))
- HART-compatible input and output modules for the connection of HART devices
- NAMUR-compatible input modules for the connection of NAMUR sensors
- ...

#### 4.4.2 Extreme conditions version (XC)

Thanks to special engineering measures and tests as well as partially coated PCBs, the XC modules can be used under extreme ambient conditions.

For use in the extended temperature range from  $-40^{\circ}\text{C}$  to  $+70^{\circ}\text{C}$ , please observe Section ["Tested successfully: use under extreme ambient conditions"](#) and the notes in the module-specific data sheet.

The function of an XC version is the same as the function of the corresponding standard version.

On the device rating plate for the XC version, the AXL F XC product range is stored in object 0006<sub>hex</sub>.

##### Tested successfully: use under extreme ambient conditions

XC modules have been tested successfully over 250 temperature change cycles according to IEC 61131-2 in the range from  $-40^{\circ}\text{C}$  to  $+70^{\circ}\text{C}$ .

The following conditions were observed:

- The Axioline F devices for all connecting cables were wired with a minimum conductor cross section of  $0.5\text{ mm}^2$
- The Axioline F station was mounted on a wall-mounted horizontal DIN rail
- Fans were used to ensure continuous movement of air in the control cabinet
- The Axioline F station was not exposed to vibration or shock
- The Axioline F station was operated with a maximum of  $24.5\text{ V}$  (ensured by using electronically regulated power supply units)




Figure 4-4 Temperature change cycle



Temperature in the control cabinet/ambient temperature



Cycle



Observe the information in the module-specific documentation.

Observe in particular restrictions regarding:

- Use in potentially explosive areas
- Use in safety technology
- Use in UL applications



#### 4.4.3 Safety modules with safe digital inputs or outputs

The safety modules are to be used in an Axioline F station at any point in a safe system (e.g., PROFIsafe).

Depending on the version, the modules either have safe digital inputs or outputs. They can be parameterized according to the specific application, and enable the integration of sensors and actuators in the safe system.



For more detailed information on these modules, refer to the module-specific user documentation.

#### 4.4.4 Intrinsically safe modules for the EX area (Ex i)

##### 4.4.4.1 Modules for different zones in potentially explosive areas

There is a large selection of I/O modules available for use in zone 2 potentially explosive areas that have received approval for this zone.

Furthermore, intrinsically safe Axioline F I/O modules are available. These can be installed in non-potentially explosive areas or potentially explosive areas of zone 2. These modules can be used to input or output signals present in Zone 1 or Zone 0.




Figure 4-5 Use of Axioline F modules in potentially explosive areas



Modules that have been approved for potentially explosive areas can be found on the Internet at [phoenixcontact.com/products](http://phoenixcontact.com/products). See Section “Approvals” on page 19.

Table 4-4 Use of Axioline F modules in potentially explosive areas

Axioline F modules	Installation in zone 2	Use of sensors/actuators in zone		
		2	1	0
Controllers, bus couplers, I/O modules <b>without</b> approval for zone 2	✗	✗	✗	✗
Controllers, bus couplers, I/O modules <b>with</b> approval for zone 2	✓	✓	✗	✗
Intrinsically safe I/O modules (AXL F EX IS ...) <b>with</b> approval for zone 2	✓	✓	✓	✓



#### **DANGER: Explosion hazard**

If at least one module in the Axioline F station does not have approval for zone 2, you may not install the entire station in this area.

In this case, install the station in a safe area.



Check if the modules you use are approved for zone 2 or have the UL approval for Class 1, Div. 2. Conformity is explained in the CE Declaration of Conformity. In addition, the modules are marked accordingly.

#### 4.4.4.2 Intrinsic safety

You can install intrinsically safe modules in any Axioline F station.

Install the intrinsically safe Axioline F modules at the end of the local bus behind the non-intrinsically safe modules.

Install the Axioline F/P partition plate for intrinsically safe AXL F/P IO EX PP modules (Order No.: 1100201) between the non-intrinsically safe and intrinsically safe section of the station.

Install the EX-IS modules so they are intrinsically safe. The EX-IS modules have intrinsically safe I/O terminal points. You can connect intrinsically safe sensors for use in zone 1, zone 0, or division 1 to these.

Figure 4-6 shows a typical installation for handling non-intrinsically safe and intrinsically safe Axioline F modules.




Figure 4-6 Handling non-intrinsically safe and intrinsically safe Axioline F modules

#### 4.4.4.3 Axioline F EX-IS modules

The following Axioline F I/O modules are available for creating an intrinsically safe Axioline F I/O system:

Table 4-5 Modules for creating an area with intrinsically safe Axioline F modules

Order No.	Type	Description	Note
<b>Intrinsically safe Axioline F modules</b>			
1052423	AXL F EX IS DI16 NAM XC 1F	Digital input module, Digital inputs: 16 (NAMUR), 8 V DC, Extreme conditions version	
1052432	AXL F EX IS AI8 HART XC 1F	Analog input module, Active analog inputs: 8 (HART), 4 mA ... 20 mA, Extreme conditions version	
1086901	AXL F EX IS DO4 SD 24-48 XC 1F	Digital output module, Digital outputs: 4, 24 V, 48 mA Extreme conditions version, Solenoid drive	
1086902	AXL F EX IS DO4 SD 21-60 XC 1F	Digital output module, Digital outputs: 4, 21 V, 60 mA Extreme conditions version, Solenoid drive	
1087081	AXL F EX IS AO4 HART XC 1F	Analog output module, Analog outputs: 4 (HART), 0 mA ... 20 mA, 4 mA ... 20 mA, Extreme conditions version	
1215393	AXL F EX IS AI8 P HART XC 1F	Analog input module, Passive analog inputs: 8 (HART), 0 mA ... 20 mA, 4 mA ... 20 mA, Extreme conditions version	
<b>Partition plate</b>			
1100201	AXL F/P IO EX PP	Axioline F/P partition plate for use as an isolator between non-intrinsically safe Axioline F I/O expansion and intrinsically safe Axioline F power supply	If you would like to use intrin- sically safe Axioline F I/O modules together with stan- dard Axioline F I/O modules in an Axioline F station, <b>al- ways</b> use the partition plate.



For more detailed information on these modules, refer to the module-specific data sheets.  
These are available on the Internet at [phoenixcontact.com/products](http://phoenixcontact.com/products).

#### 4.4.4.4 Examples for using I/O modules in the Ex area

##### 1. Axioline F station with EX-IS modules only

A simple intrinsically safe Axioline F Ex I/O station must consist of the following modules:

- 1 Axioline F bus coupler or AXC ... controller
- 2 Partition plate on the first intrinsically safe module behind the bus coupler or controller
- 3 AXL F EX IS ... I/O modules

##### 2. Axioline F station with standard modules and EX-IS modules

An intrinsically safe Axioline F Ex I/O station with standard I/O modules must consist of the following modules:

- 1 Axioline F bus coupler or AXC ... controller based on your application, with or without approval for potentially explosive areas of zone 2
- 2 Standard I/O modules based on your application, with or without approval for potentially explosive areas of zone 2
- 3 Partition plate on the first intrinsically safe module behind the standard I/O modules
- 4 AXL F EX IS ... I/O modules




Figure 4-7 Axioline F station with standard and EX-IS modules



Install the intrinsically safe I/O modules behind all standard I/O modules at the end of the Axioline F station.

#### 4.4.4.5 Power supply

The intrinsically safe modules are supplied with the same voltage as the standard modules. See [Section "Connecting the power supplies" on page 77](#).

## 4.5 Power module for the communications power $U_{\text{Bus}}$

If the maximum load of the controller or bus coupler for the Axioline F local bus supply (communications power  $U_{\text{Bus}}$ ) is reached, you can use the AXL F PWR 1H power module (item no. 2688297) to provide this voltage again.



### **DANGER: Explosion hazard**

In the area of the intrinsically safe I/O modules, the use of the power module for the communications power is not permitted.

## 4.6 Master

Masters are used to integrate lower-level systems in the Axioline F station.

### **Examples:**

- |                   |   |
|-------------------|---|
| AXL F MA DALI2 1H | The 2-channel DALI master enables communication with two DALI networks including their bus power supply.  |
| AXC F XT IB       | The INTERBUS master is designed to be directly mounted to the left of an Axioline F controller.<br>The INTERBUS master can be used to integrate INTERBUS devices in the Axioline F station. |

## 4.7 Backplane for Axioline Smart Elements




Figure 4-8 Example: AXL F BP SE6

The Axioline F backplanes are designed for use within an Axioline F station. The backplanes are designed to accept Axioline Smart Elements.

For information on the special features of the backplanes, refer to [Section “Axioline F backplane” on page 105](#).

## 5 Housing versions, design, and dimensions



If you use Axioline F backplanes (AXL F BP SE4 or AXL F BP SE6), observe [Section “Axioline F backplane” on page 105](#).

### 5.1 Housing versions

Various housing versions are available in the Axioline F portfolio; they are shown in [Figure 5-1](#).




Figure 5-1 Housing versions

Table 5-1 Housing versions

Housing type	Special feature	Example	Design	Dimensions
AXC 3	Class 3000 AXC controller	AXC 3050, AXC 3051	<a href="#">Figure 5-2 on page 37</a>	<a href="#">Figure 5-6 on page 41</a>
AXC F 2xxx	Class 2000 AXC F controller	AXC F 2152 AXC F XT SPLC 1000	<a href="#">Figure 5-3 on page 38</a>	<a href="#">Figure 5-7 on page 41</a>
BK	AXL F BK ... bus coupler Class 1000 AXC controller	AXL F BK PB, AXC 1050	<a href="#">Figure 5-4 on page 39</a>	<a href="#">Figure 5-8 on page 41</a>
2F	Wide housing, 2 terminal fields	AXL F DI16/4 2F AXL F DO16/3 2F	<a href="#">Figure 5-5 on page 40</a>	<a href="#">Figure 5-9 on page 42</a>
1F	Wide housing, 1 terminal field	AXL F AI8 XC 1F AXL F DI32/1 1F		<a href="#">Figure 5-10 on page 42</a>
1F (LVx)	Wide housing, 1 terminal field, low voltage			
1F (LV5)	5 connectors	AXL F DO4/3 AC 1F		<a href="#">Figure 5-16 on page 44</a>
1F (LV4)	4 connectors	AXL F DI8/2 110/220DC 1F AXL F DOR4/2 AC/220DC 1F		<a href="#">Figure 5-17 on page 44</a>
1F (PM)	Wide, high housing, 1 terminal field, power measurement	AXL F PM EF 1F		<a href="#">Figure 5-18 on page 45</a>
1F (HIGH)	Wide, high housing, 1 terminal field			
	5 connectors	AXL F DI16 NAM XC 1F		<a href="#">Figure 5-19 on page 45</a>
	3 connectors	AXL F AI8 HART XC 1F		
	2 connectors	AXL F EX IS AO4 HART XC 1F		
1F (HIGH EX)	Wide, high housing, 1 terminal field, intrinsically safe			
	5 connectors	AXL F EX IS DI16 NAM XC 1F		<a href="#">Figure 5-20 on page 45</a>
	3 connectors	AXL F EX IS AI8 HART XC 1F		
	2 connectors	AXL F EX IS AO4 HART XC 1F AXL F EX IS DO4 SD 24-48 XC 1F AXL F EX IS DO4 SD 21-60 XC 1F		
2H	Narrow housing, 2 terminal fields	AXL F DI16/1 DO16/1 2H AXL F DI32/1 2H		<a href="#">Figure 5-11 on page 42</a>
1H	Narrow housing, 1 terminal field			
1H	Long connectors	AXL F DI16/1 HS 1H AXL F UTH4 1H AXL F RS UNI 1H		<a href="#">Figure 5-12 on page 43</a>
1H (S)	Short connectors	AXL SSI 1/AO 1		<a href="#">Figure 5-13 on page 43</a>
1H (UNI)	Universal	AXL F PWR 1H AXC F XT IB 1H		<a href="#">Figure 5-14 on page 43</a>
		AXL F DO16 FLK 1H		<a href="#">Figure 5-15 on page 44</a>



## 5.2 Basic design of Axioline F modules

### 5.2.1 Class 3000 AXC controller




Figure 5-2 Design of an AXC 3050 controller

- 1 Bus base module
- 2 Electronics module
- 3 Ethernet interfaces
- 4 Function identification and FE tab:  
A 2.8 mm FE tab for optional functional ground connection is located under the function identification (see user manual for the controller)
- 5 Connector for connecting the communications power  $U_L$
- 6 USB interface
- 7 Slot for the parameterization memory
- 8 Mode selector switch
- 9 Diagnostic and status indicators (here: LEDs)
- 10 Programming interface
- 11 Reset button
- 12 Insert label

## 5.2.2 Class 2000 AXC F controller




Figure 5-3 Design of an AXC F 2152 controller

- 1 Bus base module
- 2 Electronics module
- 3 Reset button
- 4 SD card holder (the SD card is optional and not supplied as standard)
- 5 Diagnostic and status indicators
- 6 Ethernet interfaces
- 7 Supply connector (connector for connecting the communications power  $U_L$ )

### 5.2.3 Bus couplers and class 1000 AXC controllers




Figure 5-4 Design of a bus coupler

BK housing

Example: AXL F BK PN

- 1 Bus base module
- 2 Electronics module
- 3 Bus connection (here: Ethernet connections)
- 4 Function identification
- 5 Connector for connecting the communications power  $U_L$
- 6 Diagnostic and status indicators (here: LEDs)
- 7 Service interface
- 8 Reset button

Not shown:

- Rotary coding switch (not available for all bus couplers)
- Insert label



There are two FE springs on the bottom of the module for connecting the functional ground via the grounded DIN rail. These are not shown in [Figure 5-4](#). They are illustrated in [Figure 9-1 on page 91](#).

## 5.2.4 I/O module (electronics module)




Figure 5-5 Design of an I/O module (example: AXL F DI16/4 2F)

- 1 Electronics module
- 2 Connector for connecting the I/O supply voltage ( $U_I$ ,  $U_O$ ,  $U_{IO}$  or  $U_A$ )
- 3 Function identification
- 4 Connectors for connecting the I/O
- 5 Diagnostic and status indicators
- 6 Locking latches of the I/O connectors
- 7 Base latch for latching to the DIN rail (2 x)
- 8 Device connector for connecting to the local bus via the bus base module (at the bottom, not illustrated)



There is at least one FE spring on the bottom of the module for connecting the functional ground via the grounded DIN rail. This is not shown in [Figure 5-5](#). It is illustrated in [Figure 9-1 on page 91](#).

### 5.3 Axioline F module dimensions

All dimensions are in mm.

#### 5.3.1 AXC controller and bus coupler




Figure 5-6 Nominal dimensions of a class 3000 AXC controller housing (type AXC 3, e.g., AXC 3050, AXC 3051)




Figure 5-7 Nominal dimensions of a class 2000 AXC controller housing (type AXC F, e.g., AXC F 2152)




Figure 5-8 Nominal dimensions of a controller/bus coupler housing with separate bus base (type BK, e.g., AXL F BK PB, AXC 1050)

### 5.3.2 I/O modules for the 24 V area




Figure 5-9 Nominal dimensions of the F housing with two terminal fields (type 2F, e.g., AXL F DI16/4 2F, AXL F DO16/3 2F)




Figure 5-10 Nominal dimensions of the F housing with one terminal field (type 1F, e.g., AXL F AI8 XC 2H, AXL F DI32/1 2H)




Figure 5-11 Nominal dimensions of the H housing with two terminal fields (type 2H, e.g., AXL F DI16/1 DO16/1 2H)




Figure 5-12 Nominal dimensions of the H housing with one terminal field (type 1H, e.g., AXL F DI16/1 HS 1H, AXL F UTH4 1H, AXL F RS UNI 1H)




Figure 5-13 Nominal dimensions of the H housing with one terminal field and short connectors (type 1H (S), e.g., AXL F SSI1 AO1 1H)




Figure 5-14 Nominal dimensions of the H housing with one terminal field and short connectors (type 1H (UNI), e.g., AXL F PWR 1H, AXC F XT IB 1H)




Figure 5-15 Nominal dimensions of the H housing with one terminal field and short connectors (type 1H (UNI), AXL F DO16 FLK 1H)

### 5.3.3 I/O modules for the low voltage area




Figure 5-16 Nominal dimensions of the F housing for the low voltage area with one terminal field and five connectors (type 1F-LV5, e.g., AXL F DO4/3 AC 1F)




Figure 5-17 Nominal dimensions of the F housing for the low voltage area with one terminal field and four connectors (type 1F-LV4, e.g., AXL F DI8/2 110/220DC 1F, AXL F DOR4/2 AC/220DC 1F)



### 5.3.4 Power measurement module




Figure 5-18 Nominal dimensions of the F housing for power measurement with one terminal field (type 1F-PM, AXL F PM EF 1F)

### 5.3.5 HART/NAMUR




Figure 5-19 Nominal dimensions of the F housing for HART/NAMUR modules with one terminal field (type 1F-HIGH, e.g., AXL F DI16 NAM XC 1F)

### 5.3.6 Intrinsically safe modules




Figure 5-20 Nominal dimensions of the F housing for intrinsically safe modules with one terminal field (type 1F-HIGH EX, e.g., AXL F EX IS DI16 NAM XC 1F)

## 5.4 Bus base modules

Bus base modules connect the modules to each other.

Bus base modules carry the communications power and the bus signals from the bus coupler or the controller through the Axioline F station (local bus).

A bus base module is supplied as standard with each controller, bus coupler and Axioline F module.



**NOTE: Malfunction**

Insert the bus base module belonging to the relevant module.

Bus base modules with different overall widths and functions are available (e.g., red bus base module for the power module).

### Versions




Figure 5-21 Bus base modules

Table 5-2 Bus base modules

No.	Type	Order No.	For use with
1	AXC BS	2701582	AXC 3xxx controller
2	AXL BS BK	2701422	Bus coupler in BK housing, AXC 1050 controller
3	AXL F BS F	2688129	F housing
4	AXL F BS H	2700992	H housing
5	AXL F BS H PWR	2702051	H housing, power module
...	Others		See device-specific documentation

### Basic design





Figure 5-22 Design of a bus base module

- 1 Bus base module
- 2 Connection to the bus coupler or the previous bus base module (male connector)
- 3 Connection of the local bus to an I/O electronics module (female connector)
- 4 Connection for the following bus base module (female connector)

## PHOENIX CONTACT 47 / 178

### 5.5.1 Versions and dimensions

Various Axioline F connector versions are available.



No.	Color	Use	Examples of use
<b>24 V area</b>			
1	Black RAL 9005	Feeding the supply voltages	AXL F DI..., AXL F DO... AXL F AI..., AXL F AO... AXL F CNT2 INC2 1F
2			AXC 1xxx, AXC 3xxx AXL F BK ... AXL F SSI1 AO1 1H
3	Traffic gray A RAL 7042	I/O connection (protective extra-low voltage)	AXL F DI..., AXL F DO... AXL F AI..., AXL F AO... AXL F CNT2 INC2 1F
	Zinc yellow RAL 1018	I/O connection (safety modules, protective extra-low voltage)	AXL F PSDI8/4 1F AXL F PSDO8/3 1F
	Sky blue RAL 5015	I/O connection (intrinsically safe modules)	AXL F EX IS DI16 NAM XC 1F AXL F EX IS AI8 HART XC 1F
4	Traffic gray A RAL 7042	I/O connection (protective extra-low voltage)	AXL F SSI1 AO1 1H
<b>230 V area</b>			
5	Black RAL 9005	Feeding the supply voltages	AXL F DO4/3 AC 1F
6	Traffic gray A RAL 7042	I/O connection (low voltage)	AXL F DO4/3 AC 1F AXL F DOR4/2 AC/220 DC 1F

## 5.5.2 Basic design




Figure 5-24 Basic design of an Axioline F connector

- 1 Local diagnostic and status indicators
- 2 Terminal point
- 3 Touch connection
- 4 Terminal point marking
- 5 Spring lever  
The color of the spring lever corresponds to the function (see [Section "Color and marking" on page 49](#))
- 6 Locking latch
- 7 Space for connector marking (zack marker strip ZBF 10/5,8 AXL or ZBF 5)

## 5.6 Color and marking

### Housing

The following housing colors are currently used for the electronics modules:

Table 5-4 Electronics modules housing colors

Color	Similar RAL colors	Use
Traffic gray A	RAL 7042	Standard modules Intrinsically safe modules
Zinc yellow	RAL 1018	Safety modules

### Connectors

Connectors are currently available in the following colors::

Tabelle 5-5 Connector colors

Color	Similar RAL colors	Use
Black	RAL 9005	Bottom parts of all connectors connectors for voltage supply
Traffic gray A	RAL 7042	Connectors for connecting the peripherals for standard I/O modules
Zinc yellow	RAL 1018	Safety modules
Sky blue	RAL 5015	Intrinsically safe modules

### Function identification

The module functions are color coded (1 in [Figure 5-25](#)).




Figure 5-25 Color coding of the module function

The following colors indicate the function:

Table 5-6 Color coding of the module function

Color	Similar RAL color	Function of the module
Light blue	RAL 5012	Digital input
Flame red	RAL 3000	Digital output
Signal violet	RAL 4008	Digital input and output
Pale green	RAL 6021	Analog input, temperature measurement
Zinc yellow	RAL 1018	Analog output
Pastel orange	RAL 2003	Function: open and closed-loop control, communication, position detection
Pure white	RAL 9010	Bus coupler, controller, boost

<b>Connections</b>	Apart from the Axioline F connectors, all connections are consecutively numbered, e.g., X1, X2 for Ethernet connections.
<b>Operating elements</b>	Operating elements are marked according to their function, e.g., rotary coding switches with S1 and S2 including the switch positions.
<b>Indication elements</b>	Diagnostic and status indicators are marked with the function, e.g., D, E, UI, 00, 01, ... (1 in <a href="#">Figure 5-26</a> ).
<b>Terminal points</b>	The terminal points are consecutively numbered, e.g., a1, b1, 00, 01, ... (2 in <a href="#">Figure 5-26</a> ). The associated colored spring lever indicates the function (signal, potential) (3 in <a href="#">Figure 5-26</a> ).




Figure 5-26 Marking of terminal points and LEDs on the connectors

Table 5-7 Color coding of the terminal point function

Color	Function of the terminal points	
	Extra-low voltage	Low voltage
Orange	Signal	Signal
Red	24 V DC	230 V AC, 220 V DC, relay main contact
Blue	GND	N (neutral conductor)
Green	FE (functional ground)	PE (protective conductor)



For the marking and function identification of a module, refer to the module-specific data sheet.

**Additional marking options**

In addition to the standard marking options detailed above, you can also custom-mark the module using a zack marker strip or an insert label.




Figure 5-27 Individual marking options

- 1 Space for connector marking (zack marker strip ZBF 10/5,8 AXL or ZBF 5)
- 2 Space for module marking (zack marker strip ZB 20,3 AXL or ZB 10)
- 3 Space for slot marking (zack marker strip ZBF 10/5,8 AXL or ZBF 5)
- 4 Insert label (EMT (35X28)R, EMT (35X46)R, EMT (35X18,7)R)



See [Section “Ordering data” on page 138](#).

**Slot and connector marking**

Each slot on the module and the associated connector can be marked individually to ensure clear assignment between the slot and the connector (1 and 3 in [Figure 5-27](#)).

## 6 Transport, storage, and unpacking

### 6.1 Transport



**NOTE: Electrostatic discharge!**

Electrostatic discharge can damage or destroy components. When handling the device, observe the necessary safety precautions against electrostatic discharge (ESD) in accordance with EN 61340-5-1 and IEC 61340-5-1.

Axioline F modules are delivered packaged in a folded box.

- Please observe the notes on the packaging.

**Suitable transport packaging**

- Only transport the device in its original packaging or in packaging suitable for transport.

**Technical data and environmental conditions**

- During transport, observe the specifications regarding humidity and temperature range. See [Section “Technical data” on page 132](#).

### 6.2 Storage

**Suitable storage location**

The storage location must meet the following requirements:

- Dry
- Protected from external influences
- Protected from harmful environmental influences such as UV light

**Technical data and environmental conditions**

- During storage, observe the specifications regarding temperature range, air pressure and humidity. See [Section “Technical data” on page 132](#).

### 6.3 Unpacking

**Observing the packing slip**

- Read the complete packing slip carefully before unpacking the device.
- Retain the packing slip.



If a packing slip is not provided with the device, download the packing slip from the Internet. It can be found on the product details page for the device at [phoenixcontact.com/products](https://phoenixcontact.com/products).  
If no packing slip is available, refer to the data sheet or user manual for the product or system used.

**Checking the delivery**

- Check delivery for damage and completeness.
- Submit claims for any transport damage immediately.

**Scope of delivery of standard modules**

- Axioline F module with inserted connectors
- Associated bus base module

**Scope of supply of backplane**

- Axioline F backplane



## 7 Mounting and removing modules



If you use Axioline F backplanes (AXL F BP SE...), observe [Section “Axioline F backplane” on page 105](#).

### 7.1 Safety notes for mounting and removal

#### 7.1.1 General safety notes



**NOTE: Electrostatic discharge**

The modules contain components that can be damaged or destroyed by electrostatic discharge. When handling the modules, observe the necessary safety precautions against electrostatic discharge (ESD) according to EN 61340-5-1 and IEC 61340-5-1.



**NOTE: Damage to electronics due to inadequate external protection**

**No safe fuse tripping in the event of an error**

Provide external fuses for the 24 V area of each module. If you use a fuse, the power supply unit must be capable of supplying four times the nominal current of the fuse. This ensures that the fuse trips reliably in the event of an error.



**NOTE: Disregarding this warning may result in damage of the contacts or malfunction**

Before working on a module, disconnect the module from the I/O devices and the power supply.

**For a bus coupler or controller, this means:**

- Disconnect the communications power supply  $U_L$  at the bus coupler or controller.

**For an I/O module, this means:**

- Disconnect the connected I/O devices from the power.
- Switch off the I/O supply voltage at the relevant module.

The communications power that is supplied at the bus coupler or controller is still available.

**For an Axioline F backplane, this means:**

- Disconnect the connected I/O devices of all inserted Axioline Smart Elements from the power.
- Switch off the I/O supply voltage  $U_P$ .
- Switch off the communications power supply  $U_L$  at the bus coupler or controller.

**For an Axioline Smart Element, this means:**

- Disconnect the connected I/O devices of the Axioline Smart Element from the power.
- Switch off the I/O supply voltage  $U_P$  at the backplane in which the Axioline Smart Element is located.
- Disconnect the communications power supply  $U_L$  at the bus coupler or controller.



**NOTE: Damage to the contacts when tilting**

Tilting the modules can damage the contacts.

- **Place the modules onto the DIN rail vertically.**
- **Remove the modules from the DIN rail vertically.**




Figure 7-1 Placing and removing the module **vertically**



When using modules in the low voltage area, please also observe Section [“Additional safety notes for the low voltage area” on page 55](#).

Additionally observe the information in the module-specific data sheets.

## 7.1.2 Additional safety notes for the low voltage area

### Installing the system

Install the system according to the requirements of IEC 61010-2-201, EN 61010-2-201.

Only qualified personnel may work on Axioline F modules in the low voltage area.

In terms of this user manual, qualified personnel are persons who, because of their education, experience and instruction, and their knowledge of relevant standards, regulations, accident prevention, and service conditions, have been authorized to carry out any required operations, and who are able to recognize and avoid any possible dangers.



#### **WARNING: Dangerous contact voltage**

Please note that there are dangerous contact voltages when working on circuits that do not meet protective extra-low voltage requirements.

- The Axioline F modules for the low voltage area may only be mounted and removed when the power supply is disconnected.
- When working on the modules and wiring, always switch off the supply voltage and ensure it cannot be switched on again.
- The Axioline F modules for the low voltage area must only be operated in a closed control cabinet.

Failure to observe these instructions can lead to damage to health or even life-threatening injury.



#### **WARNING: Dangerous contact voltage in the event of ground faults**

- The Axioline F modules for the low voltage area must only be operated in grounded networks.



Additionally observe the information in the module-specific data sheets.

## 7.2 Basic information about mounting

### Mounting location

The Axioline F modules meet the requirements of IP20 degree of protection. They can therefore be used in closed control cabinets or in control boxes (junction boxes) with IP54 degree of protection according to EN 60529 or higher.

The compact design means that the Axioline F modules can be installed in standard junction boxes. Please observe the mounting distances when selecting the control cabinet, control box or function box, see [Section "Mounting distances" on page 67](#).



#### NOTE: Fire hazard

Axioline F modules must be installed in the final protective housing, which provides sufficient resistance to mechanical strain and protection against the spreading of fire in accordance with the standards UL/IEC/EN 61010-1 and UL/IEC/EN 61010-2-201.

#### NOTE: Unauthorized physical access

There is a danger tampering with the modules through unauthorized physical access.

- Protect the modules against unauthorized physical access. Use a lockable control cabinet, for example.

### IP20 degree of protection

Insert the connectors onto the electronics modules in order to achieve IP20 degree of protection.

### DIN rail

All Axioline F modules are mounted on a grounded 35 mm standard DIN rails. The preferred height of the DIN rail is 7.5 mm (corresponds to TH 35-7.5 according to EN 60715).

The recommended DIN rails from Phoenix Contact or recommended mounting straps from Lütze can be found in [Section "Ordering data" on page 138](#).

#### NOTE: Damage to the contacts when tilting the modules

Using a DIN rail with an installed height greater than 7.5 mm:

If the height of the DIN rail exceeds 7.5 mm, this can lead to tilting of the modules when mounting or removing the modules. This may damage the contacts.

- When using these DIN rails, make sure that the modules are perfectly perpendicular to the DIN rail when mounting or removing them.



#### NOTE: Damage to electronics from the fixing elements

##### Danger of malfunction

If the fixing elements (screw, rivet, etc.) are too high, the bus base modules or the Axioline F backplane are not correctly snapped onto the DIN rail.

**For fixing the DIN rail, only use elements with a maximum installation height of 3 mm.**

The distance between DIN rail fasteners must not exceed 200 mm. This distance is necessary for the stability of the rail when mounting and removing modules.




Figure 7-2 Fixing the DIN rail (in mm)

Mount the modules **vertically** on the DIN rail. As the module does not need to be tilted it provides easy installation and removal, even in confined spaces.

### Mounting position

Wall mounting on a horizontal DIN rail on the wall is the preferred mounting position (Figure 7-3, A). This mounting position provides optimum air flow for the modules.

Other mounting positions are possible, however, temperature derating may be required. Observe the ambient temperatures provided in the module-specific documentation.




Figure 7-3 Mounting positions for an Axioline F station



The module-specific documentation specifies whether any other mounting position than the preferred mounting position is not permitted.

For Axioline F backplanes, only wall mounting on a horizontal or vertical DIN rail is permitted (as shown in Figure 7-3).

**End brackets**

Mount end brackets on both sides of the Axioline F station (see [Figure 7-3](#)). The end brackets ensure that the Axioline F station is correctly mounted on the DIN rail. They secure the station on both sides and keep it from moving from side to side on the DIN rail.

Always attach the left end bracket of the station when beginning to mount the station. This ensures the following:

- It prevents the station from slipping on the DIN rail.
- The space for the end bracket is secured.
- There is a counter pressure for the insertion force that occurs when the bus base modules are installed next to the bus coupler.

Table 7-1 Recommended end brackets

Mounting position	Ambient conditions	End bracket
Horizontal, <a href="#">Figure 7-3, A</a>	Normal	CLIPFIX 35, CLIPFIX 35-5
	High shock and vibration load	E/AL-NS 35
Other, <a href="#">Figure 7-3, B</a>	Normal	E/AL-NS 35
	High shock and vibration load	



If you use Axioline F backplanes in the station, use the CLIPFIX 35 or E/AL-NS 35 end brackets. See also [Section “Ordering data” on page 138](#).

**Tool**

No tools are required for mounting the modules.

A standard tool, e.g., a bladed screwdriver with a blade width of 2.5 mm, is necessary for removing the electronics modules and using the spring levers.

**Order of the modules**

The modules on the DIN rail can be installed in any order behind the bus coupler. To ensure functionality, mount the modules side by side, without a gap.

If you are using modules with shield connection, installing them next to each other is recommended in order to make optimum use of the busbar for shield connection.

**Maximum number of modules**

The maximum number of Axioline F modules within a station is 63.

The actual number of modules within an Axioline F station may be limited by the following factors:

- Supplied logic current
- Current consumption of the connected modules
- System limits of the bus coupler

Use the Project+ configuration software to calculate the individual process or parameter data and the corresponding number of devices that can be connected.

It can be found at: [phoenixcontact.com/product/2688394](https://phoenixcontact.com/product/2688394).

**Power supply/  
current consumption**

The bus coupler, controller or the power module for the communications power provide the power supply for the local bus. In the module-specific documentation, this current value is specified as "Power supply at  $U_{BUS}$ ".

The total current consumption of all Axioline F modules arranged in the station must not exceed this maximum current. The logic current consumption values are specified for each module in the module-specific data sheet as "Current consumption from  $U_{BUS}$ ".

The following information is stored in the device description files (e.g., gsdml file):

- Current supplied by the bus coupler, controller or power module
- Maximum current consumption of the modules that can be connected

You can use these maximum currents in the engineering tool for configuration in order to prevent an overload of the communications power.



**NOTE: Electronics may be damaged when overloaded**

Observe the current consumption of each device when configuring an Axioline F station. It is specified in every module-specific data sheet and may vary. As such, the permissible number of devices that can be connected therefore depends on the station structure.

Install a power module for the communications power if the maximum current consumption at  $U_{BUS}$  is reached. Create another station as an alternative.

**System limits of the bus  
coupler**

Use the Project+ configuration software to calculate the individual process or parameter data and the corresponding number of devices that can be connected.

It can be found at: [phoenixcontact.com/product/2688394](http://phoenixcontact.com/product/2688394).

If the system limits of the bus coupler or controller are reached, create a new station.

**Example structure of an  
Axioline F station**

See [Section "Example of an Axioline F station" on page 13](#).

### 7.3 Left alignment

The following sections describe mounting and removal of standard modules. Observe the information in the packing slips for modules that are installed to the left of the controller. They are provided with the products upon delivery and/or are available on the Internet in the download area of the item at [phoenixcontact.com/products](http://phoenixcontact.com/products).



Observe [Section “Controllers and left-alignable modules AXC F XT ...” on page 23](#) and the documentation for the left-alignable modules used.

### 7.4 Mounting the modules



Please refer to Section [“Safety notes for mounting and removal” on page 53](#).

No tools are required for mounting the Axioline F modules.

- First mount the end bracket on the grounded DIN rail.



### 7.4.1 Bus base modules, controllers, and bus couplers

#### Mounting the bus base modules



- First install the bus base module for the controller or bus coupler onto the DIN rail.
- Place all other bus base modules required for the station on the DIN rail ([Figure 7-4, A](#)).

#### NOTE: Malfunction

Insert the bus base module belonging to the relevant module.  
Bus base modules with different overall widths and functions are available.

- Push each subsequent bus base module into the connection of the previous bus base module ([Figure 7-4, B](#)).




Figure 7-4 Connecting bus base modules to each other



It is not possible to snap another bus base module to the previous bus base module if there is already an electronics module on it. In this case, first remove the last electronics module before snapping on more bus base modules.

#### Snapping on the controller or bus coupler

- Place the controller or bus coupler **vertically** on the first bus base module and the DIN rail until it snaps into place with a click.  
Make sure that the device connector for the bus base connection is positioned above the corresponding female connector on the bus base module.




Figure 7-5 Snapping on the bus coupler

#### Connecting the network

- Connect the network according to the specifications in the module-specific documentation.

### 7.4.2 I/O modules

- Place the necessary I/O modules **vertically** on the corresponding bus base modules and DIN rail until they snap into place with a click.  
Pay attention to the correct position.  
Make sure that the device connectors for the bus base connection are positioned above the corresponding female connectors on the bus base module.




Figure 7-6 Inserting I/O modules

If you are using analog modules, mount the necessary shield connection elements.



For connecting the shield, Phoenix Contact recommends the AXL SHIELD SET Axioline F shield connection set or the shield connection clamp products from the “Control cabinet accessories” product range.

When using the AXL SHIELD SET, mount the elements in the following order:

1. Bus base module
2. Shield bus holder
3. Electronics module

See [Section “Connecting the shield using the Axioline F shield connection set”](#) on page 93.

## 7.5 Removing modules



Please refer to Section [“Safety notes for mounting and removal” on page 53](#).

A standard tool, e.g., a bladed screwdriver with a blade width of 2.5 mm is necessary for removing modules.

### 7.5.1 Removing connectors or cables

#### Removing the network connector

- Remove the network connector, if present, according to the specifications in the module-specific documentation.

#### Supply connector, I/O connector

- Prior to module removal, also remove the connectors or cables, if present, from the module.
  - If no cables are inserted, the connectors do not need to be removed.
  - If cables are inserted, either remove the connectors from the module or the cables from the connectors.  
The cables should only be removed from the connector if you wish to change the wiring or no longer wish to use the connector.

#### Removing cables

See [Section “Removing cables from the terminal point” on page 76](#).

#### Removing the Axioline F connectors

See [Section “Removing or inserting a connector” on page 66](#).

### 7.5.2 Controller, bus coupler, and I/O modules

The controller, bus coupler and each I/O module can be removed individually from the station.

- Insert a suitable tool (e.g., bladed screwdriver) in the upper **and** lower snap-in mechanism (base latches) of the module one after the other and unlock it (Figure 7-7, Figure 7-8, A). The base latches are locked in place in the open position.
- Remove the electronics module **vertically** to the DIN rail (Figure 7-7, Figure 7-8, B). The base latches return to the idle position again.




Figure 7-7

Removing the bus coupler




Figure 7-8

Removing an I/O module

The bus base module remains on the DIN rail.

#### Bus base module

Please proceed as follows if, after having removed modules, you want to remove bus base modules from the DIN rail as well:

- If a module is located on the neighboring bus base module to the left, remove it.

If the bus base module is in the end position:

- Remove the bus base module from the connection of the previous bus base module by sliding it approximately 5 mm to the right (A).
- Insert a suitable tool (e.g., bladed screwdriver) into the latches on one side (B, B1, B2) one after the other.
- Swivel the bus base module upward and remove it (C).




Figure 7-9

Removing the bus base module

If the bus base module to be removed is inside the station:

- If possible, push the following bus base modules and any fitted modules approximately 15 mm to the right.  
In doing so, disconnect the bus base module you want to remove from the connection of the following bus base module.
- If it is not possible to slide the following bus base modules and modules, remove the modules. Starting at the end of the station, remove the bus base modules.
- Disconnect the bus base module to be removed from the connection of the previous bus base module by sliding it about 5 mm to the right (A).
- Insert a suitable tool (e.g., bladed screwdriver) into the latches on one side (B, B1, B2) one after the other.
- Swivel the bus base module upward and remove it (C).
- Push the rest of the station back to the left until the bus base modules touch each other again.

## 7.6 Removing or inserting a connector

### 7.6.1 Removing a connector

- Release the locking latch (A). Tilt the connector slightly upward (B). Remove the connector from the module (C).




Figure 7-10 Removing the connector

### 7.6.2 Inserting a connector

- Insert the connector vertically into its position. Press firmly on the connector. Make sure that it engages with a click.




Figure 7-11 Snapping on the connector

## 7.7 Replacing a module

- To replace a module, proceed as described in Sections [“Removing modules” on page 63](#) and [“Mounting the modules” on page 60](#).
- Once replaced, restore all the necessary connections.

**When replacing a controller:**

Observe any notes for replacement in the module-specific documentation.

## 7.8 Mounting distances

The space required for cable routing depends on the number of cables to be installed. Leave this space free at the bottom and/or at the top.

Refer to [Figure 7-12](#) to [Figure 7-15](#) for the recommended clearances between the upper and lower cable ducts and the cable routing to the modules.



In addition to the specified dimensions, provide adequate space for mounting and removal of the connectors and cables.

### 7.8.1 AXC 305x and AXC F x152 controllers




Figure 7-12 Mounting distances: AXC 305x, AXC F 2152 controller (dimensions rounded)

If you maintain the clearance recommended in [Figure 7-12](#), the ambient conditions specified in the device-specific user manuals apply.

If you deviate from the clearances recommended in [Figure 7-12](#), ensure that the maximum ambient temperature does not exceed the product specifications. Never cover the ventilation slots on the upper and lower sides of the controller. The following options are available for complying with the ambient temperature specification:

1. Applied CPU temperature monitoring. To do this, use the system variables provided.
2. Depending on the ambient temperature, take one of the following measures:
  - Provide for air circulation within the control cabinet
  - Provide for control cabinet ventilation
  - Provide for control cabinet air conditioning

Ensure that the clearance is never less than 35 mm in accordance with the I/O specifications.

7.8.2 AXC F x152 controllers and bus couplers




Figure 7-13 Mounting distances: AXC F x152 controllers and bus couplers (dimensions rounded)

7.8.3 I/O modules




Figure 7-14 Mounting distances: I/O modules, housings 1F, 2F, 1H, 2H (dimensions rounded)

Table 7-2 I/O module mounting distances

Housing type	Housing height	Distance between DIN rail and housing cover	Note
1F, 2F, 1H, 2H	54 mm	75 mm	See <a href="#">Figure 7-14</a>
1F (PM)	65.5 mm	87 mm	
1F (HIGH, HIGH EX)	77.1 mm	98 mm	



## 7.8.4 Axioline F backplane




Figure 7-15 Mounting distances: AXL F BP SE ... with inserted Axioline Smart Elements



If the distances are smaller, the minimum bending radius of the cables, easy handling during installation, and a clear structure cannot be assured.

## 8 Connecting or removing cables



If you use Axioline F backplanes (AXL F BP SE4 or AXL F BP SE6), observe [Section “Axioline F backplane” on page 105](#).

### 8.1 Connections and cables in the Axioline F system

**NOTE: Damage to contacts**

There is risk of damage to the terminal points if they are mechanically overstrained.

- Implement strain relief for the connected cables.

All electrical connections are pluggable.

The network cables on the controller or bus coupler are connected via the D-SUB or RJ45 connectors depending on the network.

The cables for the I/O devices and supply voltages are connected using Axioline F connectors.

Each terminal point is designed for a maximum current of 8 A. This applies to the periphery of the I/O modules (I/O connectors) as well as to the supply of the logic, sensors, and actuators (power connectors).

**Applications with UL approval:**

- Only use copper conductors.
- The current can be reduced. Observe any specifications in the module-specific packing slip, the data sheet and the rating on the modules.

When using Axioline F modules you can use shielded and unshielded, solid and stranded cables, with or without ferrules.

Please observe the following when wiring:

- Make sure to install the conductor in the middle of the wiring space, especially with small cross sections.



If you are using ferrules, comply with the specifications described in [Section “Conductor cross sections and stripping and insertion lengths” on page 71](#).

Make sure that the ferrules are crimped correctly.

## 8.2 Conductor cross sections and stripping and insertion lengths



If you use Axioline F backplanes (AXL F BP SE4 or AXL F BP SE6), observe [Section “Axioline F backplane” on page 105](#).



For electrical and/or thermal reasons, it may not be possible to use the minimum conductor cross sections specified here for certain modules.

Therefore, always observe the information in the module-specific documentation.

### Conductor cross sections

Table 8-1 Permissible conductor cross sections for Push-in connection technology (tool-free conductor insertion)

Conductor	Cross section
Solid	0.5 mm <sup>2</sup> .... 1.5 mm <sup>2</sup>
Stranded with ferrule without insulating collar (A ...), according to DIN 46228-1	
– sleeve length 10 mm	0.25 mm <sup>2</sup> .... 1.5 mm <sup>2</sup>
Stranded with ferrule with insulating collar (AI ...), according to DIN 46228-4	
– sleeve length 8 mm	0.25 mm <sup>2</sup> .... 1.0 mm <sup>2</sup>
– sleeve length 10 mm	0.25 mm <sup>2</sup> .... 1.5 mm <sup>2</sup>



Stranded cables without ferrules are only suitable for Push-in connection technology **when using the spring lever**.

Table 8-2 Permissible conductor cross sections **when using the spring lever** for inserting the conductor

Conductor	Cross section
Solid	0.2 mm <sup>2</sup> .... 1.5 mm <sup>2</sup>
Stranded without ferrule	0.2 mm <sup>2</sup> .... 1.5 mm <sup>2</sup>
Stranded with ferrule without insulating collar (A ...)	0.25 mm <sup>2</sup> .... 1.5 mm <sup>2</sup>
Stranded with ferrule with insulating collar (AI ...)	0.25 mm <sup>2</sup> .... 1.5 mm <sup>2</sup>

Table 8-3 Permitted AWG conductor cross sections

Conductor	Cross section
AWG	24 ... 16

## Stripping and insertion lengths



### **NOTE: Malfunction when the conductor is not securely fixed**

To ensure secure fixing and correct function:

Make sure that the stripping length of a conductor without ferrule or the insertion length of a conductor with ferrule corresponds to the specifications.

For crimping, we recommend pliers for trapezoidal crimp: CRIMPFOX 6, CRIMPFOX DUO 10 or CRIMPFOX 10T-F, see [Section “Ordering data for accessories” on page 138](#). According to the current state, these crimping pliers meet the general conditions regarding the Axioline F wiring space (according to internal cylindrical gauge DIN EN 60947-1 (DIN VDE 0660-100)-A1).

Conductor without ferrule: stripping length 8 mm

Conductor with ferrule: insertion length 8 mm or 10 mm

Ferrules: see [Section “Ordering data” on page 138](#).

## TWIN ferrules



### **NOTE: Malfunction when using wrong ferrule**

TWIN ferrules are not permitted in the Axioline F system.

## **CABLE- FLK14/AXIO/OE/0,14/...**

Deviating from the above specified conductor cross-sections, the use of assembled **CABLE-FLK14/AXIO/OE/0,14/...** round cables is permitted for digital modules with 1-conductor connection technology. The conductors of these cables are fitted with ferrules and have a conductor cross-section of 0.14 mm<sup>2</sup>, AWG 26.

If round cables are approved for a module, these are listed in the module ordering data.

### 8.3 Terminal point, associated spring lever, and associated touch connection

When using the screwdriver, pay attention to the position of the spring lever to the assigned terminal point.

When testing the signal with a measuring probe, pay attention to the position of the touch connection to the assigned terminal point.




Figure 8-1 Terminal point with associated spring lever, and associated touch connection

- |   |                             |   |
|---|-----------------------------|---|
| A | Cable outlet at the bottom: | Spring lever and touch connection <b>above</b> the terminal point     |
| B | Cable outlet at the top:    | Spring lever and touch connection <b>below</b> the terminal point (B) |
| 1 | Terminal point              |   |
| 2 | Spring lever                |   |
| 3 | Touch connection            |   |

## 8.4 Connecting unshielded cables

Wire the connectors according to your application.



For the terminal point assignment, refer to the corresponding module-specific documentation.

When wiring, proceed as follows:

- Strip 8 mm off the cable.

### Without tools (Push-in)

Suitable for:

- Rigid cables with a conductor cross-section of 0.5 mm<sup>2</sup> and larger
- Flexible cables with ferrules with a conductor cross-section of 0.25 mm<sup>2</sup> and larger
- Insert the cable into the terminal point. It is clamped into place automatically.




Figure 8-2 Connecting a solid unshielded cable

### With tools

Suitable for:

- Stranded cables
- Solid cables
- Stranded cables with ferrules

•

Open the spring by pressing the screwdriver onto the spring lever (Figure 8-3, A).

Use, for example, a bladed screwdriver with a blade width of 2.5 mm.

Phoenix Contact recommends the SZS 0,4x2,5 screwdriver (see [Section "Ordering data" on page 138](#)).

- Insert the cable in the terminal point (B).
- Remove the screwdriver to secure the cable.




Figure 8-3 Connecting a stranded cable

**Inserting the connector**

- Insert the connector vertically into its position. Press firmly on the connector. Make sure that the locking latch snaps into place.




Figure 8-4 Inserting the connector

## 8.5 Connecting shielded cables



Please also observe the information in [Section “Shielding concept” on page 92](#) for shielding.

Connect the shield before the module.

When connecting the cables, proceed as follows:

**Stripping the cables, connecting the shield**

- Strip approximately 20 mm off the outer sheath of the cable at the required distance from the end of the cable (a in [Figure 8-5](#)).  
The necessary distance a depends on the distance to the busbar.
- Strip 8 mm off the wires.




Figure 8-5 Connecting the shielded cable

- If present, remove the protective foil.
- Lay the cable with the braided shield under a shield connection clamp. Secure the shield clamp (using a screw or spring-cage connection). Malfunctions will then be led to the support brackets via a busbar. The support brackets are connected to the grounded DIN rail.  
Ordering data can be found in [Section “Ordering data” on page 138](#).



Make sure the shield is as close as possible to the signal terminal points. When using twisted pair cables, keep the cable twisted until just before the terminal point.

**NOTE:**

The busbar is only for shielding the module, not for the strain relief of the connected cables.

**Wiring the connector**

- Connect the cables to the connector. Please proceed as described in [Section “Connecting unshielded cables” on page 74](#).

## 8.6 Removing cables from the terminal point

- To remove a cable from the terminal point, press on the spring lever using a suitable tool (e.g., bladed screwdriver with a blade width of 2.5 mm). This opens the leg-spring connection of the relevant terminal point (Figure 8-6, A).
- Remove the conductor (Figure 8-6, B).




Figure 8-6 Removing the cable



## 8.7 Connecting the power supplies

### 8.7.1 Axioline F system supply

When using an Axioline F station, you must provide the following supply voltages:

- Supply voltage for the bus coupler or controller ( $U_L$ )
- Supply voltage for sensors and actuators

Unshielded cables are usually sufficient for connecting the power supplies. Connect them as shown in [Section “Connecting unshielded cables” on page 74](#).



For the connector pin assignment of the supply voltage connections, refer to the module-specific documentation.




Figure 8-7 Supply voltages in the Axioline F system

Key:

$U_L$	( $U_{Logic}$ )	Communications power supply
$U_{Bus}$	( $U_{Bus}$ )	Power supply of the Axioline F local bus (generated from $U_L$ )
$U_I$	( $U_{Input}$ )	Supply for digital input modules Sensor/encoder supply (AXL F CNT2 INC2 1F) Encoder/analog supply (AXL F SSI1 AO1 1H)
$U_S$	( $U_{Sensor}$ )	Sensor supply (generated from $U_I$ )
$U_O$	( $U_{Output}$ )	Supply for digital output modules
$U_{IO}$	( $U_{Input/Output}$ )	Supply for digital input and output modules (I/O modules)
$U_A$	( $U_{Analog}$ )	Supply for analog modules
$I_{Bus}$	( $I_{Bus}$ )	Power supply for the local bus



For information regarding which supply voltage is used with a module, refer to the module-specific documentation.

### 8.7.2 Power supply requirements

Choose a power supply unit that is suitable for the currents in your application. The selection depends on the bus configuration and the resulting maximum currents.



**WARNING: Loss of electrical safety when using unsuitable power supplies. Dangerous shock currents.**

The extra-low voltage Axioline F controllers, bus couplers, and modules are designed exclusively for protective extra-low voltage (PELV) operation in accordance with EN 60204-1.

Only PELV according to the defined standard may be used for supply purposes.

- Only use power supply units that ensure safe isolation according to IEC 61010-2-201, EN 61010-2-201. They prevent short circuits between the primary and secondary circuit.



**WARNING: Dangerous contact voltage in the event of ground faults**

- The Axioline F modules for the low voltage area must only be operated in grounded networks.



Die IEC 61131-2 requires power failure protection of 10 ms. To meet this requirement, use only power supply units (230 V AC / 24 V DC, 400 V AC / 24 V DC) that support mains buffering for at least 10 ms.



Observe the information in the module-specific documentation.

### 8.7.3 Supply at the controller or bus coupler

Communications power ( $U_L$ ) is supplied at the controller or bus coupler. It supplies the module electronics (logic) of the controller or bus coupler. Additionally, it generates the communications power for the local bus ( $U_{Bus}$ ), which supplies the connected modules with logic current.

If the communications power  $U_L$  is disconnected, the local bus will shut down.

### 8.7.4 Supply at the power module

If the maximum load of the bus coupler for the Axioline F local bus supply (communications power  $U_{Bus}$ ) is reached, you can use the AXL F PWR 1H power module (item no. 2688297) to provide this voltage again.

To this end, apply a 24 V DC voltage ( $U_L$ ) to the module from which  $U_{Bus}$  is generated.



**NOTE: Malfunction**

The power module only boosts the  $U_{Bus}$  voltage when it is snapped onto the associated red bus base module and when the  $U_{Bus}$  voltage is available in the bus segment upstream of the power module.

### 8.7.5 Supply at the I/O modules

The inputs and outputs, as well as the sensors, are supplied directly at each module.

The input and output power supply ( $U_I/U_O/U_{IO}/U_A$ ) should be installed and fused independently of the communications power ( $U_L$ ). In this way, the local bus can be operated even if some I/O devices are switched off. This also prevents unnecessary interference couplings between I/O and logic.

The use of separate power supply units for  $U_L$  and  $U_I/U_O/U_{IO}/U_A$  may be necessary in environments with a lot of interference.

### 8.7.6 Jumpers in power connectors, potential forwarding, and fusing

Terminal points a1 and a2, as well as b1 and b2 are jumpered in the power connector. You can therefore use one of the terminal points for supply and the second terminal point for forwarding a potential.



**NOTE: Module damage when overloaded**

Please note that the maximum current carrying capacity of a terminal point of 8 A must not be exceeded.

Protect the supply accordingly.




Figure 8-8 Jumpering in the power connector and example of potential forwarding

F1, F2 Protecting the supply voltage using suitable fuses (see module-specific documentation)



Considering the current carrying capacity of the terminal points, potential forwarding as shown in [Figure 8-8](#) must not be used when the digital output module is fully loaded (e.g., AXL F DO16/3 2F current consumption at  $U_O$  is 8 A, maximum).

### 8.7.7 Parallel supply

If the maximum current consumption is greater than 8 A for a module, however, you wish to fully load the module, the supply voltage can be supplied in parallel. The module can now be loaded with 16 A, maximum.




Figure 8-9 Parallel supply of the supply voltage

## 8.8 Connecting the network

Your network cable is connected to a controller or bus coupler.



Connect the network according to the module-specific documentation.

## 8.9 Connecting the USB cable to the USB interface

The AXC 305x controllers are provided with a programming interface, and the AXC 105x controllers and the bus couplers are provided with a service interface. For the type of the USB socket, refer to the module-specific data sheet. In addition to providing the network interface, the interface enables communication with the controller or bus coupler from a PC.

This interface can be used, for example, to assign the IP address of the controller or bus coupler. In addition, the Diag+ diagnostic tool can be used to access the controllers, and Startup+ can be used to access the bus couplers and the class 1000 controllers.



To use the programming interface, a corresponding driver must be installed. It is provided with the software tools from Phoenix Contact.



### **NOTE: Damage to the USB interface**

In PCs, the USB ports are usually not electrically isolated from the rest of the hardware. This does not cause any problems for USB devices that do not have their own reference ground. However, if you connect grounded devices (e.g., the bus coupler), ground loops with undesired compensating currents may occur. These compensating currents can impair data transmission and, in extreme cases, destroy the interfaces.

#### **Recommendation:**

Connect the USB interface of the bus coupler to your PC in such a way that it is electrically isolated.

To do this, use a USB isolator.

A connecting cable is required for connection of the controller or bus coupler to a PC via the programming or service interface.

Table 8-4 Connection cable

Interface type	Type	Order No.
Micro USB	CAB-USB A/MICRO USB B/2,0M	2701626
USB type C	CAB-USB A/ USB C/1,8M	2404677
	CAB-USB C/ USB C/1,8M	1021809



Do not connect the USB connecting cable until you have supplied the controller or bus coupler with voltage and the controller or bus coupler has successfully entered the operating state following startup.

- Connect the connecting cable to the programming or service interface of the controller or bus coupler and to a free USB interface of the PC.




Figure 8-10 Connecting cable between PC and controller or bus coupler (the isolator is not shown)

## 8.10 Connecting sensors and actuators

Sensors and actuators are connected using I/O module connectors.

Connect the unshielded cables as described in [Section “Connecting unshielded cables” on page 74](#).

Connect the shielded cables as described in [Section “Connecting shielded cables” on page 75](#).

### 8.10.1 Connection technology for sensors and actuators

The I/O modules of the Axioline F product group normally permit connection of sensors and actuators in 1, 2, 3 or 4-wire technology.

The relevant module-specific data sheets indicate which connection technology is possible for the individual modules.

## 8.10.2 Connections used for extra-low voltage digital I/O modules



For the actual terminal point assignment, refer to the corresponding module-specific data sheet. It also provides a connection example.

Table 8-5 Overview of the connections used for extra-low voltage digital input modules

Connection	Representation in the figure	1-wire	2-wire	3-wire	4-wire
Sensor signal IN	IN	X	X	X	X
Sensor supply $U_S$	$U_S$ (+24 V)	–	X	X	X
Ground GND	GND	–	–	X	X
Grounding/FE shielding	FE ( $\frac{1}{\equiv}$ )	–	–	–	X

X Used  
– Not used

Table 8-6 Overview of the connections used for extra-low voltage digital output modules

Connection	Representation in the figure	1-wire	2-wire	3-wire
Actuator signal OUT	OUT	X	X	X
Ground GND	GND	–	X	X
Grounding/FE shielding	FE ( $\frac{1}{\equiv}$ )	–	–	X

X Used  
– Not used

### 8.10.3 Connecting digital sensors and actuators using different connection technologies

#### 1-wire technology




Figure 8-11 1-wire connection for digital modules

#### Sensor

Figure 8-11, A, shows the connection of a 1-wire sensor.

- The switch SW provides the input signal.
- The sensor signal is routed to terminal point IN1.
- The sensor is supplied with a 24 V voltage.



**NOTE: Malfunction**

To ensure the correct function, supply the sensors and  $U_I$  from a power supply with a common GND as reference potential.

#### Actuator

Figure 8-11, B, shows the connection of a 1-wire actuator.

- The actuator is supplied by output OUT1.
- The load is switched directly via the output.



**NOTE: Malfunction**

To ensure the correct function, make sure that GND of the actuators and GND of the supply voltage  $U_o$ , which supplies the actuators, have the same potential.



## 2-wire technology




Figure 8-12 2-wire connection for digital modules

## Sensor

Figure 8-12, A, shows the connection of a 2-wire sensor.

- The sensor signal is routed to terminal point IN1.
- The sensor is supplied by voltage  $U_s$ .

## Actuator

Figure 8-12, B, shows the connection of an actuator.

- The actuator is supplied by output OUT1.
- The load is switched directly via the output.

## 3-wire technology




Figure 8-13 3-wire connection for digital modules

## Sensor

Figure 8-13, A, shows the connection of a 3-wire sensor.

- The sensor signal is routed to terminal point IN1.
- The sensor is supplied with power via terminal points  $U_s$  and GND.

## Actuator

Figure 8-13, B, shows the connection of a shielded actuator.

- The actuator is supplied by output OUT1.
- The load is switched directly via the output.
- The actuator is grounded via the terminal point FE.

## 4-wire technology




Figure 8-14 4-wire connection for digital modules

## Sensor

Figure 8-14 shows the connection of a shielded 4-wire sensor.

- The sensor signal is routed to terminal point IN1.
- The sensor is supplied with power via terminal points  $U_s$  and GND.
- The sensor is grounded via the terminal point FE.

### 8.10.4 FLK

You can connect PLC relays from the “Interface” product range quickly and conveniently using the AXL F DO16 FLK 1H digital output module with 20-pos. FLK connection. This means that you can also use this output module in applications which require relays, e.g., to switch high voltages or currents.




Figure 8-15 Connection of relay modules




Figure 8-16 Connection of a termination board



For accessories, refer to the module-specific data sheet.

## 8.10.5 Redundant signals

If you are using I/O modules redundantly, connect the modules as shown in [Figure 8-17](#). In the example, the two modules are located in two Axioline F stations.

### 8.10.5.1 Redundant digital inputs




Figure 8-17 Example: connection for redundant use of digital inputs

IN08	Digital input 8
$U_S$	Sensor supply
GND	Reference potential



#### CAUTION: Malfunction

To avoid malfunction, make sure that the GND connection shown in [Figure 8-17](#) is established as the reference potential to the redundant signal inputs.

Make sure that, in the event of a short circuit of the sensor supply, the effects are limited by providing decoupling (longitudinal diode).

## 8.10.5.2 Redundant digital outputs




Figure 8-18 Example: connection for redundant use of digital outputs

OUT08	Digital output 8
$U_O$	Supply of digital outputs
GND	Reference potential

**CAUTION: Malfunction**

To avoid malfunction, make sure that the GND connection shown in [Figure 8-18](#) is established as the reference potential to the redundant signal outputs.

Make sure that, in the event of a short circuit of the supply, the effects are limited by providing decoupling (longitudinal diode).

## 9 Grounding and shielding

### 9.1 Grounding concept

Within an Axioline F station, a distinction is made between functional grounding (FE) and protective grounding (PE).

#### Protective grounding (PE)

Protective grounding protects people and machines against hazardous voltages. To avoid these dangers to the greatest extent possible, correct grounding, taking the local conditions into account, is vital.

#### Functional grounding (FE)



Functional ground is only used to discharge interference. It does not provide touch protection for people.

Functional grounding is used to improve immunity to interference. All devices must be grounded so that any possible interference from connectors for data transmission is shielded and discharged to ground.

#### 9.1.1 Protective ground (PE)

Protective ground is a low-impedance current path that minimizes the risk to the user in the event of an error. This includes a high voltage and/or high current error between an electrical circuit and ground.

According to the electrical design, the Axioline F low-voltage modules correspond to protection class II devices and therefore do not require grounding. However, IP20 protection is not sufficient for protection class II. This means that the modules only become real protection class 2 devices when used with a control cabinet or an installation box.

### 9.1.2 Functional ground (FE)

Functional ground is a low-impedance current path between circuits and ground. This current path is not intended as a protective measure but to improve immunity to interference instead, for example.

Functional ground is used in the 24 V DC area (protective extra-low voltage).

To ensure reliable functional grounding, observe the following:

- 1 The Axioline F modules (controller, bus coupler, backplanes, I/O modules) have at least one FE spring (metal clip, 1 in Figure 9-1) at the bottom. This spring establishes an electrical connection to the grounded DIN rail when the module is mounted. When using grounding terminal blocks to connect the DIN rail to protective ground, the modules are then also grounded when snapped onto the DIN rail.




Figure 9-1 FE spring (1)

- 2 When using modules for surge protection (TRABTECH) connect their functional ground directly with the grounded DIN rail. Do **not** connect the functional ground of the modules for surge protection to an Axioline F module (e.g., to an FE contact of an Axioline F connector). This ensures that interference is discharged before it enters the Axioline F module. Only then is good electromagnetic compatibility ensured.

## 9.2 Shielding concept

Shielding is used to reduce the effects of interference on the system.

### 9.2.1 Shielding with Axioline F

In the Axioline F system, shielded cables are used with the following modules:

- Network cables
- Connecting cables
  - On modules for analog signals (analog input, analog output, temperature measurement)
  - On function modules and acquisition modules

Observe the following points when shielding:

- Connect the shield to a module before connecting the signal.
- Ensure a large surface connection of the shield.
- Make sure there is good contact between the shield and shield bus (synonyms: neutral busbar, busbar).
- Do not damage or squeeze the conductors.
- When connecting the shielding, observe the specifications for wiring.
- Make sure the shield is as close as possible to the signal terminal point.

### 9.2.2 Shielding when connecting analog sensors and actuators

- Always connect analog sensors and actuators with shielded, twisted pair cables.
- Connect the shield via a shield bus (see [Figure 9-9](#)).



When connecting the cables, observe the information in the module-specific data sheet.

- As a rule, shielding must only be connected directly to the FE potential on one side. This is to prevent any occurrence of equipotential bonding currents via the shielding (see [Figure 9-9](#) and [Figure 9-10](#)).
- If necessary, integrate the shielding concept for analog I/O cables in the system concept. For example, it is advisable to use a central FE shield connection at the control cabinet entry (see [Figure 9-10](#)).



For connecting the shield, Phoenix Contact recommends the AXL SHIELD SET Axioline F shield connection set or the shield connection clamp products from the “Control cabinet accessories” product range.



### 9.2.3 Connecting the shield using the Axioline F shield connection set



If you use Axioline F backplanes (AXL F BP SE4 or AXL F BP SE6), observe [Section “Axioline F backplane” on page 105](#).

The shield connection set consists of two shield bus holders and two SK 5 shield connection clamps. It can be used to connect cable shields in an Axioline F station in the vicinity of the modules.




Figure 9-2 Connecting the shield with AXL SHIELD SET

- 1 Lead the analog cable into the connector, making sure to maintain the cable insulation.
- 2 Use shielded twisted pair cables.
- 3 Shield bus holder
- 4 SK 5 shield connection clamps (2 pcs. included in the AXL SHIELD SET) for securing the busbar (accessories) on the shield bus holder
- 5 Shield connection clamp for applying the shield on the busbar (SK ..., see [Section “Ordering data for accessories” on page 138](#))  
Connect the shield directly to the FE potential.  
Connect the shield for the entire analog transmission path to FE potential at only one point. In this example, this point is the busbar.
- 6 Busbar (NLS-CU 3/10 ..., see [Section “Ordering data for accessories” on page 138](#))
- 7 Lead the sensor cable into the sensor, making sure to maintain the cable insulation.

### Axioline F shield connection set




Figure 9-3 Set components

- 1 Shield bus holders (2 pcs.)
- 2 SK 5 shield connection clamps for securing the busbar on the shield bus holder (2 pcs.)

Contact is made with the shield on the busbar using shield connection clamps (both are available as accessories). Select the shield connection clamp according to the cable cross section and type (SK or SKS), see [Section “Material for shield connection” on page 141](#).

### Mounting

Mount the shield bus holders after mounting the bus base modules and before mounting the electronics modules.


Polished surfaces indicate the positions of the shield bus holders on the bus base modules.

The maximum distance between two adjacent shield bus holders should not exceed 215 mm (e.g., four modules with four connectors next to each other).

If the busbar is secured using more than two shield bus holders, distribute the holders equally over the width of the busbar.




If using a shield bus holder at the end of an Axioline F station, mount the shield bus holder after the last module. In this case, it is not positioned above a bus base module. Secure the shield bus holder using an end bracket (accessories).




- Hook the shield bus holder onto the DIN rail.

Figure 9-4 Hooking on the shield bus holder




- Snap the shield bus holder onto the DIN rail.




- Then snap on the second shield bus holder.

Figure 9-5 Snapping on the shield bus holders



- Push the busbar into the shield bus holders.



- Secure the busbar using the SK 5 shield connection clamps included in the scope of supply.

Figure 9-6 Mounting the busbars





Figure 9-7 Mounting the electronics modules


- Mount the electronics modules.

## Removal

For removal, use a screwdriver with a blade width of 4 mm (see accessories for examples).



- First, remove the adjacent electronics modules (to the right and left of each shield bus holder).
- Insert the screwdriver in the release slot.



- Turn the screwdriver to release the locking clip from the DIN rail.
- Remove the shield bus holder.

Figure 9-8 Removing the shield connection



The locking clip may become deformed following contact with the screwdriver. In this case, bend it back into shape prior to reassembly.

## 9.2.4 Connecting the shielding to a busbar




Figure 9-9 Connecting the shielding to a busbar

- 1 Lead the analog cable into the connector, making sure to maintain the cable insulation.
  - 2 Use shielded twisted pair cables.
  - 3 Support bracket (AB ..., see [Section "Ordering data for accessories" on page 138](#))
  - 4 Shield connection clamp for applying the shield on the busbar (SK ..., see [Section "Ordering data for accessories" on page 138](#))
- Connect the shield directly to the FE potential.  
Connect the shield for the entire analog transmission path to FE potential at only one point. In this example, this point is the busbar.
- 5 Busbar
  - 6 Lead the sensor cable into the sensor, making sure to maintain the cable insulation.

## 9.2.5 Integrating analog shielding in a concept with central equipotential bonding at the control cabinet entry




Figure 9-10 Integration of analog shielding in a concept with central equipotential bonding at the control cabinet entry

- 1 Lead the analog cable into the connector, making sure to maintain the cable insulation.
- 2 Use shielded twisted pair cables.
- 3 Connect the strain relief directly to the FE potential.  
Connect the shield for the entire analog transmission path to FE potential at only one point. In this example, this point is the marshalling level.
- 4 Lead the sensor cable into the sensor, making sure to maintain the cable insulation.



### NOTE: Functions may be impaired

Observe the following when integrating the shielding of analog I/O cables in an equipotential bonding concept:

Direct connection to the FE potential must only be made at one point (e.g., at the central grounding point of the marshalling level).

## 10 Diagnostic and status indicators



If you use Axioline F backplanes (AXL F BP SE4 or AXL F BP SE6), observe [Section “Axioline F backplane” on page 105](#).

All Axioline F modules are provided with diagnostic and status indicators for quick local error diagnostics. They enable the clear localization of system errors (bus errors) or I/O errors.

### Diagnostics

The diagnostic indicators (red, yellow, or green) provide information on the state of the module. In the event of an error, they provide information about the type and location of the error. The module is functioning correctly if all of the green LEDs are on.

### Status

The status indicators (yellow) indicate the status of the relevant input or output and of the connected I/O device.

### Extended diagnostics

Some modules have extended diagnostics. Short circuit or overload of the sensor supply, for example, can be detected and reported. If a short circuit occurs at an output, some output modules can diagnose each channel individually. Information regarding the supply voltage is also reported. Information about I/O errors is sent to the controller with precise details of the error type and is displayed using status indicators.



Diagnostic indicators D, UA, E1, E2 show the current status.

This status is not saved. This means, for example, that an open circuit or overrange is indicated via the LEDs. If the respective error has been removed and no other error has occurred, the LEDs indicate the error-free state again.

The error is not saved on the module. For some modules, however, the DiagState object (0018<sub>hex</sub>) is used to report some specific errors to the controller.



All possible positions for diagnostic and status indicators are equipped with light guides on the Axioline F connectors.

Since not every position has its own LED on the printed circuit board, there are some light guides without any function.

Examples:

AXL F AI8 1F: light guides 00 ... 07, 10 ... 17, 20 ... 27 and 30 ... 37 do not have a function.

AXL F DI32/1 1F: light guides 00 ... 07, 10 ... 17, 20 ... 27 and 30 ... 37 have a function.



For information regarding the diagnostic and status indicators on each module and their meaning, refer to the module-specific documentation.

### 10.1 Indicators on controllers



For information regarding the diagnostic and status indicators of the controllers, refer to the corresponding documentation.

# 10.2 Indicators on bus couplers

Bus couplers have power supply indicators, as well as network and module indicators. Indicators for the power supply are located on the power connector. The other indicators are located on the module.




Figure 10-1 Indicators on a bus coupler (example: AXL F BK EIP)

All bus couplers have the following indicators:

Table 10-1 LEDs on bus couplers

Designation	Color	Meaning	State	Description
U <sub>L</sub>	Green	U <sub>Logic</sub>	On	Communications power supply present.
			Off	Communications power supply not present.
RDY	Green/ yellow/ red	Ready	Green on	Device is ready to operate.
			Flashing green/yellow	Undervoltage or overvoltage of communications power.
			Yellow on	Overtemperature.
			Yellow on	Firmware/bus coupler is booting.
			Flashing yellow	Firmware update is being performed.
			Flashing yellow/red	Firmware update has failed.
			Flashing red	Faulty firmware.
			Red on	Rotary encoding switches are set to an invalid/reserved position.
			Off	Device is not ready to operate.



Table 10-1 LEDs on bus couplers

Designation	Color	Meaning	State	Description
D	Red/ yellow/ green	Diagnostics of local bus communication		
		Run	Green on	The station is ready to operate. The communication within the station is OK. The controller is providing <b>valid data</b> . An error has not occurred
		Active	Flashing green	The station is ready to operate. The communication within the station is OK. The controller is <b>not providing valid data</b> . There is no malfunction on the module.
			Flashing green/red	A residual system is operated, at least one device in the configuration is not reachable.
		Ready	Yellow on	The station is ready to operate. No data is being exchanged.
		Connected	Flashing yellow	Access from Startup+ in I/O check mode
			Flashing yellow/red	Local bus error during active I/O check (when using Startup+)
		Not connected	Flashing red	Local bus error during startup
				Possible causes: – Configuration cannot be generated, information is missing from a device – Chip version of a device is <V1.1 – Desired configuration and actual configuration differ – Local bus device not connected – Maximum number of local bus devices exceeded
		Reset	Red on	The station is ready to operate but has lost connection to at least one device.
				Possible causes: – Communication error – Local bus device has been removed or a configured device is missing – Reset at a local bus device – Serious device error at a local bus device (local bus device can no longer be reached)
		Power down	Off	Device is in (power) reset or power save mode.
E	Yellow/ red	Error	Yellow on	I/O warning at a local bus device
			Red on	I/O error at a local bus device
			Off	No I/O messages present.

Further diagnostic and/or status indicators may also be available.



For information regarding the diagnostic and status indicators of the bus couplers and their meanings, refer to the documentation for the bus couplers.

## 10.3 Indicators on I/O modules

The LEDs of the I/O modules are located on the connectors.

### 10.3.1 LEDs on the power connectors



Figure 10-2 LEDs on the power connectors (examples)

Table 10-2 LEDs on the power connectors

Designation	Color	Meaning	State	Description
D	Red/ yellow/ green	Diagnostics of local bus communication		
		Run	Green on	The device is ready to operate. The communication within the station is OK. The controller is providing <b>valid process data</b> . There is <b>no malfunction</b> .
		Active	Flashing green	The device is ready to operate. The communication within the station is OK. The controller is <b>not</b> providing <b>valid data</b> . <b>No malfunction</b> has occurred on the module.
		Device application not active	Flashing green/ yellow	The device is ready to operate. The communication within the station is OK. The controller is providing <b>valid process data</b> . There is a <b>malfunction on the I/O side</b> of the module. The process output data <b>cannot</b> be output and/or the process input data <b>cannot</b> be read in.
		Ready	Yellow on	The device is ready to operate, but has still not detected a valid cycle after power-up.
		Connected	Flashing yellow	The device is not (yet) part of the active configuration.
		Reset	Red on	The device is ready to operate, but has lost the connection to the head. of the station (bus coupler or controller).
		Not connected	Flashing red	The device is ready to operate, but there is no connection to the previous device.
		Power down	Off	Device is in (power) reset state. – The supply voltage not present. – The energy saving mode is active.
U <sub>x</sub>	Green	U <sub>x</sub>	On	I/O supply is present.
			Off	I/O supply not present.

Table 10-2 LEDs on the power connectors

Designation	Color	Meaning	State	Description
E1	Red/ yellow	Device error or warning Indicates messages that apply to the entire device.		
			Red on	Error (priority 1)
			Yellow on	Warning (priority 2)
E2	Red/ yellow	I/O error, channel error or warning (group message) Indicates messages that only apply to a single channel.		
			Red on	Error (priority 1)
			Yellow on	Warning (priority 2)

Voltages  $U_x$ :

$U_I$	( $U_{\text{Input}}$ )	Supply for digital input modules; sensor/encoder supply
$U_O$	( $U_{\text{Output}}$ )	Supply for digital output modules
$U_{IO}$	( $U_{\text{Input/Output}}$ )	Supply for digital input and output modules
$U_A$	( $U_{\text{Analog}}$ )	Supply for analog modules



For information regarding the diagnostic and status indicators on each module and their meaning, refer to the module-specific documentation.

### 10.3.2 LEDs on the I/O connectors

The LEDs on the I/O connectors are numbered according to the terminal points. All LED locations are numbered even when they are not used.

Exception: modules with secure inputs or outputs (see module-specific documentation).




Figure 10-3 LEDs on the I/O connectors (e.g., AXL F DI16/4 2F, AXL F DO16/3 2F)

Table 10-3 LEDs on the I/O connectors

Designation	Color	Meaning	State	Description
xx	Yellow	Status of the input or output	On	Corresponding input or output set.
			Off	Corresponding input or output not set.
yy	Red	Diagnostics of the output	On	Error at the output.
			Off	No error at the output.

xx Channel identification

yy Channel identification



Table 10-3 lists commonly used LEDs. Additional LEDs may also be found on the modules.

For information regarding the LEDs on each module and their meaning, refer to the module-specific documentation.

### 10.4 Reporting diagnostics via PDI

The malfunctions indicated by the local diagnostic and status indicators are also mapped in PDI object 0018<sub>hex</sub> (DiagState).

Detailed information can be found in [Section “Objects for diagnostics” on page 147](#) and in the module-specific data sheet.

# 11 Axioline F backplane

The Axioline F backplane is intended for use in a station that is opened by an Axioline F bus coupler or an Axiocontrol.

Depending on the version, the backplane can accommodate four or six Axioline Smart Elements.

## 11.1 Housing versions

Two housing versions are available for the Axioline F backplanes, they are shown in [Figure 11-1](#).




Figure 11-1      Housing versions SE4 and SE6

Table 11-1      Housing versions

Housing type	Special feature	Example	Design	Dimensions
SE4	Backplane, 4 slots for Axioline Smart Elements	AXL F BP SE4	<a href="#">Figure 11-2 on page 106</a>	<a href="#">Figure 11-5 on page 108</a>
SE6	Backplane, 6 slots for Axioline Smart Elements	AXL F BP SE6		<a href="#">Figure 11-6 on page 108</a>

## 11.2 Basic design




Figure 11-2 Design of an Axioline F backplane

- 1 Axioline F backplane**
- 2** Release mechanism (base latch)
- 3** Connections for the supply voltage
- 4** Connection to the upstream Axioline F backplane or an Axioline F bus base module
- 5** Slots for Axioline Smart Elements
- 6** Connection for the downstream Axioline F backplane or an Axioline F bus base module (not shown in the figure)
- 7 Axioline Smart Element**
- 8** Release mechanism
- 9** Connections for the I/O devices (if present)



For information on the Axioline Smart Elements, refer to the “Axioline Smart Elements” user manual.

## 11.3 Dimensions

All dimensions are in mm.

### 11.3.1 Dimensions of the backplanes




Figure 11-3 Nominal dimensions of the AXL F BP SE4




Figure 11-4 Nominal dimensions of AXL F BP SE6

### 11.3.2 Dimensions of the backplanes with inserted Smart Elements




Figure 11-5 Nominal dimensions of AXL F BP SE4 with inserted Axioline Smart Elements




Figure 11-6 Nominal dimensions of AXL F BP SE6 with inserted Axioline Smart Elements



## 11.4 Color and marking

<b>Housing color</b>	Axioline F backplanes are available in the housing color traffic gray A (RAL 7042).
<b>Slots</b>	The slots of the backplane are marked (1 in <a href="#">Figure 11-7</a> ).
<b>Indicators</b>	Diagnostic and status indicators are marked with the function, e.g., D, 1 ... 6, UP (2 in <a href="#">Figure 11-7</a> ).
<b>Terminal points</b>	On a backplane, terminal points for the 24 V voltage supply of the I/O supply are available. These are marked with UP+ (a1, a2) and UP- (b1, b2) (3 in <a href="#">Figure 11-7</a> ).




Figure 11-7 Markings of the slots, the LEDs and the terminal points

- 1 Markings of the slots
- 2 Markings of the diagnostic and status indicators
- 3 Markings of the terminal points for the 24 V voltage supply

Equipment identification  
by the user

- You can apply an equipment identifier on the backplane. Two options are available:
- Stick on a label.
- Or
- Snap on a marker.




Figure 11-8 Individual module marking

1 Position for equipment identification

You can use the following marking material provided by Phoenix Contact:

Table 11-2 Marking material

Description	Type	Order No.	Pcs./ Pkt.
Label, continuous, cassette, transparent with black imprint, mounting type: adhesive, can be marked with THERMOFOX	MM-TML (EX4,2)R C1 TR/BK	0803979	1
Marker strip, roll, white, unmarked, can be marked with: THERMOMARK ROLL 2.0, THERMOMARK ROLL, THERMOMARK ROLL X1, THERMOMARK ROLLMASTER 300/600, THERMOMARK X1.2, mounting type: adhesive, for terminal block width: 5 mm, lettering field size: continuous x 5 mm	SK 5.0 WH:REEL	0805221	1
Markers, 24-section, unmarked, can be marked with THERMOMARK CARD and BLUEMARK, color: white	UM6M-TM (5X12)	0830928	10
Markers, sheet, white, unmarked, can be marked with: THERMOMARK CARD, THERMOMARK CARD 2.0, THERMOMARK PRIME, BLUEMARK ID, BLUEMARK ID COLOR, TOPMARK LASER, TOPMARK NEO, mounting type: snap into a high marker groove, for terminal block width: 5.2 mm, lettering field size: 4.17 mm x 11.3 mm	UCT6M-TM 5	0830756	10

## 11.5 Mounting and removing the backplane

### 11.5.1 Safety notes for mounting and removal

#### 11.5.1.1 General safety notes



**NOTE: Electrostatic discharge**

The modules contain components that can be damaged or destroyed by electrostatic discharge. When handling the modules, observe the necessary safety precautions against electrostatic discharge (ESD) according to EN 61340-5-1 and IEC 61340-5-1.



**NOTE: Damage to the electronics**

The maximum permissible current consumption  $U_P$  is 16 A.

Provide external protection for the 24 V supply  $U_P$ . If you use a fuse, the power supply unit must be able to supply four times the nominal current of the fuse. This ensures that the fuse trips reliably in the event of a fault.



**NOTE: Disregarding this warning may result in damage to the contacts or malfunction**

Before working on the backplane, disconnect the I/O devices and the supply from the power.

This means:

- Disconnect the connected I/O devices of all inserted Axioline Smart Elements from the power.
- Switch off the I/O supply voltage  $U_P$  at the backplane.
- Switch off the communications power supply  $U_L$  at the bus head of the station.



**NOTE: Damage to the connections**

To avoid damaging the connections when removing the backplane, observe the following:

- First separate the connections to the upstream and downstream modules (backplane or bus base module), by pushing the modules apart.
- Now disengage the backplane.

See [Section "Removing the backplane from the DIN rail" on page 115](#).



**NOTE: Damage to contacts**

There is risk of the terminal points getting damaged if they are mechanically overstrained.

- Relieve strain in the connected cables.

### 11.5.2 Basic information about mounting

Note the information in [Section "Basic information about mounting" on page 56](#).

### 11.5.3 Mounting the backplane and Smart Elements



Please refer to Section [“General safety notes” on page 111](#).

No tools are required for mounting the Axioline F backplanes.

Within an Axioline F station, an Axioline F backplane can be installed in any position. This means:

- Axioline F backplane directly downstream of the station head (controller or bus coupler)
- Axioline F backplane downstream of an Axioline F module
- Axioline F backplane downstream of an other Axioline F backplane

#### Example station




Figure 11-9 Example station for mounting

- 1 End bracket (CLIPFIX 35 or E/AL-NS 35)
- 2 Axioline F bus head (controller or bus coupler)
- 3 Axioline F backplane with inserted Smart Elements



If you use additional Axioline F modules downstream of the station head, observe Section [“Bus base modules, controllers, and bus couplers” on page 61](#) ff.

### 11.5.3.1 Mounting the backplane

- First mount the end bracket on the DIN rail.
- Install the bus base module for the controller or bus coupler onto the DIN rail.
- Place the backplane on the DIN rail (Figure 11-10, A).
- First backplane: push the connection of the backplane into the connection of the previous bus base module (Figure 11-10, B).
- Place the controller or bus coupler onto the bus base module (Figure 11-10, C).
- See [Section “Bus base modules, controllers, and bus couplers” on page 61](#).
- Subsequent backplanes: push the backplanes together (Figure 11-10, D).
- Mount the final end bracket on the DIN rail.




Figure 11-10 Connecting the backplane with the bus base module



In a station with Axioline F modules:

- It is not possible to snap a backplane to the previous bus base module if there is already an electronics module on it. In this case, first remove the electronics module before snapping on a backplane.
- If you want to mount an Axioline F module downstream of a backplane:
  - Place the associated bus base module on the DIN rail.
  - Push the bus base module into the appropriate connection of the backplane.
  - To do this, proceed as described in [Section “Mounting and removing modules” on page 53](#).

### 11.5.3.2 Inserting Axioline Smart Elements




Figure 11-11 Slot numbering (example AXL F BP SE6)

- The slots are numbered as shown in [Figure 11-11](#).
- Insert the required Axioline Smart Elements into the appropriate slots of the Axioline F backplane ([Figure 11-12, A](#)).
- Push down the release mechanism ([Figure 11-12, B](#)). This locks the Smart Element in the backplane.




Figure 11-12 Inserting the Smart Element



Fill up all slots. If there is a slot you do not want to use, insert an AXL SE SC-A (Order No. 1088134) or AXL SE SC (Order No. 1167159) slot cover. Note the information in [Section “Technical appendix: Controllers, bus couplers, AXL SE SC ... and AXL SE PD ...”](#) on page 168.

## 11.5.4 Removing the backplane



Please refer to Section [“Safety notes for mounting and removal”](#) on page 111.

A standard tool, e.g., a bladed screwdriver with a blade width of 2.5 mm is necessary for removing modules.

### 11.5.4.1 Removing the Axioline Smart Elements

- Before removing a backplane, remove the Smart Elements from the backplane. To do so, pull up the release mechanism vertically ([Figure 11-13, A](#)) and remove the Smart Element ([Figure 11-13, B](#)).




Figure 11-13 Removing a Smart Element

### 11.5.4.2 Removing cables

- Remove the cables that are connected to the backplane. See [Section “Removing cables from the terminal point”](#) on page 121.

### 11.5.4.3 Removing the backplane from the DIN rail



#### NOTE: Damage to the connections

To avoid damaging the connections when removing the backplane, observe the following:

- Separate the connections to the upstream and downstream modules (backplane or bus base module), by pushing the modules apart ([Figure 11-14, A](#))
- Now disengage the backplane ([Figure 11-14, B](#)).




Figure 11-14 Separating and removing the module from neighboring modules

If there is a device with a bus base module upstream of the backplane to be removed:

- Disengage the device from the bus base module (Figure 11-15, A).
- Pull the backplane out of the connection of the bus base module.
- See Section “Controller, bus coupler, and I/O modules” on page 64.

If there is a device with a bus base module downstream of the backplane to be removed:

- Remove the Axioline F module or the bus base module from the connection of the backplane.

Separating backplanes from each other:

- Disconnect the neighboring backplanes from one another by carefully inserting a bladed screwdriver into the groove between the backplanes (Figure 11-15, B1).
- Push the adjacent devices far enough apart that the backplane to be removed no longer has contact to the adjacent devices (Figure 11-15, B2, B3).
- Insert a suitable tool (e.g. bladed screwdriver) into the snap-on mechanism (base latch) of the backplane and release it (Figure 11-15, B4).
- Rotate the backplane away from the DIN rail. (Figure 11-15, B5).




Figure 11-15 Removing the backplane

### Working in confined spaces



As shown in Figure 11-9 on page 112 there is a CLIPFIX 35 or E/AL-NS 35 end bracket upstream and downstream of the station.

The CLIPFIX 35 is 9.5 mm wide.

The E/AL-NS 35 is 10 mm wide.

If you remove the end bracket upstream and downstream of the station, you gain the space needed to remove the backplane from the neighboring modules.



### 11.5.5 Replacing the backplane

- To replace a backplane, proceed as described in Section [“Removing the backplane” on page 115](#) and [“Mounting the backplane and Smart Elements” on page 112](#).
- Once replaced, restore all the necessary connections.

### 11.5.6 Mounting distances

See [Section “Mounting distances” on page 67](#).

## 11.6 Connecting and removing cables

### 11.6.1 Connections and cables at an Axioline F backplane

Connect the I/O supply voltage  $U_P$  for the Axioline Smart Elements to the terminal points of the backplane. You can use solid and stranded cables, with or without ferrules.

The backplanes are designed for a maximum current of 16 A.



For use in applications in which UL approval is required:  
Observe any specifications in the documentation of the backplane and Smart Element used and the rating on the devices.

Please observe the following when wiring:

- Make sure to install the conductor in the middle of the wiring space, especially with small cross sections.

### 11.6.2 Conductor cross sections and stripping and insertion lengths

#### Conductor cross sections

Table 11-3 Permitted conductor cross sections

Conductor	Cross section
Solid	0.5 mm <sup>2</sup> ... 2.5 mm <sup>2</sup>
Stranded with ferrule without insulating collar (A ...), according to DIN 46228-1	
– sleeve length 10 mm	
Stranded with ferrule with insulating collar (AI ...), according to DIN 46228-4	
– sleeve length 8 mm	
– sleeve length 10 mm	
Stranded without ferrule ( <b>only when actuation slot for inserting the conductor is used</b> )	



Stranded cables without ferrules are only suitable for Push-in connection technology **when the actuation slot is used.**

Table 11-4 Permitted AWG conductor cross sections

Conductor	Cross section
AWG	20 ... 14

**Stripping and insertion lengths****NOTE: Malfunction when the conductor is not securely fixed**

To ensure secure fixing and correct functioning:

Make sure that the stripping length of a conductor without ferrule or the insertion length of a conductor with ferrule corresponds to the specifications.

For crimping, we recommend pliers for trapezoidal crimp: CRIMPFOX 6, CRIMPFOX DUO 10 or CRIMPFOX 10T-F, see [Section “Ordering data for accessories” on page 138](#).

According to the current state, these crimping pliers meet the general conditions regarding wiring space for the Axioline F backplane (according to internal cylindrical gauge DIN EN 60947-1 (DIN VDE 0660-100)-A1).

Conductor without ferrule: stripping length 8 mm

Conductor with ferrule: insertion length 8 mm or 10 mm

Ferrules: see [Section “Ordering data” on page 138](#).

**TWIN ferrules****NOTE: Malfunction when using wrong ferrule**

TWIN ferrules are not permitted in the Axioline F system.

### 11.6.3 Connecting cables




Figure 11-16 Terminal point assignment of the backplanes

When wiring, proceed as follows:

- Strip 8 mm off the cable.

#### Without tools

You can connect solid cables or cables with ferrules without tools.

- Insert the cable into the terminal point. It is clamped into place automatically.




Figure 11-17 Connecting a cable without tools

#### With tools

- Open the spring by pressing the actuation slot with the screwdriver (Figure 11-18, A). Use, for example, a bladed screwdriver with a blade width of 2.5 mm. Phoenix Contact recommends the SZS 0,4x2,5 screwdriver (see [Section "Ordering data" on page 138](#)).
- Insert the cable in the terminal point (B).
- Remove the screwdriver to secure the conductor.




Figure 11-18 Connecting a stranded cable with tools

#### 11.6.4 Removing cables from the terminal point

- To remove a cable from the terminal point, press on the actuation slot using a suitable tool (e.g., bladed screwdriver with a blade width of 2.5 mm to max. 3.5 mm). This opens the terminal point ([Figure 11-19, A](#)).
- Remove the conductor ([Figure 11-19, B](#)).




Figure 11-19 Removing the cable

## 11.7 Power supplies

The Axioline F backplanes are an integral part of the energy supply concept of Axioline F.  
See [Section “Connecting the power supplies” on page 77](#).  
See [Section “Power supply requirements” on page 78](#).

### 11.7.1 Supplying the Axioline F system with Axioline F backplanes

When using an Axioline F backplane within an Axioline F station, you must provide the following supply voltages:

- Supply voltage for the bus coupler or controller ( $U_L$ )
- Supply voltage for sensors and actuators

Unshielded cables are usually sufficient for connecting the power supplies. Connect them as shown in [Section “Connecting cables” on page 120](#).



For the terminal point assignment of the supply voltage connections, refer to the module-specific documentation.




Figure 11-20 Supply voltages in an Axioline F station with Axioline F backplanes

Key:

$U_L$	( $U_{Logic}$ )	Communications power supply See <a href="#">Section “Supply at the controller or bus coupler” on page 78</a> .
$U_{Bus}$	( $U_{Bus}$ )	Power supply for the Axioline F local bus (generated from $U_L$ )
$U_{SE}$	( $U_{Smart Element}$ )	Communications power supply for Axioline Smart Elements (generated at $U_{Bus}$ )
$U_P$	( $U_{Periphery}$ )	I/O supply for Axioline Smart Elements

### 11.7.2 Supply at the Axioline F backplane

At an Axioline F backplane, you supply the I/O devices of the Axioline Smart Elements.

The voltage supply for the I/O devices ( $U_P$ ) should be installed and fused independently of the communications power ( $U_L$ ). In this way, the local bus can be operated even if some I/O devices are switched off. This also prevents unnecessary interference couplings between I/O and logic.

The use of separate power supply units for  $U_L$  and  $U_P$  may also be necessary in environments with a lot of interference.

### 11.7.3 Jumpers, potential forwarding, and fusing

In the backplane, terminal points  $U_{P+}$  (a1 and a2) as well as terminal points  $U_{P-}$  (b1 and b2) are jumpered. You can therefore use one of the terminal points for supply and the second terminal point for forwarding a potential.




Figure 11-21 Jumping the terminal points and example of potential forwarding

F1, F2 Protecting the supply voltage using suitable fuses (see module-specific documentation)



#### NOTE: Module damage when I/O supply $U_P$ is overloaded

Two key figures apply for the I/O supply:

- Current consumption  $U_P$  at each Smart Element slot: **max. 6 A**
- Permissible total current at  $U_P$  supply: **max. 16 A**
  - Make sure that no Smart Element draws more than 6 A at  $U_P$ .
  - Make sure that all Smart Elements that have been installed onto a backplane together do not draw more than 16 A.
  - If you conduct the potential to the next backplane: Make sure that the total current of 16 A is not exceeded.
  - Protect the supply accordingly.

## 11.8 Grounding and shielding

For the Axioline F backplanes, the specifications on grounding and shielding as set out in [Section “Grounding and shielding” on page 90](#) apply.



If, for shielded cables on Smart Elements, you want to connect the shielding using an Axioline F shield connection set, observe the following:

You cannot place the shield bus holders next to an Axioline F backplane. This means:

- If there are Axioline F modules in your station:  
Place the shield bus holders at a suitable position between two Axioline F modules respectively.
- If there are no Axioline F modules in your station:  
Place the shield bus holders upstream and downstream of the station, so that they are fixed by the end brackets.

Or:

- Connect the shielding to a busbar.



## 11.9 Diagnostic and status indicators

The Axioline F backplanes are provided with diagnostic and status indicators for quick local error diagnostics. They enable the clear localization of system errors (bus errors) or I/O errors.




Figure 11-22 LEDs on an Axioline F backplane

One D LED (red, yellow, green) is assigned to each slot for a Smart Element.

Each D LED signals the state of the local bus of the assigned slot.

The UP LED signals the state of the I/O supply voltage.

Meaning in the following table:

- 1) The controller or bus coupler firmware does not support passive Smart Elements and empty slots.
- 2) The controller or bus coupler firmware supports passive Smart Elements.

A Smart Element is passive if it has no process data and no PDI objects are implemented.

Passive Smart Elements:

- AXL SE SC
- AXL SE PD16 24V, AXL SE PD16 GND, AXL SE PD8/8 24V/GND



For more information on the controllers and bus couplers that support Smart Elements, please refer to the data sheets for the passive Smart Elements and backplanes.

Table 11-5 LEDs on an Axioline F backplane

Designation	Color	Meaning	State	Description
D (1 ... 4/6)	Red/ yellow/ green	Diagnostics		Diagnostics for local bus communication for each backplane slot
		Run	Green on	The Smart Element is ready to operate. Communication within the station is ok. The controller is providing <b>valid process data</b> . <b>No malfunction</b> occurred.
		Active	Flashing green	The Smart Element is ready to operate. Communication within the station is ok. The controller is <b>not providing valid process data</b> . No malfunction occurred on the Smart Element. The backplane slot is configured for a passive Smart Element. <sup>2)</sup>
		Device application not active	Flashing green/yellow	The Smart Element is ready to operate. Communication within the station is ok. The controller is providing <b>valid process data</b> . There is a <b>malfunction on the I/O side</b> of the Smart Element. The process output data cannot be output and/or the process input data cannot be read.
		Ready	Yellow on	The Smart Element is ready to operate, but has still not detected a valid local bus cycle after power up.
		Connected	Flashing yellow, 1 Hz	The Smart Element is not (yet) part of the active configuration. During power up: The Smart Element configured for the backplane slot <b>before</b> the slot with the flashing yellow D LED is missing from this slot or it is passive. <sup>1)</sup>
				Configuration difference
			Flashing yellow, 8 Hz	Possible causes: – The Smart Element has lost the connection to the backplane or has been removed. – An unconfigured Smart Element has been plugged into the slot.
				During operation: The Smart Element in the backplane slot <b>before</b> the slot with the flashing yellow/red D LED has lost the connection to the backplane.
		Not connected	Flashing red	The Smart Element is ready to operate, but there is no connection to the previous Smart Element or Axioline F module.
		Reset	Red on	The Smart Element is ready to operate, but has lost the connection to the head of the station (bus coupler or controller).
			Red on (one LED)	The local bus has been interrupted. The flashing red D LED indicates the location of the error in the station.
			Red on (all LEDs)	During power up: There is an unconfigured Axioline F module or Smart Element in the station.
		Power down	Off	The Smart Element is in (power) reset mode.
				Possible causes: – The supply voltage is not present. – Energy-saving mode is active. – The slot is empty or the inserted Smart Element is passive. <sup>1)</sup>
UP	Green	U <sub>Periphery</sub>		I/O supply voltage of the Smart Elements
			On	Supply voltage U <sub>P</sub> is present.
			Off	Supply voltage U <sub>P</sub> is not present.

## 12 Process, parameter, and diagnostic data

The Axioline F local bus is used for transmission of process data as well as parameter and diagnostic data.

### 12.1 Process data

Axioline F devices have at least one byte of process data. If less than eight bits are used, they occupy the least significant bits of the byte.

The significance of the data corresponds to the Motorola format (Big Endian).

The significance of the data bytes declines as the number goes up.



For the process data assignment and the assignment of the process data to the terminal points of a module, refer to the module-specific data sheet.

### 12.2 Parameter and diagnostic data (PDI channel)

Parameter and diagnostic data as well as other information is transmitted via the PDI channel (PDI = Parameters, Diagnostics, and Information).

The PDI channel is used in addition to the process data channel in the Axioline F system for the demand-oriented, acyclic transmission of parameter and diagnostic data as well as other information. Each Axioline F I/O module is equipped with this acyclic channel for exchanging acyclic data.

Read and write services can be used to access communication objects created in the Axioline F I/O module via the PDI channel. These objects can be used, for example, to set measuring ranges, to specify the substitute value behavior of outputs in the event of a bus error, or to read I/O diagnostics details.



The module-specific PDI objects can be found in the module-specific documentation (data sheet or user manual).

## 12.3 Saving of parameters

Every Axioline F module has parameters. They can be read or written or can be read and written. The parameters that can be written are saved every time a change is made.

Some parameters are defined as startup parameters in the device description file of each module.

### Startup parameters (Flash)

Startup parameters are stored retentively (in a non-volatile way, permanently) in the flash memory.

Startup parameters include the application object parameters, e.g., substitute value, filter time etc. As soon as valid parameters are specified for these objects, they are stored retentively on the module.

Due to the storage technology used, parameters that are stored retentively can only be written for a specific number of times (100,000 up to 1,000,000 times, typically). They are not suitable for being changed cyclically.

**NOTE: Damage to the flash memory during cyclic write access**

The flash memory is only designed for a limited number of write access operations. Make therefore sure that write access operations are not performed too often and, in particular, not cyclically.

**Observe this behavior when programming function blocks.**

### Other parameters (RAM)

Other parameters are stored temporarily (in a volatile way) in the RAM.

## 13 Software support

The following software from Phoenix Contact supports you when working with Axioline F:

PLCnext Engineer	PLC programming for PLCnext Control
PC Worx	PLC programming for conventional controllers
Project+	Planning and configuration
Startup+	Startup and parameterization of Axioline F stations
PROJECT complete	Planning and marking
IOL-CONF	Network management

You can also integrate Axioline F into any other system, e.g., via GSDML in TIA Portal or via ESI in TwinCAT®, etc.



For the software for supporting safety modules, refer to the module-specific documentation.



For detailed information on the software of Phoenix Contact, visit [phoenixcontact.com/products](https://phoenixcontact.com/products) under “Automation software”.

## 14 Device replacement, device defect and repair

### 14.1 Device replacement

Axioline F modules can be replaced, if necessary.

If you want to replace an Axioline F module, proceed as follows:

- Observe the safety notes in [Section 7.1, “Safety notes for mounting and removal”](#).
- If necessary, disconnect the wiring as shown in [Section 8.6, “Removing cables from the terminal point”](#).
- Replace the Axioline F module in your application with a new Axioline F module. See [Section 7.7, “Replacing a module”](#).
- If necessary, connect the supply and the I/O devices. See [Section 8, “Connecting or removing cables”](#).

#### Observe the device type and version

The new module must meet the following requirements:

- Same device type
- Same or later version

### 14.2 Device defect and repair

#### Do not open the housing

Repairs may only be carried out by Phoenix Contact. Do not open the housing. If the housing is opened, the function of the device can no longer be ensured.

#### Defective devices

- Please contact Phoenix Contact.

# 15 Maintenance, decommissioning, and disposal

## 15.1 Maintenance

Axioline F modules are maintenance free.

## 15.2 Decommissioning and disposal

Carry out decommissioning according to the requirements of the machine or system manufacturer.

When decommissioning, ensure the following for the Axioline F modules used:

**The device continues to be used only as intended:**

- Observe the storage and transport requirements.  
See [Section "Transport, storage, and unpacking" on page 52](#).

**The device is not used any more:**

### Device disposal



The symbol with the crossed-out trash can indicates that this item must be collected and disposed of separately from other waste. Phoenix Contact or public collection sites will take the item back for free disposal. For information on the available disposal options, visit [phoenixcontact.com](https://www.phoenixcontact.com). Collect and dispose of included batteries separately from other waste. Delete personal data before returning the item.

### Packaging disposal

- Dispose of packaging materials that are no longer needed (cardboard packaging, paper, bubble wrap sheets, tubular bags, etc.) with household waste in accordance with the currently applicable national regulations.



Please also follow the disposal instructions in the user documentation for each device.

## 16 Technical data and ordering data



### Observe additional documentation

For the system data of your network, refer to the corresponding documentation.

If you are using Axioline F in a system with other product groups, also observe the technical data for these product groups. For this technical data, refer to the associated documentation.

For safety applications, refer to the documentation for the safety modules used.

Please refer to the associated documentation when using an AXC controller.



The following values are standard values for the preferred mounting position (wall mounting on horizontal DIN rail).

**For different values, refer to the module-specific documentation.**

The technical data does not claim to be complete. Technical modifications reserved.

### 16.1 Technical data

#### System data

Number of devices supported in an Axioline F station      63 devices, maximum



Each Axioline F module and each Axioline Smart Element is a device.

Maximum current consumption of the Axioline F modules      See module-specific data sheet



When configuring an Axioline F station, observe the communications power supply through the bus coupler, the controller or the power module, as well as the current consumption of each device. This data may vary depending on the module and is given in the module-specific documentation. Create a new station or install a power module for the communications power if the maximum current consumption at  $U_{BUS}$  is reached. In addition, the maximum number of devices may be limited by the controller/bus coupler system data. Observe the information in the module-specific documentation.

Use the Project+ configuration software to calculate the individual process or parameter data and the corresponding number of devices that can be connected.

It can be found at: [phoenixcontact.com/product/2688394](https://phoenixcontact.com/product/2688394).

See also [Section "Maximum number of modules" on page 58](#).



**General data (standard values; for deviations see module-specific documentation)**

Ambient temperature

Ambient temperature (operation)	-25°C ... +60°C
Ambient temperature (operation) for XC versions	-25°C ... +60°C (standard; if the respective approvals are available: Applications with UL approval, use in potentially explosive areas (see module-specific data sheet)) -40°C ... +70°C (extended, see <a href="#">Section “Tested successfully: use under extreme ambient conditions” on page 28</a> and information in the module-specific data sheet)
Ambient temperature (storage/transport)	-40°C ... +85°C
Temperature change	5 K/min (no condensation permitted)
Permissible humidity (operation/storage/transport)	5% ... 95% (non-condensing)
Permissible air pressure (operation/storage/transport)	70 kPa ... 106 kPa (up to 3000 m above sea level) Higher than 3000 m above mean sea level: see <a href="#">Appendix B 1 “Use of Axioline F modules at an elevation of more than 3000 meters” on page 157</a> .
Degree of protection	IP20
Protection class	Extra-low voltage: III, IEC 61140, EN 61140, VDE 0140-1 Low voltage, mounted in an adequate housing with at least IP54 protection: II, IEC 61140, EN 61140, VDE 0140-1
Air clearances and creepage distances	Extra-low voltage: according to EN 60664-1 Low voltage: according to EN 61010-2-201
Housing material	Plastic, self-extinguishing (V0)
Pollution degree	Extra-low voltage: 2, IEC 60664-1, EN 60664-1 Low voltage: 2, IEC 61010-2-201, EN 61010-2-201
Overvoltage category	Extra-low voltage: II, IEC 60664-1, EN 60664-1 Low voltage: III, EC 61010-2-201, EN 61010-2-201



Do not use the device in an atmosphere that contains corrosive gas.

**Mechanical tests (standard values; for deviations see module-specific documentation)**

Vibration resistance according to EN 60068-2-6/ IEC 60068-2-6	5g
Shock testing according to EN 60068-2-27/IEC 60068-2-27	30g
Bump endurance test according to EN 60068-2-27/ IEC 60068-2-27	10g

**Conformance with EMC Directive 2014/30/EU  
(for deviations and detailed values see module-specific documentation)**

**Immunity test according to EN IEC 61000-6-2**

Electrostatic discharge (ESD) IEC 61000-4-2	Criterion B
--	-------------

Electromagnetic fields IEC 61000-4-3	Criterion A
---	-------------

Fast transients (burst) IEC 61000-4-4	Criterion B
--	-------------

Transient overvoltage (surge) IEC 61000-4-5	Criterion B
--	-------------

Conducted interference IEC 61000-4-6	Criterion A
---	-------------

**Axioline F modules:**

<b>Noise emission test according to EN IEC 61000-6-3</b>	Class B
--	---------

<b>Axioline F backplane Noise emission test according to EN IEC 61000-6-4</b>	Class A
---	---------



The Axioline F backplanes and the Axioline Smart Elements to be inserted into the backplanes are a class A product.  
The noise emission meets the requirements for industrial environments.

- Note this when combining products approved for residential environments.
- Observe the requirements for noise emission for electrical and electronic equipment (EN IEC 61000-4-6).
- Implement appropriate precautions against noise emission.

**Low-voltage modules: developed according to IEC 61850-3  
(for deviations and detailed values see module-specific documentation)**

Electrostatic discharge (ESD) IEC 61000-4-2	Criterion A
--	-------------

Electromagnetic fields IEC 61000-4-3	Criterion A
---	-------------

Fast transients (burst) IEC 61000-4-4	Criterion A
--	-------------

Transient overvoltage (surge) IEC 61000-4-5	Criterion A
--	-------------

Conducted interference IEC 61000-4-6	Criterion A
---	-------------

Immunity against magnetic fields IEC 61000-4-8	300 A/m continuous, 1000 A/m for 1 s
---	--------------------------------------

Immunity against attenuated oscillating magnetic fields IEC 61000-4-10	100 A/m
---	---------

**Low-voltage modules: developed according to IEC 61850-3  
(for deviations and detailed values see module-specific documentation)**

 Immunity to conducted common mode interference,  
IEC 61000-4-16

30 V continuous, 300 V for 1 s

 Attenuated oscillating waves  
IEC 61000-4-18

1 kV symmetrical, 2.5 kV asymmetrical

**Noise emission test according to  
EN IEC 61000-6-3**

Class B

**Interface for Axioline F local bus**

Connection method

Bus base module, backplane

Transmission speed

100 Mbps

**24 V supply ( $U_L$ ,  $U_I$ ,  $U_O$ ,  $U_{IO}$ ,  $U_A$ ,  $U_P$ )**

Nominal voltage

24 V DC

Ripple

 $\pm 5\%$ 

Maximum permissible voltage range

19.2 V DC ... 30.0 V DC (all tolerances included, ripple included)

Connection

 Axioline F connector (Axioline F modules)  
Terminal points of the backplane (Axioline F backplane)


The Axioline F local bus supply (communications power)  $U_{BUS}$  is generated from communications power  $U_L$  (24 V).

**Axioline F local bus supply (supplies the bus logic of the connected modules)**

Comment

The communications power  $U_L$  is supplied on the bus coupler, controller or power module for the communications power.

The communications power  $U_{BUS}$  is generated from this communications power  $U_L$  and distributed over the bus base modules. These two voltages are not electrically isolated.

The current through the local bus  $I_{BUS}$  is short-circuit proof.

Connection

Bus base module, backplane

 Communications power ( $U_{BUS}$ )

5 V DC

 Maximum load current in the local bus ( $I_{BUS}$ )

See controller, bus coupler or power module documentation

**Voltage dips and interruptions of the I/O supply**

Degree of severity PS1

Interrupt time &lt;1 ms

Time interval between voltage dips

&lt;1 s

Behavior

Criterion A

A supply voltage dip of <1 ms has no effect.

Degree of severity PS2

Interrupt time &lt;10 ms

### Voltage dips and interruptions of the I/O supply [...]

Time interval between voltage dips	<1 s
Behavior	Criterion C Bus disconnection, all system outputs are reset.



Die IEC 61131-2 requires power failure protection of 10 ms. To meet this requirement, use only power supply units (230 V AC / 24 V DC, 400 V AC / 24 V DC) that support mains buffering for at least 10 ms.

### Axioline F connector/connection method/cable cross sections



For electrical and/or thermal reasons, it may not be possible to use the minimum conductor cross sections specified here for certain modules. Therefore, always observe the information in the module-specific documentation.

Designation	Axioline F connector
Connection method	Push-in connection
Maximum load capacity of the contacts	8 A
Cable cross section (typical)	0.2 mm <sup>2</sup> ... 1.5 mm <sup>2</sup> ; AWG 24 ... 16 See <a href="#">Section "Conductor cross sections and stripping and insertion lengths" on page 71</a>
Stripping lengths	8 mm or 10 mm; See <a href="#">Section "Conductor cross sections and stripping and insertion lengths" on page 71</a>

### Terminal points of the Axioline F backplane/connection method/cable cross section

Designation	Terminal points of the Axioline F backplane
Connection method	Push-in connection
Maximum load capacity of the contacts	16 A
Cable cross section (typical)	0.5 mm <sup>2</sup> ... 2.5 mm <sup>2</sup> ; AWG 20 ... 14 See <a href="#">Section "Conductor cross sections and stripping and insertion lengths" on page 118</a>
Stripping lengths	8 mm or 10 mm; See <a href="#">Section "Conductor cross sections and stripping and insertion lengths" on page 118</a>

### Electrically isolated areas

See module-specific documentation

**Test voltages (standard values for the 24 V area;  
for deviations and low-voltage area see module-specific documentation)**



For information about the test voltages between the network and other potential areas, refer to the documentation for the bus coupler.

Isolating distance	Test voltage
Logic / I/O supply	500 V AC, 50 Hz, 1 min
Logic/functional ground	500 V AC, 50 Hz, 1 min
I/O supply/functional ground	500 V AC, 50 Hz, 1 min

**Approvals**

For the latest approvals, please visit [phoenixcontact.com/products](https://phoenixcontact.com/products).

## 16.2 Ordering data

### Ordering data for the Axioline F modules

For the ordering data for the Axioline F modules, refer to the module-specific documentation.

It is also available on the Internet at [phoenixcontact.com/products](http://phoenixcontact.com/products).

### Ordering data for accessories


Description	Type	Order No.	Pcs./Pkt.
<b>Tool</b>			
Screwdriver, slot-headed, VDE-insulated, size: 0.4 x 2.5 x 80 mm, 2-component handle, with non-slip grip	SZS 0,4X2,5 VDE	1205037	1
Crimping pliers, for ferrules without insulating collar according to DIN 46228 Part 1 and ferrules with insulating collar according to DIN 46228 Part 4, 0.25 mm <sup>2</sup> ... 6.0 mm <sup>2</sup> , lateral entry, trapezoidal crimp	CRIMPFOX 6	1212034	1
Crimping pliers, type of contact: Insulated and uninsulated ferrules, standards/specifications: DIN 46228-1, DIN 46228-4, min. cross section: 0.14 mm <sup>2</sup> , max. cross section: 10 mm <sup>2</sup> , for TWIN ferrules up to 2 x 4 mm <sup>2</sup> , automatic cross section adjustment, rotating die, lateral and frontal insertion, compression: Trapezoidal crimp, black/green	CRIMPFOX DUO 10	1031721	1
Crimping pliers, type of contact: Insulated and uninsulated ferrules, standards/specifications: DIN 46228-1, DIN 46228-4, min. cross section: 0.14 mm <sup>2</sup> , max. cross section: 10 mm <sup>2</sup> , For TWIN ferrules up to 2 x 4 mm <sup>2</sup> , automatic cross section adjustment, frontal insertion, compression: Trapezoidal crimp, black	CRIMPFOX 10T-F	1134913	1
Measuring probes	MPS-MT 1-S4-B RD	1982800	50
<b>Marking material (Axioline F modules)</b>			
Zack marker strip for Axioline (device marking), in 2 x 20.3 mm pitch, unprinted, 25-section, for individual marking with B-STIFT 0.8, X-PEN, or CMS-P1-PLOTTER	ZB 20,3 AXL:UNPRINTED	0829579	25
Zack marker strip flat for Axioline (connector/slot marking), in 1 x 5.8 mm + 4 x 10.0 mm pitch, unprinted, 50-section, for individual marking with B-STIFT 0.8, X-PEN, or CMS-P1-PLOTTER	ZBF 10/5,8 AXL:UNPRINTED	0829580	50
Zack marker strip, unprinted: 10-section, for individual marking with B-STIFT, ZB-T or CMS system, enough to mark 100 terminal blocks, for terminal block width of 10.2 mm, color: white	ZB 10:UNBEDRUCKT	1053001	10 strips, each with 10 markers
Zack marker strip, flat, unprinted: 10-section, for individual marking with B-STIFT or ZBF T, for 100 terminal blocks, color: white	ZBF 5:UNBEDRUCKT	0808642	10 strips, each with 10 markers

Description	Type	Order No.	Pcs./Pkt.
Insert label, roll, white, unmarked, can be marked with: THERMOMARK ROLL, THERMOMARK ROLL X1, THERMOMARK X, THERMOMARK S1.1, mounting type: snapped into marker carrier, lettering field size: 35 x 28 mm (for H housing)	EMT (35X28)R	0801602	500 individual labels
Insert label, roll, white, unmarked, can be marked with: THERMOMARK ROLL, THERMOMARK ROLL X1, THERMOMARK X, THERMOMARK S1.1, mounting type: snapped into marker carrier, lettering field size: 35 x 46 mm (for F housing)	EMT (35X46)R	0801604	500 individual labels
Insert label, roll, white, unmarked, can be marked with: THERMOMARK ROLL, THERMOMARK ROLL X1, THERMOMARK X, THERMOMARK S1.1, mounting type: snapped into marker carrier, lettering field size: 35 x 18.7 mm (for BK housing)	EMT (35X18,7)R	0801831	500 individual labels
<b>Marking material (Axioline F backplane)</b>			
Markers, 24-section, unmarked, can be marked with THERMOMARK CARD and BLUEMARK, color: white (marking)	UM6M-TM (5X12)	0830928	10
Markers, sheet, white, unmarked, can be marked with: THERMOMARK CARD, THERMOMARK CARD 2.0, THERMOMARK PRIME, BLUEMARK ID, BLUEMARK ID COLOR, TOPMARK LASER, TOPMARK NEO, mounting type: snap into a high marker groove, for terminal block width: 5.2 mm, lettering field size: 4.17 x 11.3 mm (marking)	UCT6M-TM 5	0830756	10
Label, continuous, cassette, transparent with black imprint, mounting type: adhesive, can be marked with THERMO-FOX	MM-TML (EX4,2)R C1 TR/BK	0803979	1
Marker strip, roll, white, unmarked, can be marked with: THERMOMARK ROLL 2.0, THERMOMARK ROLL, THERMOMARK ROLL X1, THERMOMARK ROLLMASTER 300/600, THERMOMARK X1.2, mounting type: adhesive, for terminal block width: 5 mm, lettering field size: continuous x 5 mm	SK 5,0 WH:REEL	0805221	1
<b>Mounting material</b>			
Patch cable, CAT6, pre-assembled, different lengths	FL CAT6 PATCH ...		
Power supplies	QUINT-PS ...		
DIN rail, perforated/unperforated, 2 meters (corresponds to TH 35-7.5 according to EN 60715)	NS 35/ 7,5 PERF 2000MM NS 35/ 7,5 UNPERF 2000MM	0801733 0801681	
Standard end bracket, snapped on without tools	CLIPFIX 35-5	3022276	50
End bracket for use in the event of vibrations or installation on vertical DIN rail; to be secured with screws	E/AL-NS 35	1201662	50

**UM EN AXL F SYS INST**

Description	Type	Order No.	Pcs./Pkt.
<b>Ferrules</b>			
Ferrules with insulating collar (plastic collar), according to DIN 46228-4; sleeve length: 8 mm	Al ...		
Cross section 0.5 mm <sup>2</sup>	Al 0,5 - 8 WH -1000	3200881	1000
Cross section 0.75 mm <sup>2</sup>	Al 0,75- 8 GY -1000	3200894	1000
Cross section 1.0 mm <sup>2</sup>	Al 1 - 8 RD -1000	3200904	1000
Ferrules without insulating collar (plastic collar), according to DIN 46228-1; sleeve length: 8 mm	A ...		
Cross section 0.5 mm <sup>2</sup>	A 0,5 - 8	3202481	1000
Cross section 0.75 mm <sup>2</sup>	A 0,75- 8	3202504	1000
Cross section 1.0 mm <sup>2</sup>	A 1 - 8	3202517	1000
Ferrules with insulating collar (plastic collar), according to DIN 46228-4; sleeve length: 10 mm	Al ...		
Cross section 0.5 mm <sup>2</sup>	Al 0,5 -10 WH	3201275	100
Cross section 0.75 mm <sup>2</sup>	Al 0,75-10 GY	3201288	100
Cross section 1.0 mm <sup>2</sup>	Al 1 -10 RD	3200182	100
Cross section 1,5 mm <sup>2</sup>	Al 1,5 -10 BK	3200195	100
Ferrules without insulating collar (plastic collar), according to DIN 46228-1; sleeve length: 10 mm	A ...		
Cross section 0.5 mm <sup>2</sup>	A 0,5 -10	3202494	1000
Cross section 0.75 mm <sup>2</sup>	A 0,75-10	3200234	1000
Cross section 1.0 mm <sup>2</sup>	A 1 -10	3200250	1000
Cross section 1,5 mm <sup>2</sup>	A 1,5 -10	3200276	1000



Description	Type	Order No.	Pcs./Pkt.
<b>Material for shield connection</b>			
<div>  Please observe the available space when selecting the shield connection clamps. </div>			
Axiline shield connection set (contains 2 shield bus holders and 2 SK 5 shield clamps)	AXL SHIELD SET	2700518	1
Shield connection clamp for applying the shield on busbars; automatic fixing with spring	SKS ...		
3 mm ... 8 mm diameter	SKS 8	3240210	10
3 mm ... 14 mm diameter	SKS 14	3240211	10
5 mm ... 20 mm diameter	SKS 20	3240212	10
Shield connection clamp for applying the shield on busbars; to be secured with screw	SK ...		
8 mm diameter	SK 8	3025163	10
14 mm diameter	SK 14	3025176	10
20 mm diameter	SK 20	3025189	10
35 mm diameter	SK 35	3026463	10
Support bracket (on mounting plate or for busbar)	AB		
Neutral busbar, 10 mm x 3 mm, 1 m long	NLS-CU 3/10 SN 1000 MM	0402174	1
Connection terminal block, connection method: screw connection, load current: 41 A, cross section: 0.5 mm <sup>2</sup> - 6 mm <sup>2</sup> , width: 7 mm, color: silver	AK 4	0404017	50
<b>Cable for connecting PLC relays</b>			
System cable for eight channels	CABLE-FLK14/AXIO/OE/0,14/..		
Cable length: 1 m	CABLE-FLK14/AXIO/OE/0,14/1,0M	1369897	
Additional cable lengths	CABLE-FLK14/AXIO/OE/0,14/...		
<b>Connecting cable</b>			
Connecting cable, for connecting the controller to a PC for PC Worx and LOGIC+, USB A to micro USB B, 2 m in length.	CAB-USB A/MICRO USB B/2,0M	2701626	
Connecting cable, for connecting the controller to a PC from USB A to USB C	CAB-USB A/ USB C/1,8M	2404677	
Connecting cable, for connecting the controller to a PC from USB C to USB C	CAB-USB C/ USB C/1,8M	1021809	

Ordering data for documentation

Description	Type	Order No.	Pcs./Pkt.
"Axioline F: diagnostic registers, and error messages" user manual	UM EN AXL F SYS DIAG	–	–



The comprehensive documentation listed above and all module-specific documentation can be downloaded at [phoenixcontact.com/products](https://phoenixcontact.com/products).  
Make sure you always use the latest documentation.

# A Technical appendix: communication objects (PDI objects)

Communication objects are stored on each module. You can access these objects with read, write or read and write services via the PDI channel.

In most cases, the objects are accessed automatically, e.g., when writing the start parameterization during the startup of the bus coupler or the controller.


The objects created in a module are:

- General standard objects (index 0001<sub>hex</sub> to 003D<sub>hex</sub>)  
For more detailed information on these objects, please refer to [Section “General standard objects” on page 144](#).
- Manufacturer-specific application objects (index 0080<sub>hex</sub> to 5FFF<sub>hex</sub>, FF8F<sub>hex</sub>)  
These objects have device-specific variables.  
For more detailed information on these objects, please refer to the documentation for the module.

Table A-1 Object types

Object type	Meaning
Var	Object with only one element (simple variable)
Array	Object with several simple variables of the same data type with the same length
Record	Object with several simple variables of different data types or the same data type with different lengths

Table A-2 Data types

Data type	Meaning
Visible string	<p>Byte string only with printable ASCII characters The byte string finishes with 00<sub>hex</sub> (null-terminated) or is filled with 00<sub>hex</sub> to reach the total length.</p> <div>  <p>In the following tables and the module-specific data sheets, only the pure user data is provided in the “Content” column. Null termination and filling up a visible string with 00<sub>hex</sub> is not shown.</p> </div>
Bit string	Bit strings always have a length of n x 8 bits, where n ∈ N (n element of the natural numbers).
Octet string	Byte string with any contents
Unsigned 8	UINT8 Value without sign, only positive values 00 <sub>hex</sub> ... FF <sub>hex</sub>
Unsigned 16	UINT16 Value without sign, only positive values 0000 <sub>hex</sub> ... FFFF <sub>hex</sub>
Unsigned 32	UINT32 Value without sign, only positive values 0000 0000 <sub>hex</sub> ... FFFF FFFF <sub>hex</sub>

The following applies for the tables below:

Table A-3 Key for the following tables

Abbreviation	Meaning
Length in bytes	Maximum length of the elements in bytes
R	Read
W	Write
[x]	Number of elements in an array or record

## A 1 General standard objects

The standard objects include:

- Objects for identification (device rating plate)
- Objects for device diagnostics
- Objects for process data management
- Objects for device management
- Object with object descriptions
- Objects for modular devices and subsystems



Certain objects are optional, which means that not every object is implemented on every module. Information on which object is supported by a particular module is available in the module-specific data sheet.

### A 1.1 Objects for identification

These objects describe the manufacturer, the device, and device application and form the device rating plate

The bold entries in [Table A-4](#) are identical for all Axioline F modules and Axioline Smart Elements from Phoenix Contact. All other entries may vary depending on the individual module.

Table A-4 Objects for identification (device rating plate) according to basic profile V3.0

Index [hex]	Object name	Data type	Length in bytes	Rights	Meaning	Content/example
<b>Manufacturer</b>						
0001	VendorName	Visible string	32	R	Manufacturer name	<b>PHOENIX CONTACT</b>
0002	VendorID	Visible string	7	R	Manufacturer ID	<b>00A045</b>
0003	VendorText	Visible string	58	R	Manufacturer text	<b>Components and systems for industrial automation</b>
0012	VendorURL	Visible string	58	R	Manufacturer URL	<b>www.phoenixcontact.com/qr/&lt;item no.&gt;</b>

Table A-4 Objects for identification (device rating plate) according to basic profile V3.0 [...]

Index [hex]	Object name	Data type	Length in bytes	Rights	Meaning	Content/example
<b>Module - general</b>						
0004	DeviceFamily	Visible string	58	R	Device family	... (e.g., I/O analog IN)
0006	Product family	Visible string	32	R	Product family	<b>AXL F, AXL F XC or AXL SE</b>
000E	CommProfile	Visible string	5	R	Communication profile	633
000F	DeviceProfile	Visible string	5	R	Device profile	0010
0011	ProfileVersion	Record [2]	30	R	Profile version	
.1	BuildDate	Visible string	11	R	Version date	2018-04-19
.2	Version	Visible string	19	R	Version ID	Basic profile V3.0
0017	Language	Record [2]	56, max.	R/W	Language	<b>en-us; English</b>
<b>Module - specific (for a specific module)</b>						
0005	Capabilities	Array [N] of octet strings	N * 8	R	Device properties	... (e.g., Nothing) See <a href="#">Table A-5</a>
0007	ProductName	Visible string	32	R	Product name	... (e.g., AXL F AI4 I 1H, AXL SE AI4 I 4-20)
0008	SerialNo	Visible string	22	R	Serial number	xxxxxxxxxx (e.g., 12345123456)
0009	ProductText	Visible string	58	R	Product text	... (e.g., 4 analog input channels)
000 A	OrderNumber	Visible string	32	R	Order No.	xxxxxxx (e.g., 2688491)
000B	Hardware version	Record [2]	22	R	Hardware version	
.1	BuildDate	Visible string	11	R	Manufacturing date	YYYY-MM-DD
.2	Version	Visible string	11	R	Version ID	xxx (e.g., 01)
000C	FirmwareVersion	Record [2]	22	R	Firmware version	
.1	BuildDate	Visible string	11	R	Manufacturing date	YYYY-MM-DD
.2	Version	Visible string	11	R	Version ID	xxx (e.g., --, 1.10)
000D	PChVersion	Record [2]	22	R	Parameter channel version	
.1	BuildDate	Visible string	11	R	Manufacturing date	YYYY-MM-DD
.2	Version	Visible string	11	R	Version ID	xxx (e.g., 2016-12-01, PDI V1.10)
0037	DeviceType	Octet string	8	R	Device type	xx xx xx xx xx xx xx xx <sub>hex</sub> (e.g., 00 20 00 08 00 00 00 A6 <sub>hex</sub> )

Table A-4 Objects for identification (device rating plate) according to basic profile V3.0 [...]

Index [hex]	Object name	Data type	Length in bytes	Rights	Meaning	Content/example
003 A	VersionCount	Array [4] of UINT16	8	R	Version counter; unique consecutive numbering for the version of the corresponding component	E.g., 0009 0002 0001 0117
.1	ProfileVersion	UINT16	2	R	0009 for basic profile V3.0	xx xx <sub>hex</sub> (e.g., 0009)
.2	PChVersion	UINT16	2		PDI version	xx xx <sub>hex</sub> (e.g., 0002)
.3	Hardware version	UINT16	2		Hardware version e.g., HW 01	xx xx <sub>hex</sub> (e.g., 0001)
.4	Firmware version	UINT16	2		Firmware version e.g., FW 1.17	xx xx <sub>hex</sub> (e.g., 0117)
<b>Use of the device</b>						
0014	Location	Visible string	58	R/W	Installation location	... (e.g., Please fill in ... ); Can be filled in by the user.
0015	Equipment Ident	Visible string	58	R/W	Equipment ID	... (e.g., Please fill in ... ); Can be filled in by the user.
0016	ApplDevice Addr	UINT16	2	R/W	Application-specific device address	... (e.g., Please fill in ... ); Can be filled in by the user.

**Properties (0005<sub>hex</sub>: Capabilities)**

This object indicates the properties and functions the device has in addition to the basic functions. At the moment, the following properties exist:

Table A-5 Properties

Content	Meaning
Nothing	No additional functions
Safety0	The slave supports secure data communication. This takes place in both directions.
Energy0	The slave supports energy management.
SubMA_0	The slave is a subbus master. There is at least one additional subsystem below this slave.
FwUpdt0	The slave supports the firmware update. Currently, only the Phoenix Contact Service can perform a firmware update.
Syncl_0	The slave supports synchronization of the inputs.
SyncO_0	The slave supports synchronization of the outputs.

## A 1.2 Objects for diagnostics

These objects describe the diagnostic state of the device and any connected I/O devices, as well as options for resetting diagnostics.

For the specific content of these objects, refer to the module-specific data sheet.

### A 1.2.1 Diagnostic state (0018<sub>hex</sub>: DiagState)



Read off all information via sub-index 00 to receive all information on an error number. Access to individual elements of the object is not permitted.

Table A-6 Objects for diagnostics: diagnostic state (read) **according to basic profile V2.x**

0018 <sub>hex</sub> : DiagState (Read)					
Index [hex]	Object name	Data type	Length in bytes	Meaning	
0018	DiagState	Record [6]	58, max.	Diagnostic state	Complete diagnostic information
.1	Consecutive no.	UINT16	2	Error number	0 ... 65535 <sub>dec</sub> Unique, consecutive number since the last power-up reset or the last reset of the diagnostics counter
.2	Priority	UINT8	1	Priority	Priority of the message, 1: highest priority. See <a href="#">Table A-9 on page 150</a> 00 <sub>hex</sub> No error 01 <sub>hex</sub> Error 02 <sub>hex</sub> Warning 81 <sub>hex</sub> Error eliminated 82 <sub>hex</sub> Warning eliminated 83 <sub>hex</sub> Information
.3	Channel/ Group/ Module	UINT8	1	Channel/ group/ module	Channel, group or module where the error occurred. Additional information under "Additional information". 00 <sub>hex</sub> No error xx <sub>hex</sub> Channel xx, groupxx or module xx FF <sub>hex</sub> Entire device
.4	Code	Octet string	2	Error code	

Table A-6 Objects for diagnostics: diagnostic state (read) **according to basic profile V2.x**

0018 <sub>hex</sub> : DiagState (Read)					
Index [hex]	Object name	Data type	Length in bytes	Meaning	
.5	MoreFollows	Bit string 8	1	Additional Information	Additional information on malfunction
					00 <sub>hex</sub> Subindex 3 refers to a channel number.
					04 <sub>hex</sub> Subindex 3 refers to a group number.
					08 <sub>hex</sub> Subindex 3 refers to a module number.
					Other Currently not used.
.6	Text	Visible string	max. 51	Text	Plain text message. Default: status OK

Table A-7 Objects for diagnostics: diagnostic state (read) **according to basic profile V3.x**

Index [hex]	Object name	Data type	Length in bytes	Meaning	
0018	DiagState	Record [11]	123, max.	Diagnostic state	Current diagnostic state of the device in short form
.01	Consecutive no.	UINT16	2	Consecutive number	0 ... 65535 <sub>dec</sub> Unique, consecutive error number since the last power up or error memory reset
.02	Priority	UINT8	1	Priority	Fault priority. 1: highest priority. See <a href="#">Table A-9 on page 150</a>
					00 <sub>hex</sub> No error
					01 <sub>hex</sub> Error
					02 <sub>hex</sub> Warning
					81 <sub>hex</sub> Error eliminated
					82 <sub>hex</sub> Warning eliminated
					83 <sub>hex</sub> Information
.03	Channel	UINT8	1	Channel	Channel on which the error occurred
					00 <sub>hex</sub> No error
					xx <sub>hex</sub> Channel xx, groupxx or module xx
					FF <sub>hex</sub> Entire device
.04	Code	Octet string	2	Error code	
.05	MoreFollows	Bit string 8	1	Additional Information	Information for interpreting the following data (see <a href="#">Table A-8</a> )
.06	Reserved	Octet string	2	Reserved	(= 0000 <sub>hex</sub> )
.07	SubModNo	UINT8	1	Submodule number	If the device is a modular device, the corresponding submodule is specified here. If the device is not a modular device, "0" is entered here.



Table A-7 Objects for diagnostics: diagnostic state (read) **according to basic profile V3.x [...]**

Index [hex]	Object name	Data type	Length in bytes	Meaning	
.08	Function Group	Octet string	8	Function group	Short designation of the function that report a diagnosis. E. g.: DI (0x44, 0x49, 0x00, 0x00, 0x00, 0x00, 0x00, 0x00) RTD (0x52, 0x54, 0x44, 0x00, 0x00, 0x00, 0x00, 0x00) AI, AO, DO, IOL, CNT, INC, RS485, PSDI, PSDO, SC  The manufacturer-specific designation (e.g., "Relay OUT") is specified in the diagnostic text (0x0018.11).
.09	AddValue	Octet string	4	Additional information	"Additional value" regarding the current diagnostic state of the device.
.0A	TextLength	UINT8	1	Text length	Length of the following diagnostic text in bytes.
.0B	Text	Visible string	100, max.	Diagnostic text	Device-specific explanation of the malfunction that occurred.  Information includes: – Type of the error – Function group or channel – Terminal point – Option for action for the user  Default: "Status OK"  The string is terminated 00 <sub>hex</sub> .

Table A-8 Index 5: additional information

Byte/bit	Value	Meaning
Byte	00 <sub>hex</sub>	No additional information
Bit 0	1	There is additional information on this fault . That can be read via the object E800 <sub>hex</sub> "Diag-StateLong" (if implemented).
Bit 1 ... 3	0	Reserved
Bit 4	1	There are additional "simultaneously occurring diagnostic events". That can be read via the object E806 <sub>hex</sub> "ComplDiagState" (if implemented).
Bit 5 ... 6	0	Reserved
Bit 7	1	Indication that this is an extended version of object 0018 <sub>hex</sub> (compared to version V2.x).

Table A-9 Classification of the error messages

Priority		Message type	Example	Note
01 <sub>hex</sub>	High	Error (fault, alarm)	Supply voltage faulty Parameter table invalid	An error is present, which must be responded to.  A fault leads e.g., to an activity in the drive, but does not necessarily require the system to be stopped with immediate effect.
02 <sub>hex</sub>	Medium	Warning	Limit value not reached or exceeded	Risk of error. A warning does not require action to be taken in the device.
83 <sub>hex</sub>	Low	Information (message, notification)	General operating message: 10000 operating hours have elapsed.	



Diagnostic object 0018<sub>hex</sub> is implemented with a storage depth of 1.

This means that:

- A higher priority message overwrites a lower priority message.
- Lower priority messages are not indicated if a higher priority message is already present.

### A 1.2.2 Handling diagnostic messages (0019<sub>hex</sub>: ResetDiag)

Table A-10 Objects for diagnostics: Handling diagnostic messages (write)

Index [hex]	Object name	Data type	Length in bytes	Meaning
0019	ResetDiag	UINT8	1	Handling diagnostic messages

Table A-11 Value range

Value (hex)	Meaning
00	Permit all diagnostic messages
02	Delete and acknowledge all diagnostic messages that are still pending
05	Delete and acknowledge the last (pending) diagnostic message  Used with safety devices as follows:  If an error is no longer present when this value (05 <sub>hex</sub> ) is written, any “passivated” output is only now released again and also can only now be set again.
06	Delete and acknowledge all diagnostic messages and do not permit new diagnostic messages

### A 1.3 Objects for process data management

The contents for objects implemented on a device are contained in the module-specific documentation.

Table A-12 Objects for process data management

Index [hex]	Object name	Data type	Length in bytes	Rights	Meaning
0024	ResetCode	Array [N] of UINT16	N * 2	R/W	Substitute value behavior during bus reset (PDOOUT)
0025	PDIN	Octet string	Process data length	R	Input process data
0026	PDOOUT	Octet string	Process data length	R	Output process data
002F	PDOOUT_Subst	Octet string	Process data length	R/W	Substitute value for output process data If acceptance of substitute value has been parameterized in 0024 <sub>hex</sub> .
0030	PF_Code	Array [N] of UINT16	N * 2	R/W	Substitute value behavior during I/O error (PDIN)
0031	PDIN_Subst	Octet string	Process data length	R/W	Substitute value for input process data If acceptance of substitute value has been parameterized in 0030 <sub>hex</sub> .

## A 1.4 Objects for device management

Table A-13 Objects for device management (write)

Index [hex]	Object name	Data type	Length in bytes	Rights	Meaning
0029	ParamSet WriteControl	UINT8	1	R/W	Block parameterization control, see <a href="#">“Block parameterization” on page 153</a>
					01 Initiate block parameterization
					00 Terminate block parameterization
					Other Reserved
002A	Conflict Dictionary	Array [N] of records [6]	N * 8	R	Conflict dictionary. Result of block parameterization n = 1 ... N, N = number of dependent parameters, see <a href="#">“Conflict dictionary” on page 154</a>
.01	ConfGrNo_n	UINT8	1	R	Conflict group number of the nth dependent parameter
.02	Subslot_n	UINT8	1	R	Subslot of the nth dependent parameter
.03	Index_n	UINT16	2	R	Index of the nth dependent parameter
.04	Subindex_n	UINT8	1	R	Subindex of the nth dependent parameter
.05	Element_n	UINT8	1	R	Element in the record of the nth dependent parameter
.06	AddCode_n	UINT16	2	R	Additional information on the nth dependent parameter
002B	ParamSet	UINT16	2	R/W	Select parameter record
002D	ResetParam	UINT8	1	R/W	Reset parameterization
					00 No action
					01 Reset application parameters to default values (application objects and selected standard objects)
					Other Reserved
002E	ParamHash	UINT32	4	R	Hash value, see <a href="#">“Hash value” on page 154</a>
0040	ListOfObj ToRestore	Array [N] of records	N * 3	R	List of objects to be restored List of objects to be read and backed up from this device in order to restore the parameterization for the substitute device in the event of a device being replaced.
0048	PChMaxResp Time	UINT16	2	R	Maximum permissible PDI response time in ms Default: 01F4 <sub>hex</sub> (500 ms)

**A 1.4.1 Block parameterization**

Block parameterization serves to enable the joint transfer of interdependent parameters. If you attempt to parameterize dependent parameters individually, this may result in the error message "Dependency of other parameter not taken into consideration". Block parameterization should be used in this case.

The plausibility check for the parameterization data is disabled during block parameterization, the data is only stored temporarily. However, the data length and subindex are checked.

The plausibility check is only performed when block parameterization is terminated with data item 00<sub>hex</sub>.

If the check was completed with no errors, the temporarily stored parameterization data is applied and stored in the flash memory.

If errors were detected in the temporarily stored parameterization data, the service is acknowledged negatively with 08, 00, 0040<sub>hex</sub>.

The exact cause of the error can be read in object 002A<sub>hex</sub>.

Not all startup objects have to be written.

The following actions are carried out when the parameter contents are modified:

**Write control changes from 00<sub>hex</sub> to 01<sub>hex</sub>:  
initiation of block parameterization**

- Block parameterization is initiated
- Conflict dictionary is reset

**Write control changes from 01<sub>hex</sub> to 00<sub>hex</sub>:  
termination of block parameterization**

- Block parameterization is terminated
- Individual parameterization is active
- Parameterization is checked for compatibility

Parameters are compatible:

- The parameter contents are accepted.
- Write access to the write control parameter is acknowledged positively.

Parameters are not compatible:

- The old contents of all the parameters required for block parameterization remain in effect.
- The conflict dictionary is updated.
- Write access to the write control parameter is acknowledged negatively.

Error code in the event of negative acknowledgment:

Code (hex)	Additional code (hex)	Meaning	Remedy
0801	0040	Dependent values were not taken into consideration.	Check the parameterization.

In the event of an error, the conflict dictionary contains the indices and additional code for the parameters involved in the conflict.



The block parameterization is permanently stored in the device description files for the module. This means that whenever the module is parameterized using a tool, the block parameterization is automatically launched at the start of parameterization and terminated at the end of parameterization.

To use block parameterization without tools, proceed in the following sequence:

- Initiate block parameterization by writing the value 01<sub>hex</sub> to object 0029<sub>hex</sub>.
- Write the startup parameters that you want to change to the corresponding objects.
- Terminate block parameterization by writing the value 00<sub>hex</sub> to object 0029<sub>hex</sub>.

#### A 1.4.2 Conflict dictionary

The conflict dictionary contains the indices and error messages (additional code) for the parameters involved in the conflict.

##### Block parameterization

With block parameterization, all conflicts within the “parameter block” are listed.

If, after the block parameterization has been completed, you receive a negative response, the plausibility of the parameters has been violated. In this case, the module does not save the parameterized values.

Check and correct the parameterization.

##### Individual parameterization

With individual parameterization, the contents of the conflict dictionary refer to the “last” write access.

Check and correct the parameterization.

#### A 1.4.3 Hash value

The hash value is a unique value that is generated for a specific device and which ensures the integrity of the parameter data. The data of the startup objects is verified with this hash value. The value changes only if an object relevant for startup has been changed. The value is therefore suitable for comparing the parameterization.

## A 1.5 Objects for object descriptions

These objects are only applicable to tools.

Table A-14 Object descriptions

Index [hex]	Object name	Data type	Length in bytes	Rights	Meaning
0038	ObjDescrReq	Record [2]	3	R/W	Object description request
0039	ObjDescr	Record [16]	58, max.	R	Object description

## A 1.6 Objects for energy management

Table A-15 Objects for energy management

Index [hex]	Object name	Data type	Length in bytes	Rights	Meaning
003D	WakeUpTime	UINT16	2	R	Startup time, the period of time (in ms) that elapses between the point at which the supply voltage is switched on, and the time when the system is ready to operate Default: 01F4 <sub>hex</sub> : < 500 ms

## A 1.7 Objects for modular devices

The contents for objects implemented on a device are contained in the module-specific documentation.

Table A-16 Objects for modular devices

Index [hex]	Object name	Data type	Length in bytes	Rights	Meaning
0035	SubBusInfo	Record	16	R	Subbus information
0036	ActSubBusStructure	Array [N] of records	N * 8	R	Actual subbus configuration
0041	RefSubBusStructure	Array [N] of records	N * 8	R/W	Desired subbus configuration
0042	ModuleStatus	Array [N] of bytes	N * 1	R	Module status
0043	SubBusBehaviour	Record	3	R/W	Subbus behavior
0044	SubBusControl	UINT8	1	R/W	Subbus control
0047	AddInfo	Record	16	R	Additional information
00F0	PackedPrm	Record	63, max.	R/W	All startup parameters consecutively; only relevant for PROFIBUS
C000 ... C07F	ProjBasProf				Projection of basic profile onto the subbus modules

## A 2 Manufacturer-specific application objects

Manufacturer-specific application objects are module-specific and are documented in the module-specific documentation.

For example, parameterization of individual channels for analog modules or parameterization of filter times for digital input modules is implemented using these objects.

## A 3 Value ranges

Make sure to observe the permissible value ranges during module parameterization. If invalid values are specified for an object, these are not saved and an error message is generated.

## A 4 Function blocks for access to the objects

Under PLCnext Engineer and PC Worx, you can access the PDI objects via function blocks stored in libraries.

Table A-17 Function blocks

Software	Library	Download at
PLCnext Engineer	AXL_PD	plcnextstore.com
PC Worx	PCW_6_AXL_PDI_2	<a href="https://phoenixcontact.com/product/298538">phoenixcontact.com/product/298538</a>

Detailed documentation is provided as online help for each of the function blocks.

When you access an object that is not implemented, you will receive a corresponding error message.



## B Technical appendix: Altitude, times, synchronization, substitute value behavior, and power-on behavior

### B 1 Use of Axioline F modules at an elevation of more than 3000 meters

This section applies to modules of the Axioline F product group that are operated with a DC voltage of <60 V DC.



**WARNING: Dangerous contact voltage. Loss of safety function.**

This section does **not** apply to the following modules or applications:

- Modules that are not operated with PELV (protective extra-low voltage) (e.g., 120 V or 230 V)
- Modules with safety functions (e.g., SafetyBridge, PROFIsafe)
- Use of a safe signal path
- Use in potentially explosive areas (IECEX, ATEX, hazardous location).
- XC versions

In these cases, consider the individual module or application separately.

The Axioline F modules are approved for use up to an elevation of 3000 m above sea level, see [“Technical data” on page 132](#).

The maximum permissible ambient temperature decreases at elevations above this level. Therefore, keep temperature derating in mind when using the modules at an elevation of more than 3000 m up to 5000 m.




Figure B-1 Derating of the permissible ambient temperature depending on the operating elevation

Key:

T [°C] Maximum ambient temperature (operation) in °C  
h [m] Elevation in m

## B 2 Transmission speed

Within an Axioline F station, communication takes place via a fast, cyclic and time-equidistant local bus. The typical cycle time is less than 50  $\mu\text{s}$ .

## B 3 Typical cycle time on the local bus

The typical cycle time on the local bus is calculated according to the following equation:

$$t = 2 \mu\text{s} + n * 1 \mu\text{s}$$

Where:

t Typical cycle time on the local bus

n Number of modules connected to the bus coupler

The typical cycle time for a station comprising five modules is:

$$t = 2 \mu\text{s} + n * 1 \mu\text{s}$$

$$t = 2 \mu\text{s} + 5 * 1 \mu\text{s}$$

$$t = 7 \mu\text{s}$$

# B 4 Response times in an Axioline F system

In general, the response time in an I/O system is the time from reading in the input, processing in the controller, through to setting the output. This includes the times shown in [Figure B-2](#). They are explained in [Table B-1](#) with example times.




Figure B-2 Response times of the overall system




Figure B-3 Response time  $t_R$  starting from reading in an input (DI) and ending with setting an output (DO)

When determining the response time of the overall system, the Axioline F (no. 1 ... 3) takes up the lowest proportion by far. Therefore, it can normally be ignored. See example values in [Table B-1](#).

Table B-1 Typical processing times in an Axioline F system

No. in Figure B-2	Meaning	Example
1	Processing time in the Axioline F I/O modules (depending on the I/O application)	E.g., <5 µs (AXL F DI16/1 HS 1H) Approx. 150 µs (AXL F DI32/1 1F) Approx. 160 µs (AXL F AI4 I 1H, filter 12 kHz, without mean-value generation) Approx. 33 ms (AXL F AI4 I 1H, filter 30 Hz, without mean-value generation)
2	Cycle time of the Axioline F local bus	Here: 7 µs (see appendix <a href="#">Section B 3</a> , "Typical cycle time on the local bus")
3	Time for copying the data between the local bus and higher-level network in the Axioline F bus coupler	~ 0 µs
4	Update time (cycle time) of the higher-level network	Depending on the higher-level network, e.g., PROFINET with 2 ms
5	Processing time (cycle time) of the controller	E.g., 4 ms
	You also have to take the processing time of the connected sensors and actuators (I/Os) into consideration	E.g., <100 µs

The response time of the overall system depends on the selected Axioline F I/O modules.

When using I/O modules with very low processing times (e.g., digital modules), the response time of the overall system (no. 1 ... 3) represents the smallest proportion by far and can therefore normally be ignored.

However, in time-critical applications with very short application/processing times in the controller, take the processing time in the modules into account as well.

Rule of thumb for applications:

Application/bus cycle time > 2 x module processing time (Nyquist-Shannon sampling theorem)

Table B-2 Terms used

Term	Use e.g., with	Meaning
<b>Processing time</b>		The processing time of an I/O module depends on the device type and can include, for example: <ul style="list-style-type: none"> <li>– Conversion time</li> <li>– Input filter time</li> <li>– Process data update time</li> </ul>
– Conversion time (A/D conversion time, D/A conversion time)	AI, AO	Time needed by the analog-digital or digital-analog converter to convert the signal
– Input filter time (filter time)	DI	Minimization of the effects of contact bouncing
	RTD	Increase in the accuracy of the measurement results
– Process data update time (process data update, update time)	DI, DO AI, AO	Time in which the process data is updated cyclically by the I/O module. The currentness of the values in the process data depends on the conversion time or filter time.



Conversion time, input filter time, and process data update time

If the time is relevant for a module, you will find this in the module-specific data sheet.

Example: AXL F AI4 I 1H with 4-sample mean-value generation

Information from the data sheet 106223\_en\_04:

Analog inputs	
Number of inputs	4
...	...
A/D conversion time	31.25 µs
...	...
Process data update	160 µs
Input filter	30 Hz, 12 kHz and mean value generation (can be parameterized)
...	...





Figure B-4 Transmission of the data from an analog input to the controller

Table B-3 Key for Figure B-4

Transmission of the data from an analog input to the controller	Designation in Figure B-4	Meaning	Information in the AXL F AI4 I 1H data sheet
	Signal (CPU)	Mapping of the signal in the controller	
	CPU	Transfer of the process data into the controller process image In the next controller cycle, the then current process data will be transferred into the controller process image. In the example, this is the mean value of EFGH and the mean value of UVWX.	
	Network	Transfer of the current process data into the network The mean value of ABC will not be transferred, because the mean value of EFGH is already available in the network at the time of the data transfer.	
	Copy time bus coupler	Copy time in the bus coupler is negligible The bus coupler makes the value available to the network.	0 µs
	Local bus	Local bus The local bus adopts the value made available into the process data.	
	Process data update	Process data update During the process data update by the firmware, the last mapped mean value is adopted and made available to the local bus. This value will be made available to the local bus up until the next process data update.	160 µs
	Mean-value: 4-sample	4-sample mean value Mean-value generation from the respective last four values.  The mean-value generation can usually be configured. A 4-sample mean-value generation was selected for the example.	Configurable: 16-sample (default) No mean value 4-sample 32-sample
	A/D conversion time	Conversion time of the analog-digital converter Conversion of the analog input value to the digital value.	31.25 µs
	Filter	Filter of the AI signal, shown qualitatively here	Configurable: 30 Hz (default) 12 kHz
	AI (signal)	Signal at the analog input under consideration	

## B 5 Synchronization



If you want to use the synchronization function, make sure that the following requirements are met simultaneously:

- The bus coupler or controller supports the function.
- There is at least one module in the Axioline F station that supports local bus synchronization.

Only the Axioline F modules that support local bus synchronization can be operated in a synchronous manner. All the other Axioline F modules of the station work in an asynchronous manner.

### B 5.1 Synchronization in general

Some Axioline F modules offer a synchronization option.

To use this property, synchronization must be consistently supported from the clock master in the higher-level network to the I/O modules.




Figure B-5 Network and local bus synchronization

#### Clock master

In the overall system, the clock master is the unit which determines the synchronization times and synchronization time points and sends out a synchronization clock signal. Usually, this is the network controller.

#### Higher-level network

The higher-level network is the communication system which links the controller and the head of the Axioline F station. This network must support synchronization.

The head of an Axioline F station can be a bus coupler or an AXC controller. Currently, only some bus couplers support synchronization.



**Bus couplers**

The bus coupler is the link between the higher-level network and the Axioline F station. It must support synchronization according to the definition of the higher-level network and transfer the synchronization parameters and signals to the Axioline F station.

**Examples of bus couplers which support the synchronization mechanisms for a network**

Table B-4 Synchronization mechanisms of the bus couplers

Network	Bus coupler	Synchronization mechanism of the network	Remark
EtherCAT®	AXL F BK EC	SM-synchronous	Asynchronous
		DC-synchronous	The bus cycle of the local bus is synchronized with the EtherCAT® cycle. The implemented distributed clock unit is used to synchronize the processes in a temporal manner.
Sercos	AXL F BK S3	Asynchronous	Asynchronous
		Clock-synchronous	Cyclical master-slave communication with a cycle time to be selected during initialization.

**I/O modules**

Not all I/O modules support local bus synchronization.

In the case of modules which support local bus synchronization, the SyncI\_0 (synchronization of inputs) property or SyncO\_0 (synchronization of outputs) property is specified in the "Capabilities" object 0005<sub>hex</sub>.

In the case of an I/O module which works asynchronously, its input or output signals are read or output at a time point determined by the higher-level network. The data is consistent, i.e., all data for a module is processed at the same time point.

In order for the clock master in the higher-level network to calculate the exact time point for an input or output, the module provides the bus coupler or Axioclock with various information. This includes, for example, the minimum possible repeat time, signal processing length, and required run-up for the transfer of the data. These values are either permanently set in the module or are dynamically determined based on the parameterization.

The bus coupler or Axioclock reads the values and makes them available to the clock master. The synchronization time point determined by the clock master, which can be different for each module, is set by the bus coupler or Axioclock in each module that can be synchronized.

In this way, synchronism requirements within a station of a few nanoseconds are achieved. The precision of the overall system is essentially determined by the higher-level network capabilities and its clock master.

Modules that do not support synchronous processing do not affect a synchronous system. They do not accept or transfer the values at a specific point in time but as fast as possible.

## B 5.2 Synchronization options

Modules can either support synchronization or not. When a module can be synchronized, you can use the function or deactivate it, depending on the application.

Table B-5 Synchronization options

Module property	Use	Remark
Cannot be synchronized	Asynchronous	
Can be synchronized	Asynchronous	If synchronization is not required for your application or is not useful, then deactivate synchronous mode.
	Synchronous	The modules are to be synchronized. Select the modules in a suitable manner. Parameterize them accordingly. See <a href="#">Section B 5.3, "Conditions for local bus synchronization"</a> .

## B 5.3 Conditions for local bus synchronization

To make good use of this function, the following conditions must be met:

1. The higher-level controller must support synchronization mechanisms for the network.
2. The bus coupler must support synchronization mechanisms for the network.
3. At least one module on the local bus must support local bus synchronization.

## B 6 Substitute value behavior and power-on behavior

### Substitute values for Axioline F

The term substitute value is used for the behavior when switching on the power supply as well as for the behavior when valid process data is missing.

### Power-on behavior

The power-on behavior defines the module behavior after switching on the power supply. An Axioline F module has this behavior until it receives valid process data.

### Substitute value behavior (failsafe behavior)

The substitute value behavior defines the module behavior when valid process data is missing.

Once a module has exchanged valid process data for the first time after switching on the power supply, the substitute value behavior is activated.

If valid process data is missing (e.g., in the event the connection is aborted), the module changes to the substitute value behavior.

Typically, the substitute value behavior is parameterized using the engineering tool or object 0024<sub>hex</sub> "Substitute value behavior when process data is missing". The following values are possible:

Table B-6 Possible settings for the substitute value behavior

Code (hex)	Behavior	Example: AXL F AO4 1H
0000	Output of zero values	Output of zero values (0 V / 0 mA / 4 mA) at the output
0001	Output of final values	Output of final values (10 V / 5 V / 20 mA) at the output
0002	Hold last value	Hold last value
0003	Substitute value	Acceptance of substitute values from the "Substitute OUT process data" object (002F <sub>hex</sub> )



To determine whether, and if yes, which substitute value behavior can be parameterized for a module, refer to the module-specific data sheet.

## C Technical appendix: Controllers, bus couplers, AXL SE SC ... and AXL SE PD ...

Note the special characteristics of individual controllers and bus couplers when using slot covers (AXL SE SC ...) and Smart Elements for potential distribution (AXL SE PD ...).

### C 1 AXL SE SC, AXL SE PD ...

The following controllers and bus couplers support the Smart Elements AXL SE SC and AXL SE PD ... from the specified firmware version:

Tabelle C-1 Support of AXL SE SC and AXL SE PD ...

Type	Firmware version
<b>Controllers</b>	
AXC 1050	≥ 5.0
AXC 3050	≥ 6.3
AXC F 1152	≥ 2020.0
AXC F 2152	≥ 2020.0
AXC F 3152	≥ 2020.3
<b>Bus couplers</b>	
AXL F BK PN TPS (XC)	≥ 1.30
AXL F BK ETH (XC)	≥ 1.30
AXL F BK EIP	≥ 1.30
AXL F BK EIP EF	≥ 1.30
AXL F BK EC	≥ 1.30
AXL F BK S3	≥ 1.35
AXL F BK PB (XC)	≥ 2.20

Controllers and bus couplers not listed in the table do not support the AXL SE SC and AXL SE PD ....

If you need a slot cover, in this case, use the AXL SE SC-A slot cover or a different Smart Element, such as AXL SE DI16/1.

## C 2    AXL SE SC-A

Note when using bus couplers for PROFIBUS DP with the hardware and software (HW/SW) firmware version it runs:

AXL F BK PB:                      HW/FW  $\leq$  05/2.13

AXL F BK PB XC:                  HW/FW  $\leq$  00/2.13

The bus coupler does not support AXL SE SC-A slot covers.

Use another Smart Element to cover the unused slots, such as AXL SE DI16/1.

## D Index

### Numerics

1-wire technology .....	84
2-wire technology .....	85
3-wire technology .....	85
4-wire technology .....	86

### A

Application note .....	11
Application objects .....	156
Approvals .....	
Approval of a product .....	19
Product with specific approval .....	19
Array .....	143
Axioline F backplane .....	105
Housing versions .....	105
Indicators .....	109
Slots .....	109
Axioline Smart Element .....	
Passive .....	125
Axioline F local bus .....	14, 16

### B

Backplane .....	
see Axioline F backplane .....	105
Bit string .....	143
Block parameterization .....	152, 153
Bus base module .....	27
Design .....	40
Bus connection .....	16
Bus coupler .....	26
Design .....	39
Diagnostics .....	100
Indicators .....	100
Nominal dimensions .....	41
Supply .....	78

### C

Cable connection method .....	136
Cable cross section .....	136
Checking the delivery .....	52
Communication objects .....	143
Standard objects .....	144

Components .....	14
Conductor cross sections .....	71, 118
Conflict dictionary .....	152, 154
Connecting cables .....	
Shielded .....	75
Unshielded .....	74
Connecting shielded cables .....	75
Connecting the network .....	80
Connecting unshielded cables .....	74
Connection .....	
FE .....	17
I/O .....	16
Network .....	80
Supply voltage .....	16
Connection technology .....	82
Connector .....	
Inserting .....	66
Removing .....	66
Connectors .....	16
Control box .....	16, 56
See also Junction box .....	
Control cabinet .....	16, 56
Controller .....	23
Design .....	37, 106
Indicators .....	99
Nominal dimensions .....	41, 107, 108
Cycle time .....	158

### D

Data sheet .....	11
Data transfer .....	135
Data type .....	143
Design .....	37, 106
Bus base module .....	40
Bus coupler .....	39
Controller .....	37, 106
Input/output modules .....	40
Device rating plate .....	144
Device replacement .....	130
Diagnostics .....	17, 99
Bus coupler .....	100
Extended .....	99
I/O modules .....	102

Dimensions		
Input/output modules .....	42, 44	
DIN rail .....	56	
Disposal .....	131	
Downloads .....	12	
<b>E</b>		
End bracket .....	58	
Error		
Diagnostics .....	99, 125	
Extension module .....	23	
<b>F</b>		
FE connection .....	17	
Function blocks .....	144	
Functional ground (FE) .....	90	
<b>G</b>		
Generate product PDF .....	11	
Grounding		
Functional grounding .....	90	
Grounding concept .....	90	
<b>I</b>		
I/O		
Connection .....	16	
I/O modules		
Diagnostics .....	102	
Indicators .....	102	
Indicators		
Axioline F backplane .....	109	
Bus coupler .....	100	
Controller .....	99	
I/O modules .....	102	
Input modules .....	27	
Input/output modules .....	27	
Design .....	40	
Nominal dimensions .....	42, 43, 44, 109	
Supply .....	79	
Intended use .....	19	
Intrinsic safety .....	31	
Intrinsically safe modules .....	30	
IP20 .....	16, 56	
IP20 degree of protection .....	56	
<b>J</b>		
Junction box .....	16, 56	
<b>K</b>		
Kleinspannung .....	15	
Kommunikationsobjekte .....	161	
<b>L</b>		
LED		
I/O connector .....	104	
Power connector .....	102	
Left-alignable module .....	23	
Left-alignment .....	23	
Local bus		
See Axioline F local bus .....	14	
Low voltage .....	15	
<b>M</b>		
Maintenance .....	130, 131	
Manufacturer-specific application objects .....	156	
Marking material .....	110	
Mechanical requirements .....	133	
Modules		
Extension module .....	23	
Left-alignable .....	23	
Maximum number .....	58	
Mounting .....	60	
Order .....	58	
Removing .....	63	
Mounting .....	16, 60	
Distances .....	67	
Location .....	16, 56	
Mounting position .....	57	
<b>N</b>		
Niederspannung .....	15	
Nominal dimensions		
Bus coupler .....	41	
Controller .....	41, 107, 108	
Input/output modules .....	42, 43, 44, 109	
Number of modules .....	58	
<b>O</b>		
Object type .....	143	

Octet string.....	143
Order.....	58
Order designation .....	20
Output modules.....	27

## P

Packing slip.....	10
Parameterization memory .....	18
Passive Smart Element .....	125
PCP objects	
Application objects .....	156
PDI channel.....	127, 129, 143
PDI-Kanal.....	161
Power module	
Supply .....	78
Power supply	
Requirement.....	78
Sizing .....	78
Product description .....	14
Product groups.....	20
Programming interface.....	17, 37
Protective extra-low voltage .....	15
Protective ground (PE).....	92
Push-in.....	74

## Q

Quick start guide .....	11
-------------------------	----

## R

Reaktionszeit .....	174
Record .....	143
Removal.....	16, 63
Replacing.....	130
Reset button.....	17
Response time .....	159

## S

Scope of supply .....	52
Service interface .....	17, 39
Shielding .....	92
Analog sensors and actuators .....	92
Concept.....	92
Connecting the shield.....	75
Slots for Axioline F backplane .....	109

Smart Element	
Passive.....	125
Spring lever.....	48, 50, 73
Standard objects.....	144
Diagnostics .....	147
Startup+ .....	17
Status.....	99
Storage .....	52
Stripping lengths .....	72, 119
Supply	
Bus coupler .....	78
Input/output modules.....	79
Power module .....	78
Supply voltage	
Connection.....	16
System data .....	132

## T

Test voltages .....	137
Tool.....	58
Touch connection .....	48, 73
Transmission speed.....	158
Transport .....	52
TWIN ferrules.....	72, 119

## U

Unpacking.....	52
Unsigned 16.....	143
Unsigned 32.....	143
Unsigned 8.....	143
User manual.....	10

## V

Var .....	143
Versions.....	14
Visible string.....	143
Voltage ranges	
Low voltage .....	17
Protective extra-low voltage .....	17

## W

Web-based management .....	17
----------------------------	----



## E Revision history

Table E-1 Revision history

Revision	Date	Contents	
00	2010-02-16	First publication	
01	2011-08-22	Entire document	Corrections Addition: new modules, housings, connectors
02	2011-09-08	Entire document	Corrected terminology (Push-in technology)
03	2013-12-19	Entire document	Complete revision Change: Axioline -> Axioline F Change: Axio bus -> Axioline F local bus Addition: new modules, housings, connectors Addition: AWG
		Section 1.2 Documentation on the Internet	Correction
		Section 4.4 Color and marking	Addition: colors, function identification, marking
		Section 5.4 Reporting diagnostics via PDI	New: reporting diagnostics via PDI
		Section 6.1 Basic information about mounting	Addition: Warning "NOTE: Disregarding this warning may result in malfunction"
			Revision: mounting position
			Revision: maximum number of modules
		Section 6.3 Mounting/removal	Addition: F-BK bus coupler housing
		Section 9 Technical data and ordering data	Corrections/additions
		Appendix A3 Response times for an Axioline F system	Revision
		Appendix A 5 Communication objects	Addition: visible string
04	2015-05-22	Appendix A General standard objects 5.2	Corrections/additions
		Appendix A 6 Synchronization	New
		Entire document	Complete revision of all sections Additions – New modules, housings, connectors – Low voltage area – Safety notes
05	2015-06-18	Entire document	Corrections

Table E-1 Revision history

Revision	Date	Contents		
06	2017-02-15	Section 6.2	Stripping lengths/insertion lengths	Warning: recommendation for crimping
		Section 8	Diagnostic and status indicators	Addition: notes
		Section 8.3.1	LEDs on the power connectors	Correction for LEDs E1 and E2
		Appendix A	Technical appendix	New: A1 Use of Axioline F modules at an elevation of more than 3000 meters
		Entire document		Notes on safety modules
07	2018-11-22	Section 4.1	Structure of the order designations	Addition: new functions
		Section 4.6	Master	New
		Section 5.1	Housing versions	Addition: housings AXC F 2xxx and 1F (PM)
		Section 5.2.2	AXC F controller	New
		Section 5.3.1	AXC F controller	New
		Section 5.3.4	Power measurement module	New
		Section 6.4	Mounting and removing modules, left alignment	New
		Section 7.2	Conductor cross sections, and stripping and insertion lengths	Addition: text in warning "NOTE: Malfunction when the conductor is not securely fixed"
		Section 7.10.5	Redundant signals	Addition: redundant digital outputs
		Section 9.2	Indicators on bus couplers	Addition: for D LED, flashing yellow/red
		Section 10.3	Saving parameters	Revision
		Section 11	Software support	Revision
		Appendix A4	Response times for an Axioline F system	Revision
		Appendix A5	Communication objects (PDI objects)	Addition
		Appendix A 5.2	General standard objects	Conversion to basic profile V3.0
		Appendix A6	Synchronization	Addition: note
		Appendix A7	Substitute value behavior and power-on behavior	Revision
		Entire document		Deleted: description for BK housing (with integrated bus base) Renamed: F-BK housing changed to BK housing

Table E-1 Revision history

Revision	Date	Contents		
08	2019-11-18	Entire document		Addition: Axioline F backplane
		Section 6	Transport, storage, and unpacking	New
		Section 11	Axioline F backplane	New
		Section 13	Software support	Updated
		Section 14	Device replacement, device defect, and repair	New
		Section 15	Maintenance, decommissioning, and disposal	New
		Appendix A + B	Technical appendix	New structure, PDI objects supplemented
09	2019-12-17	Section 16	Technical data and ordering data	Housing material, addition: self-extinguishing (V0)
10	2020-07-20	Sections 4, 5, 7		Addition: Intrinsically safe modules for the EX area
11	2021-02-26	Section 4.2.2	AXC F XT ... controllers and left-alignable modules	New
		Section 7.8	Mounting clearances: AXC 305x, AXC F x152 controllers	Addition
		Section 8	Connecting or removing cables	Addition: Strain relief
		Section 8.2	Conductor cross-sections, and stripping and insertion lengths	Addition: VIP-CAB-FLK14/AXIO/0,14/
		Section 11.5.3.2	Plugging in Axioline Smart Elements	Addition: Note
		Section 16.1	Technical data	Addition: Ambient temperature for XC versions
		Section 11.6	Connecting and removing cables	Addition: UL note
		Section A 1.2.1	Diagnostic state (0018 <sub>hex</sub> : DiagState)	Addition: Sub-index 00 note
		Appendix B4	Response times in an Axioline F system	Revision
		Appendix C	Controllers, bus couplers, and slot covers	New

Table E-1 Revision history

Revision	Date	Contents		
12	2022-07-15	Entire document		Addition: grounded DIN rail Change: EN 50178 -> IEC 61010-2-201
		Section 7.2	Basic information about mounting	Addition: NOTE: Unauthorized physical access NOTE: Damage to the contacts when tilting the modules
		Section 11.9	Diagnostic and status indicators (Axioline F backplanes)	Revision
		Appendix B4	Response times in an Axioline F system	Revision
13	2022-09-20	Appendix C1	AXL SE SC, AXL SE PD ...	Correction FW version AXL F BK S3
14	2024-02-05	Entire document		Actualization

---

## Please observe the following notes

### **General Terms and Conditions of use for technical documentation**

Phoenix Contact reserves the right to alter, correct, and/or improve the technical documentation and the products described in the technical documentation at its own discretion and without giving prior notice, insofar as this is reasonable for the user. The same applies to any technical changes that serve the purpose of technical progress.

The receipt of technical documentation (in particular user documentation) does not constitute any further duty on the part of Phoenix Contact to furnish information on modifications to products and/or technical documentation. You are responsible to verify the suitability and intended use of the products in your specific application, in particular with regard to observing the applicable standards and regulations. All information made available in the technical data is supplied without any accompanying guarantee, whether expressly mentioned, implied or tacitly assumed.

In general, the provisions of the current general Terms and Conditions of Phoenix Contact apply exclusively, in particular as concerns any warranty liability.

This manual, including all illustrations contained herein, is copyright protected. Any changes to the contents or the publication of extracts of this document are prohibited.

Phoenix Contact reserves the right to register its own intellectual property rights for the product identifications of Phoenix Contact products that are used here. Registration of such intellectual property rights by third parties is prohibited.

Other product identifications may be afforded legal protection, even where they may not be indicated as such.

---

## How to contact us

### Internet

Up-to-date information on Phoenix Contact products and our Terms and Conditions can be found on the Internet at:

[phoenixcontact.com](http://phoenixcontact.com)

Make sure you always use the latest documentation.

It can be downloaded at:

[phoenixcontact.com/products](http://phoenixcontact.com/products)

### Subsidiaries

If there are any problems that cannot be solved using the documentation, please contact your Phoenix Contact subsidiary.

Subsidiary contact information is available at [phoenixcontact.com](http://phoenixcontact.com).

### Published by

PHOENIX CONTACT GmbH & Co. KG

Flachsmarktstraße 8

32825 Blomberg

GERMANY

Should you have any suggestions or recommendations for improvement of the contents and layout of our manuals, please send your comments to:

[tecdoc@phoenixcontact.com](mailto:tecdoc@phoenixcontact.com)



PHOENIX CONTACT GmbH & Co. KG  
Flachsmarktstraße 8  
32825 Blomberg, Germany  
Phone: +49 5235 3-00  
Fax: +49 5235 3-41200  
E-mail: [info@phoenixcontact.com](mailto:info@phoenixcontact.com) **phoe-**  
**nixcontact.com**